


iBMD

Servomotor with integrated drive



iBMD

*Ed. 2.1 - English - 20/07/2016
(Translated from the original instructions)*

IMPORTANT

Bonfiglioli Mechatronic Research Spa reserves the right to make changes to the products described in this document at any time without notice.

This document has been prepared by Bonfiglioli Mechatronic Research Spa solely for use by its customers, guaranteeing that at the date of issue it is the most up-to-date document on the products.

Users use the document under their own responsibility and certain functions described in this document should be used with due caution to avoid danger for personnel and damage to the machines.

No other guarantee is therefore provided by Bonfiglioli Mechatronic Research Spa, in particular for any imperfections, incompleteness or operating difficulties.

Table of Contents

1. General informations on this manual	1
1.1. Aim	1
1.2. Recipients	2
1.3. Responsibilities	2
1.4. Abbreviations	3
1.5. Symbols	5
1.6. Definitions	6
1.7. Reviews	9
2. Information on the <i>i</i>BMD drives	11
2.1. Laws and standards	12
2.2. General features of the <i>i</i> BMD drives	13
2.2.1. Equipment of <i>i</i> BMD series drives	14
2.2.2. Block diagram of <i>i</i> BMD drives	14
2.2.3. Identificative plate	15
2.3. Safety precautions and limits	15
3. Main features of MotionDrive	21
3.1. Requirements and compatibility	21
3.2. Installation	22
3.3. MotionDrive overview	22
4. Quick start for drives <i>i</i>BMD	25
4.1. Before starting	25
4.2. Hardware installation	26
4.3. Setup software	30
4.4. Starting the motion	31
5. Technical features	33
5.1. <i>i</i> BMD technical features	33
5.2. <i>i</i> BMD dimensions and sizes	36
5.3. Downgrading with altitude	38
6. STO safety function: Safe Torque Off	39
6.1. General informations	39
6.2. <i>i</i> BMD functional specifications	43
7. Electrical connections, leds and dip switches	49
7.1. Installation notes	49
7.2. Electrical connections	50
7.2.1. System Supply	50
7.2.2. Fuses	51
7.2.3. Field bus (CAN)	51

7.2.4. iBMD drive connectors	53
7.2.5. Cables for iBMD	62
7.3. Leds	66
7.3.1. Leds arrangement in the iBMD	67
7.4. Dip switches	67
7.4.1. Arrangement and characteristics of the dipswitches of the iB- MD	67
8. Communicating with the drive	69
8.1. Communicate with master CANopen	69
8.2. Communicate with master EtherCAT	72
8.2.1. File access over EtherCAT (FoE) protocol	76
8.3. Communicate with master Modbus RS232 (auxiliary communication port)	76
8.4. Errors in reading / writing of the parameters	76
8.5. CiA402 state machine	78
8.6. System manager	82
9. Communication port CANopen	85
9.1. Network management objects (NMT)	87
9.2. Emergency object (EMCY)	88
9.3. Synchronization object (SYNC)	89
9.4. Service data object (SDO)	89
9.5. Process data object (PDO)	90
9.5.1. PDO Mapping	90
10. Communication port EtherCAT	93
10.1. Protocol CANopen over EtherCAT (CoE)	95
10.2. Emergency Error Code	95
10.3. Process data object (PDO)	96
10.3.1. PDO Mapping	97
10.3.2. Missing or corrupted PDO RX management	97
10.4. Synchronization	98
11. Auxiliary communication port Modbus	101
12. Communicating with MotionDrive	103
12.1. MotionDrive via RS232 (auxiliary communication port)	103
12.2. Offline mode	104
12.3. Communication errors with MotionDrive	106
12.4. Connection status with MotionDrive	107
12.5. Disconnection of MotionDrive	108
12.6. MotionDrive options	108
13. Units of measurement	111
13.1. Units of measurement of the parameters	111
13.2. Revolution resolution	112

13.3. Polarity	113
13.4. MotionDrive units	114
14. Power configuration	115
14.1. iBMD series drives supply: Y topology	115
14.1.1. Supply with iBMD-DC	116
14.1.2. Supply with a generic power supplier	118
14.2. Supply voltages	120
14.3. Regeneration	120
14.4. Drive currents	121
14.5. Power PWM	121
14.6. I2T	122
15. Configuring motor, sensors and brake	125
15.1. Motor parametrization	125
15.2. Sensor of the feedback position	126
15.3. Feedback sensor phasing check.	127
15.4. Absolute feedback position sensor	128
15.5. Auxiliary position sensor	130
15.6. Brake	131
16. Digital inputs and outputs	133
16.1. Digital inputs and outputs of the iBMD drives	133
16.1.1. I/O functionality for iBMD drive	136
16.2. Configuring the I/O through MotionDrive	137
16.3. Configuring the I/O by using the parameters	139
16.4. Functionalities	140
16.5. Filters, polarities and terminations	144
17. Analog input	147
17.1. Capture	148
17.2. Calibration	149
17.3. Conversion	149
18. Capture Peripherals	153
18.1. Configuring the capture by using MotionDrive	154
18.2. Configuration interface selection	154
18.3. Configure the capture by using the CUSTOM interface parameters	155
18.4. Filter on CaptureSource0_A and CaptureSource0_B	156
19. Motion limits	159
19.1. Electricity limit	159
19.2. Limit I2T	159
19.3. Torque limit	160
19.4. Speed limit	161
19.5. Limits of hardware position	161
19.6. Limits of software position	162

19.7. Profiles limit	162
20. System tuning	165
20.1. How to determine the tuning criterion	165
20.2. Reset the tuning	168
20.3. Fast tuning guide	168
20.4. Gains calculation	171
20.5. Detailed tuning guide	173
20.6. Function Generator	180
20.7. RL estimator	183
20.8. Resonance estimator	184
20.9. Inertia estimator	186
21. Saving, restoring or cloning the drive configuration.	193
21.1. Drive configuration	193
21.2. Saving/Exporting parameters file	195
21.3. Downloading parameters file	196
21.4. Importing parameters file	198
21.5. Compare parameters file	198
21.6. Parameters cloning	200
21.7. Permanent memory	201
21.8. Resetting	202
22. Creating a motion	205
22.1. Enabling by using the master	206
22.2. Disabling by using the master	207
22.3. Carrying out a stop by using the master	207
22.4. Change the operative mode with CiA-402 standard parameters	208
22.5. On-the-fly operative mode change	208
22.6. How to control a motion in position	209
22.7. Control of a speed motion	210
22.8. Control of a torque motion	211
22.9. <i>Profile Position Mode</i>	212
22.10. <i>Interpolated Position Mode</i>	214
22.11. <i>Cyclic Synchronous Position Mode</i>	217
22.12. <i>Cyclic Synchronous Velocity Mode</i>	219
22.13. <i>Cyclic Synchronous Torque Mode</i>	221
22.14. <i>Profile Velocity Mode (CiA402)</i>	222
22.15. <i>Profile Velocity Mode (CUSTOM)</i>	223
22.16. <i>Profile Velocity AI Mode</i>	224
22.17. <i>Torque Mode</i>	224
22.18. <i>Torque AI Mode</i>	225
22.19. <i>Homing Mode</i>	225
22.20. <i>Tuning Mode</i>	233
23. Oscilloscope and monitoring	235
23.1. Parameters monitoring	235
23.2. Monitoring by oscilloscope	236
23.3. Setting the oscilloscope Trigger	237

23.4. Saving or uploading an oscilloscope capture	239
23.5. Processing the captured tracks by the oscilloscope	240
24. Fault and Warning	245
24.1. Management of the errors with MotionDrive	247
24.2. Monitoring the errors on the status leds	248
24.3. Reaction to the Warnings	249
24.4. Reaction to the Faults	249
24.5. Resetting the errors	253
24.6. Errors description	253
25. Troubleshooting	271
25.1. Generic problems	271
25.2. Electric and connection problems	272
25.3. Problems with Fault and Warning	272
25.4. Problems with parameters and configuration	273
25.5. Communication problems	274
25.6. Motion problems	274
25.7. Problems with the oscilloscope	275
25.8. Tuning problems	277
26. Software updating	279
26.1. MotionDrive updating	280
26.2. Updating the motors database	280
26.3. Firmware updating	280
26.4. Updating the boot	281
26.5. Updating the Configuration File	282
26.6. ESI EEPROM updating procedure on ETC drive	282
26.6.1. ESI EEPROM updating from MotionDrive through debug serial port	282
26.6.2. ESI EEPROM updating from MotionDrive through gateway CoDeSys	284
26.6.3. ESI EEPROM updating from EtherCAT master in manual mode .	284
26.6.4. ESI EEPROM updating from EtherCAT master in automatic mode	285
27. Parameters vocabulary	287
27.1. Agreements on the parameters description	287
27.2. Reading and writing a parameter	288
27.3. Uploading/downloading	289
27.4. Initial configuration, update and board identity (0-999)	289
27.5. Communication port CANopen (1000-1099)	296
27.6. Communication port EtherCAT (1000-1099)	301
27.7. Auxiliary communication port (1100-1199)	305
27.8. Motor, drive and I2T (1200-1299)	307
27.9. Tuning (1400-1499)	311
27.10. Loop (1500-1599)	317
27.11. Power Pwm (1600-1699)	327
27.12. Drive status (1800-1999)	328

27.13. Fault and Warning (2000-2199)	332
27.14. CiA402 state machine (2400-2449)	340
27.15. System manager (2450-2499)	342
27.16. Capture peripherals (2800-2899)	348
27.17. Feedback sensor (3000-3999)	366
27.18. Motion (4000-4999)	369
27.19. Brake (5000-5199)	390
27.20. Auxiliary position sensor (6500-6549)	391
27.21. Digital inputs and outputs (6550-6999)	393
27.22. Analog input (7000-7999)	400
27.23. PDO managed by the port CANopen (10000-11999)	403
27.24. Sync manager and PDOs managed by the port EtherCAT	414
28. Digital filters	427
29. Order codes	431
29.1. OrderCode	431

Chapter 1

General informations on this manual

CANopen is a registered trade mark of CAN in Automation e. V.

EtherCAT is a registered trade mark and a patented technology, the licence granted by Beckhoff Automation GmbH.

Modbus is a registered trade mark of Schneider Automation Inc.

WINDOWS is a registered trade mark of Microsoft Corporation.

1.1. Aim

This manual is a complete guide to the installation, commissioning, functioning and use of the drives of the series *iBMD*. There are general purpose informations about the functionalities and about the drive structure, notices related to the safety for people and for the product; furthermore, for the technicians in-charge to installation, all the data and specifications to be observed for the wiring and the installation are described.

IMPORTANT

**What is written in this manual refers to the versions of firmware
31 et seq., except from any other different instructions.**

Previous firmware versions could not implement all the functionalities described in this manual.

The description of the different functionalities always refers to the whole series of the drives *iBMD* unless it is specified in which versions you can find the functionalities mentioned in the description.

1.2. Recipients

Only specialized staff can modify the drives of the series *iBMD* and use them, who previously read the manual and all the documents related to the product. Specialized staff must have been adequately trained about safety in order to prevent any possible risks. The technical training, foreground and experience of the specialized staff must help them preventing from any possible risk occurring during the product use, from the settings modification to the functioning of the mechanical, electrical and electronic equipment of the device. The specialized staff must know all the current regulations and safe working practices in case of any intervention on the product.

This manual must be read by the following staff members:

- Transport: only for personnel expert in handling sensitive parts of electrostatic charges.
- Unpacking: only for qualified electricians.
- Installation: only for qualified electricians.
- Use: only for qualified staff expert in electro-technology and activation technology.

The qualified staff must know and follow these rules:

- EN ISO 12100, EN 60364 ed EN 60664;
- national safe working practices.

This manual is addressed to all users of the drives *iBMD* with or without master controller.

WARNING

The nonobservance of the precautions included in this document may cause risk of death, serious injuries or material damage. For a safe functioning, follow all the safety instructions in this manual. The security officer must check that the staff working with the drives read and understood this manual before using them.

1.3. Responsibilities

ATTENTION

Bonfiglioli Mechatronic Research S.p.a can modify the described products in this manual in any time and without any notice.

This manual was written by Bonfiglioli Mechatronic Research S.p.a only for their customers' use providing the most updated version of the products.

The responsibility to use this manual belongs to every user and the use of some functions must be under strict care to avoid any danger for the staff and the equipment.

No other warranty is provided by Bonfiglioli Mechatronic Research S.p.a, in particular for possible imperfections, incompleteness, and/or any other difficulties.

1.4. Abbreviations

Abbreviation	Meaning
0x	Number in hexadecimal notation
+HV	DC bus voltage, supply voltage of the power section
ABS_E	Absolute encoder
A	Motor phase U
AI	Analog input
ac	Alternating current
B	Motor phase V
BDM	Base drive module
C	Motor phase W
CAN	Controller Area Network, filed bus
CDM	Complete drive module
CE	Communauté Européenne
CH A	Channel A of a torque of quadrature signals
CH B	Channel B of a torque of quadrature signals
COB-ID	Communication object identifier
CoE	CANopen over EtherCAT
COM	Serial communication interface for personal computer
CRC	Cyclic redundancy control
D	Phase signal with the magnetic field of the motor rotor
D. Fan	Digital output starting the drive external cooling fan
dc	Direct current
Dir	Direction
Drv OK	Digital output with drive function OK
EEPROM	Electrically erasable programmable memory (permanent memory)
EMC	Electromagnetic compatibility
EMCY	Emergency: protocol object CANopen and EtherCAT to notify any errors
ESC	EtherCAT Slave Controller (ET1100 component)
ETC	EtherCAT, Ethernet for Control Automation Technology, field bus
FA	Phase A of a torque of quadrature signals
FB	Phase B of a torque of quadrature signals
FC + / FC POS	Positive limit switch or positive limit of hardware position
FC - / FC NEG	Negative limit switch or negative hardware position
FC + sw	Positive limit position programmable via software
FC - sw	Negative limit position programmable via software
FoE	File access over EtherCAT
FW	Firmware
GND	Ground
HOME	Digital input of Home
HW	Hardware
I	Input, generally digital
I2C	Inter-Integrated Circuit, two-wire serial communication system used among integrated circuits

Abbreviation	Meaning
I2T	Passing specific over energy
iBMD	Integrated brushless drive
ID	Identifier
LED	Light-emitting diode
LSB	Byte (or bit) less important
MB	Mega Byte
M. Fan	Digital output starting the external fan to cool down the motor
MDB	Modbus, serial communication protocol Modbus on RS232
MSB	Byte (or bit) less important
neg	Negative
NC	Not connected
NMT	Network management: protocol object CANopen to manage the network
O	Output, generally digital
OSC	Integrated oscilloscope
OSI	Open system interconnection
PC	Personal computer
PDO	Process data object: object of the CANopen and EtherCAT protocols to read and write the cyclic data (mappable parameters on the PDOs)
PDS	Power Drive System
PE	Protection Earth, protection conductor
PLC	Programmable logic control, drive integrated programmability
PLL	Phase locked loop
pos	Positive
Q	Quadrature signal with the magnetic field of the motor rotor
PWM	Pulse-width modulation
Pwm O	Output PWM
RAM	Random access memory (non permanent memory)
RES	Resolver
RMS	Root Mean Square, effective value
RTR	Remote transmission request
RX	Reception
SDO	Service data object: object of the CANopen and EtherCAT protocol for the reading and writing of the drive parameters
S1	Continuous service, functioning condition used to reach the thermal value
a.s.l.	Above sea level
SYNC	Synchronization: protocol object CANopen to synchronize the network nodes
SM	Sync manager (SM)
/STO	Safe Torque Off (this is an active-low logic signal)
SW	Software
TBD	To be defined
Temp	Temperature
T _{SYNC}	Period in which the process data (PDO) are exchanged
TX	Transmission
U	Motor phase U

Abbreviation	Meaning
V	Motor phase V
W	Motor phase W

1.5. Symbols








Symbol	Description
 DANGER	It shows a surely dangerous situation, in case of failure to comply with safety rules it can lead to a serious or fatal accident
 WARNING	It shows a probably dangerous situation, in case of failure to comply with safety rules it can lead to a serious or fatal accident or damage to the equipment.
 ATTENTION	It shows a probably dangerous situation, in case of failure to comply with safety rules it can lead to a serious accident or damage to the equipment.
 NOTICE	It shows a potentially dangerous situation, in case of failure to comply with safety rules it can lead to a serious accident or damage to the equipment.
	It shows the presence of dangerous voltages that can cause electrical shocks.
	It shows the problems related to electromagnetic compatibility.
	It shows the presence of surfaces and/or heat sources that can cause burns.

Table 1.1. Danger classes





Symbol	Description
	It shows some information to pay attention to. Please pay attention to what has been shown.
 IMPORTANT	It shows some important information on the mentioned topic.
 NOTE	It shows some important information on the text about the mentioned topic.
 ADVICE	It shows some useful information on the mentioned topic.

Table 1.2. Information classification

Symbol	Description
	Optical coupler









Symbol	Description
	Make contact
	Break contact
	Break command with emergency shutdown, started by a "mushroom-headed" button and at a certain position
	Control coil
	Lamp
	Fuse
	Ground protection
	Screen

Table 1.3. Electrical symbols.

1.6. Definitions

BDM Base drive module

Activation module made up by a conversion section and a section used to check the speed, the torque, the current or the voltage, etc. In this manual the BDW is called **power section**.

CAN 2.0

Standard that describes the *data link layer* and the *physical layer* (ISO/OSI Reference Model) of the CAN bus.

CANopen over EtherCAT

Protocol on EtherCAT bus that allows the access to the drive parameters through SDO CANopen.

CDM Complete drive module

Activation without motor and sensors mechanically coupled to the drive shaft, made up by a BDM, but not limited to it, and other devices, such as the charge section and the auxiliaries.

CiA-301

Detailed note on communication protocols and objects to manage the network CANopen (*Communication Profile DS301*).

CiA-402

Detailed note to define the rules for a standardized behaviour of the drives connected to a fieldbus. The drive management according to this specification is described in [Section 8.5, CiA402 state machine](#). In case of a CANopen network, the specification refers to the *Device profile for drives and motion control DSP402 v.3.0*, the profile is constructed basing on the [CiA-301](#). In case of an EtherCAT network, the specificateion refers to the *Implementation Directive for CiA-402 Drive profile ETG.6010*.

Distributed clocks

Mechanism used to synchronize the masters and the slaves in the network EtherCAT (functionality implemented in the chip [ET1100](#)).

Drive

See [PDS Power drive system](#) definition

Drive disable

States of the CiA402 State Machine (see [Section 8.5, CiA402 state machine](#)) in which the torque is not applied to the motor and the motor control loops aren't active.

Drive enable

States of the CiA402 State Machine (see [Section 8.5, CiA402 state machine](#)) in which the torque is applied to the motor and the motor control loops are active.

File access over EtherCAT

Protocol on bus EtherCAT used to update the drive directly from the files.

Index

Encoder zero mark.

Master

[Node](#) taking control of the communication bus and starting first to interact with the other connected nodes.

Node

Hardware device (drive, sensors, actuators) connected to the communication bus which can communicate with the other devices.

Operation disable

States of the CiA402 State Machine (see [Section 8.5, CiA402 state machine](#)) where it is not possible to command the motor motion. The drive can be enabled or disabled.

Operation enable

State of the CiA402 State Machine (see [Section 8.5, CiA402 state machine](#)) where it is possible to command the motor motion.

Integrated PDS

PDS where the motor and the CDM/BDM are mechanically integrated in a single unit.

PDS Power drive system

System used to control the speed of an electric motor, including the CDM and the motor, but not the already started equipment. In this manual the PDS is simply called **drive**.

Network protocol

All rules, mechanisms and formalities that two or more electronic devices connected one another must respect to start a communication.

Real-time

Drive command mode used to control the motor motion continuously and in pre-arranged time.

Modbus register

Memory area of 1 Word = 16 bit = 2 byte that contains a numeric value, accessible both in reading and in writing. It's identified by a number that represents its memory position and it's used to exchange data in the Modbus protocol.

Functional safety

Part of the safety of the machine and the machine control system which depends on the correct functioning of the [Safety system](#), other technology safety-related systems and external risk reduction facilities.

Safety system

(Even named SRECS) Machine electrical control system whose failure can result in an immediate increase of the risk(s).

Sync manager (SM)

Functionality of the chip [ET1100](#) (contained in the drives version ETC) used to exchange data in a safe and sound way between the master and the drives EtherCAT. For any further information please look [EtherCAT Technology Group \(ETG\)](#).

Sync Signal

Hardware signal generated by [ET1100](#) and managing the [Distributed clocks](#).

Discrepancy time (maximum)

(Maximum) time interval during which a difference between the signal logic level is allowed.

Transition

Intermediate phase that allows the transition from a state to another one of the CiA402 State Machine (see [Section 8.5, CiA402 state machine](#)).

1.7. Reviews

Revision History		
Revision 2.1	20/07/2016	Author: Bonfiglioli Mechatronic Research S.p.a
<ul style="list-style-type: none"> • First manual revision. 		

Chapter 2

Information on the *i*BMD drives

The drives *i*BMD are digital drives for three-phase sinusoidal brushless motors with permanent magnets. In particular, the *i*BMD drive is composed by a brushless motor, a feedback position sensor, static brake (optional), interface to the field buses, power section and control section. All versions of this drive type have digital I/O, analog input, leds and dip switches. There is also a permanent memory and an auxiliary serial port in which the protocol Modbus has been implemented.

The software on the drives of the series *i*BMD is divided into two types:

- *Boot firmware*: it boots the drive by enabling some basic services and, after an initial phase of identification and diagnostics of the system, it runs the firmware
- *Firmware*: it manages all the drive operating functions

The firmware provides some different working operating modes that can be divided into three classes:

- *Position modes*: the drive receives a position reference and follows the motion in order to minimize the error between the reference value and the current position.
- *Speed modes*: the drive receives a speed reference and runs the motion in order to minimize the error between the reference value and the current speed.
- *Torque modes* : the drive receives a torque reference and runs the motion in order to minimize the error between the torque reference and the current found in the phases.

NOTE

The drive mission time is 20 years.

NOTE

For further details on the features and options of the available versions, see [Chapter 5, Technical features](#) and [Chapter 29, Order codes](#).

2.1. Laws and standards



The products of the *iBMD* series are in accordance with the following specifications:

- 2004/108/CE relating to electromagnetic compatibility;
- 2006/95/CE relating to electrical equipment designed for use within certain voltage limits;
- 2006/42/CE relating on machinery;

in conditions in which the installation may be considered as typical (then the instructions in the user manual are respected and there are not particular work environment or installation needs).

Bonfiglioli Mechatronic Research S.p.a guarantees the conformity of the drive to the harmonized standards:

EN 61800-5-1:2007	Adjustable speed electrical power drive systems Part 5-1: Safety requirements - Electrical, thermal and energy
EN 61800-3:2004 EN 61800-3/A1:2012	Adjustable speed electrical power drive systems Part 3: EMC requirements and specific test methods
EN 61000-6-2:2005/ AC:2005	Electromagnetic Compatibility (EMC) Part 6-2: Generic Standards - Immunity for industrial environments
EN 55011:2009 EN 55011/A1:2010	Limits and methods of measurement of radio disturbance characteristics of industrial, scientific and medical (ISM) radio frequency equipment
EN 60204-1:2006 EN 60204-1/A1:2009	Safety of machinery - Electrical equipment of machines Part 1: General requirements
EN 61800-5-2:2007	Adjustable speed electrical power drive systems Part 5-2: Safety requirements - Functional safety
EN ISO 13849-1:2008	Safety of machinery - Safety-related parts of control systems Parte 1: General principles for design

The products of the *iBMD* series are commercialized as components of a Power Drive System, belong to the restricted distribution category and are intended to the installation in industrial environment. If used in domestic environment it may be necessary to take further emission measures and appropriate precautions.

The installation of these devices is intended to specialized personnel that has an in-depth knowledge about the safety requirements and the electromagnetic compatibility (EMC).

The planner has the responsibility to guarantee that the product or the final system comply to the pertinent regulations that are in force in the country in which the product (or the entire system) is used.

If the entire system is connected to a low voltage distribution public network it will be necessary to pay attention to the network harmonic and flicker inclusion effects to guarantee the overall certification.

2.2. General features of the *iBMD* drives

Features	<i>iBMD</i>
Motor size	See the table at the beginning of the Chapter 5, Technical features
Range of supply of the power section	See the table at the beginning of the Chapter 5, Technical features
Range of supply of the control section	See the table at the beginning of the Chapter 5, Technical features
Feedback sensor	Hyperface absolute Encoder
Main communication port (field bus)	CANopen or EtherCAT with CiA-402 device profile
Auxiliary communication port	Modbus on RS232
Multifunction port	N. 3 differential bidirectional lines (RS485 compatible) for presettable default functions (master encoder input, pulse-dir#, others)
Rotary dip switches	Setting the node number and/or communication speed of the main bus
Leds	Information and local diagnostics through transparent window
Number of digital bidirectional I/O	4
Number of digital inputs	6
Number of digital outputs	3
Number of analog inputs	1
Functional safety	See Chapter 6, STO safety function: Safe Torque Off
Electrical insulation	Adequate distances of electric insulation both in the surface and in the air are guaranteed according to the EN61800-5-1 regulation, between the input voltage of the DC bus/motor connections and the signal and communication electronics of the control section (refer to Chapter 5, Technical features).
Protections	<ul style="list-style-type: none"> • DC bus overvoltage • short circuit and/or overcurrent on the motor phases • power section overtemperature • control section circuits overtemperature • Motor winding overtemperature • motor energy overload, through I^2T (please refer to Chapter 24, Fault and Warning and to Section 14.6, I²T).
Permanent memory	YES
Integrated PLC	YES

Table 2.1. Features of the *iBMD* drives

2.2.1. Equipment of iBMD series drives

The drive package includes:

- the iBMD drive (in the CAN or ETC version)
- plastic cap for the M8 connector
- “dust cover” plastic cap for the M23 I/O connector
- package leaflet

NOTE

No flying connector or cable is included in the standard equipment.

Before to begin to work with the drive, verify that there are not visible damages. Be sure that the iBMD drive you have taken from the package is the correct model for your application, that it corresponds to what you have ordered and that you can provide a voltage supply as prescribed for the system.

2.2.2. Block diagram of iBMD drives




Figure 2.1. Block diagram of iBMD drives

2.2.3. Identificative plate




Figure 2.2. Product plate example.

Reference	Meaning
1	Product designation
2	Product code
3	Stall torque
4	Nominal torque
5	Rated speed
6	Brake nominal torque
7	Range of input voltage of the power section
8	Nominal power ^a of the power section input
9	Protection degree
10	Motor class of insulation
11	Bus communication protocol mark
12	Control section voltage range
13	Maximum current of the control section
14	Working ambient temperature for a functioning compliant to the technical data
15	Serial number
16	Serial number in bar code format

^areferring to the torque at the rated speed

Table 2.2. Plate fields

2.3. Safety precautions and limits


⚠ WARNING

The precautions described in this paragraph are perfect to avoid any dangerous situation by suggesting the right use of the product. Only qualified staff who read and understood all the documents on this product can use it. The specialized staff must follow a safety training in order to know which individual protective equipments to be taken and to avoid any risks related to the product use (included any changes in the parameters) and to find a possible solution.

⚠ DANGER

The drive must not be used in an explosive or corrosive environment, in the presence of inflammables, water or fuels. There can be risk of fire, electrical shock or injuries.

In case of failures because of accidental circumstances or wiring errors the power section can even cause electric arcs. The drive must be installed in an environment without any inflammables. It is particularly forbidden to use it in the presence of inflammable gases or vapours.

 NOTICE

The drives can be used/installed outdoor, but can't be directly exposed to the sunlight (UV rays).



 DANGER

Do not transport, install or make any connections or inspections when the drive is charged. In such cases switch the power off, wait for some seconds until the voltage is lower than 50 volts, otherwise there can be risks of electrical shock or damaging the drive.

The connector used to connect the power supply may have a high voltage.
Do not touch these devices when the drive is supplied, even if it is disabled.



 DANGER

The usage of this product implies the presence of a voltage greater than 50V, therefore there is life-threatening and a risk of electric shock and serious injury. Follow the general and safety regulations when you are working on the power related installations.

Do not connect the power connector (power supply and/or motor) when the drive is powered. There can be electrical arcs that can damage the connector and the drive and cause a fire.

 WARNING

The protection from surge must be delegated to a device that's external from the iB-MD drives, after an accurate risk analysis made by the integrator of the machine.

 WARNING

Keep the drive power supply within the specified ranges in order to avoid any risks of fire, electrical shocks and damaging the drive. In the same way connect the cables in a safe way by respecting the connections.



 DANGER

Do not touch the connection devices when the drive is in voltage. In case of maintenance be aware that the voltage in the power connectors is lower enough to not cause an electrical shock.



 **DANGER**

**Do not touch the drive or the motor during functioning or immediately after its disabling: the surface temperature can be higher than 80°C.
To prevent any risks of damaging the drive do not obstruct or limit its ventilation.**

 **WARNING**

Do not open and do not modify the system: for any internal checks please contact Bonfiglioli Mechatronic Research S.p.a. In case of forcing the system the warranty expires.

 **ATTENTION**

**Please do not short-circuit any signals from the power connector with the drive case or logic signals (for example coming from the connectors for the field bus).
It's recommended a control section supply wiring separated by the power supply one, in order to avoid malfunctioning and to limit the control logic signals noises.
The cables section for the power stage must be adequate to the drive power.**

 **WARNING**


**The section of the power supply conductors must be adequate to the drive power and not lower than 1.5 mm².
Always connect the protection ground and the functional mass with two separate cables.**

 **DANGER**


In case of simultaneous failure of two power semiconductors (IGBT) of the power section, it is possible that the motor turns by 180°/number of pole pairs.

 **DANGER**

**Don't apply an excessive force on the motor shaft, in order to avoid the damage of the bearings.
If the key is installed on the motor shaft, be sure that it is fixed to the machinery so that the key cannot slip off from its seat.**


 **NOTICE**

Insofar as their purpose allows, accessible parts of the drive have no sharp edges and no rough surfaces likely to cause injury. In case the key is removed, the sharp edges of the key seat are accessible to the user, unless the shaft plastic cover is installed: beware the injury danger in case of removing the plastic cover or the shaft key.


 **NOTICE**

The drive has dip switches to set the node number and/or communication speed of the main bus. All this settings must be made when the drive is switched off. To prevent damages to the drive it's recommended to pay particular attention when working on this settings because in

the drive there are some components that are sensitive to the electrostatic discharge. It's in particular advisable to preventively discharge the static electricity, to place the drive on a conductive support and to avoid contact with highly insulating materials. **BEFORE TO POWER THE SYSTEM, REMEMBER TO FASTEN THE TRANSPARENT COVER (if it has been removed).**

 NOTICE

When some Fault is found, the drive automatically disables and a led signal shows the possible cause: the motor is no longer in torque and it can move to another position and may damage the devices and/or the surrounding people. It must be made a evaluation of the risk about the particular machine in which the product is used. In consequence the user must take appropriate measures to avoid risks to the safety of the person.

 NOTICE


When there is a Fault, the drive is disabled; before enabling it again by rebooting the system or by some correct commands through the field bus, remove the cause generating the Fault.

 WARNING

The magnetic and electromagnetic fields, that are generated by the conductors in which the current flows or by permanent magnets inside the electric motors, represent a serious danger for the people with the pacemaker, metallic prostheses and hearing aids. Be sure that these people have no access to the areas in which these systems are presents (both during functioning and in storage). Eventually, if these persons have to enter in the described areas, consult a doctor.

 WARNING

The device builder using the drives iBMD must analyse the risk for the device and implement the necessary measures to safeguard the device itself and the surrounding people from any unforeseen motions.

 NOTICE

The drive has been designed and constructed so that risks resulting from the emission of airborne noise are reduced to the lowest level. The airborne noise emission and the related risks for the user are in any case depending on the application and must be analyzed by the machine designer.



 ATTENTION

The drive has been designed and constructed to limit the build-up of potentially dangerous electrostatic charges and is provided of a discharging system: the chassis is made of metal and polimeric material. The metallic part is protected by the grounding system. The non-metallic materials may build-up electrostatic charges in case of contact with other insulating materials.

 DANGER

This product is intended to be exclusively used in machines and systems in industrial environment, respecting the described application, environmental and functioning conditions.

Follow the safety regulations and the ordinances of the country in which the product (or the relative control and command system) is used.

It is recommended not to use the product for any further purpose than those specified in this manual.

Chapter 3

Main features of MotionDrive

MotionDrive is a programme for *personal computer* used to control, configure and programme in a simple, quick and perceptive way the drives of the *iBMD* series.

From the tab Main of MotionDrive it is possible to know the whole drive status. For example: the detailed description of the found errors, the status of the outputs and the digital and analog inputs, position and speed of the shaft, drive operative status, connection status, etc... From MotionDrive it is possible to export the drive parameters in a text file to clone more drives in the same mode by exporting the parameters from one drive to another.

MotionDrive offers a window for programming, diagnostics and control of the internal PLC.

IMPORTANT

What is written in this manual refers to the MotionDrive 3.0.1.223 versions et seq. Previous versions of MotionDrive could not implement all the functionalities described here.

3.1. Requirements and compatibility

Minimum PC requirements:

- System with compatible processor Pentium 133 MHz or higher.
- Sufficient memory for the operating system, minimum 128 MB, recommended 512.
- Hard disk with minimum available space to install the programme, at least 35MB.

- Display adapter and monitor Super VGA, minimum resolution 800 x 600 px, better 1024x768 px or higher.

Compatibility with the following operating systems:

- Microsoft Windows XP
- Microsoft Windows Vista, 7, 8 or latest versions, 32bit and 64bit.

3.2. Installation

Check if all the system prerequisites are respected ([Section 3.1, Requirements and compatibility](#)).

Installation from the Bonfiglioli website

- Connect to the <http://www.bonfiglioli.com> website and enter the *Products & Solutions* through the *iBMD* drop-down menu.
- Enter in the pages dedicated to the *Business Unit Industrial* and, from here, enter the section that's dedicated to the products and download the *MotionDrive.msi* file.
- Run the *MotionDrive.msi* downloaded file by following the proposed installation procedure.
- Every *MotionDrive* version is released with the most updated firmware, in relation to the release date.

Installation from file

- If the *MotionDrive.msi* file is already on the PC, run the file and follow the proposed procedure, otherwise contact Bonfiglioli Mechatronic Research S.p.a in order to request the file.
- Every *MotionDrive* version is released with the most updated firmwares and motors database, in relation to the release date.

ADVICE

Please accept all the configurations proposed during the installation.

3.3. MotionDrive overview

All the functionalities of *MotionDrive* can be accessible through the three tabs (Bus, Main), the menus or the toolbars.




Figure 3.1. Tab Main of MotionDrive

Tab	Functionalities	Link
Main	Variables status	Section 23.1, Parameters monitoring
	Analog inputs status	Chapter 17, Analog input
	Errors status	Chapter 24, Fault and Warning
	Configuration File	Section 26.5, Updating the Configuration File
	Digital I/O status	PhysicalOutputs and DigitalInputs
	<code>ManufacturerDeviceName</code>	Section 29.1, OrderCode
	Enable status	Operation enable
Bus	Configure the Main bus	Chapter 8, Communicating with the drive
Program	Programme the internal PLC	Chapter under construction.

Table 3.1. Functionalities of the two main tabs

Chapter 4

Quick start for drives

iBMD

For a quick test installation of the drives *iBMD*, follow what is reported in this chapter.

4.1. Before starting

Safety precautions



Before installing the drive, read the paragraph on safety [Section 2.3, Safety precautions and limits](#). If you do not follow the safety instructions you may damage the equipment or be hurt.

Requested instruments, materials and equipment

- Supply system to supply the control and power section;
- Supplying cable to connect to the connector [CN5](#);
- Serial cable to connect to the connector [CN1](#);
- Screwdrivers to tighten the supply conductor according to the suitable wiring;
- PC with serial port RS232 and with the requisites in [Section 3.1, Requirements and compatibility](#).




Figure 4.1. Minimum setup for the quick start.

4.2. Hardware installation

1. Mechanical installation

For the system installation use the 4 holes on the motor anterior flange. The dimensions are reported on the [Section 5.2, iBMD dimensions and sizes](#). Be sure that the drive and the motor ventilation is free, respecting however the maximum admitted environment temperature (see [Chapter 5, Technical features](#)).

2. Connection of the protection conductors

Connect the PE protection conductor to the motor flange as shown in the [Figure 4.2](#). For detailed informations about the connection to the protection conductors see [Section 7.2.1, System Supply](#).



Figure 4.2. Connection of the PE protection conductor to the flange

3. Connection of supplies and /STO

ADVICE


For further details please refer to [Chapter 6, STO safety function: Safe Torque Off](#).

Connect the supplies and the /STO input according to what's reported in the following scheme.



DANGER

Before proceeding, check if the power supplies are switched off and there is no more voltage in the connection terminal boards.



To connect the pins of **CN5**, please pay attention to what is shown in the following table:

PIN	Signal	Description
1	HV -	DC Power supply (negative pole)
3	-	Not connected
4	HV +	DC Power supply (positive pole)
T	PE	Protection Earth
A	/STO	Safe Torque Off Input (this is an active-low logic signal)
B	GND	Ground Control supply
C	IN9	Digital Input 9
D	+24 V	+24Vdc Control supply
Chassis		

The STO integrated function is implemented in the drives according to the EN 61800-5-2 norms and is used to execute a stop of 0 category according to the EN 60204-1 norms.

 WARNING

When the voltage of the digital input associated to the STO function is cut off, the motor torque is disabled in a safe way, the drive power section is disabled without cutting the voltage to the DC bus and it is not possible to control the motor motion. It is advisable to always stop the motor before disabling the input /STO.

4. Connection of the serial port

Connect the serial port RS232 to the connector **CN1** of the iBMD drive.

 WARNING

Connect and disconnect the communication connectors only when the drive is switched off. Check if the Ground Control Supply pin of **CN5, the drive and the PC are correctly connected to the protection conductor.**



To connect the pins of **CN1**, please pay attention to what is shown in the following table:

PIN	Signal	Description
1	TX232	Transmit Data RS232
2	RX232	Receive Data RS232
3	NC	Reserved, not connected
4	GND_COM	Ground RS232
Chassis	PE	Protection Earth

5. Confirmation of the connections

After having completed the connections, check if they are correctly connected and switch on the power supply of the control section (24Vdc). The leds of the transparent window should have the following configuration. If it is not so, see [Table 7.6](#).

- L1 RED ON; L2 RED 2 FLASH; drive in Fault for [DC bus under voltage](#);
- L4 GREEN, 1 FLASH, [ActualMotorCurrent](#) at 0;
- L3 and L5 OFF;
- L6 OFF, no voltage on the /STO input.




4.3. Setup software

1. MotionDrive installation

Install the last available version of MotionDrive that you can download from the <http://www.bonfiglioli.com> website or that is provided by Bonfiglioli . Accept the configurations proposed by the installation procedure. For further details see [Section 3.2, Installation](#).

2. Starting MotionDrive

Start MotionDrive from: **Start menu** > **Programs** > **Bonfiglioli** > **MotionDrive** and set the [Connection parameters](#) in the proposed window *Drive connection* .




In case of problems see [Section 12.3, Communication errors with MotionDrive](#) or [Section 25.5, Communication problems](#).

3. Configuration restoring

Restore default parameters

Check if you are using the default configuration, push the button in the window *Permanent memory* (**Main menu > Drive > Permanent memory...**)




4.4. Starting the motion

IMPORTANT

The quick start guide is designed to perform the movement command only with the MotionDrive tool, without the interference of the fieldbus (CANopen / EtherCAT) master. The MotionDrive tool is not designed to command the *iBMD* drives in one of the real time modes.

1. Enabling the power

After having checked if the connections are correct and safe, switch on the power supply of the power section. Check if the voltage applied is included in the right ranges and reset any errors.



2. Enabling/disabling the drive and the motor motion.

- Turn on the voltage to the /STO input and check if the led L6 is switched on (GREEN);
- enable the drive by pushing the On/Off button shown in the previous picture; the drive enters the status **Operation enable** by giving voltage to the motor phases;
- write a rotation speed:
 - Open the *Object dictionary* window; **Main menu > Drive > Object dictionary...**
 - write 4700 in the field *Address Modbus* (parameter **TargetVelocity**);
 - write 8000 in the field *Value*;
 - by pushing the *Write* button, the motor starts moving at 8000inc/s. To modify the speed, modify the value of the parameter **TargetVelocity**.

IMPORTANT

To stop the motion, write 0 in the parameter **TargetVelocity** and only then disable the drive.

Chapter 5

Technical features

5.1. iBMD technical features

Power section		
Supply voltage	Vdc	Nominal 560; Minimum 275; Maximum 730 ^a
Internal fuse	-	-
Capacity on DC bus	μF	2.2 for motors with 82/102 mm flange 5.45 for motors with greater flange

^aThe DC bus must be obtained from a TT or TN network; system voltage (nominal voltage between phase and earth): MAX 300V [overvoltage category III]

Control section		
Supply voltage without brake	Vdc	24 (-15% / +15%)
Supply voltage with brake	Vdc	24 (-10% / + 6%)
Threshold drive disabling	Vdc	18.3
Error threshold for the brake	Vdc	20.9
Absorbed current @ 24Vdc (control section only)	mA	Nominal 250; Max 500;
ADDITIONAL absorbed current @ 24Vdc (if brake is present)	mA	500 with 4.5Nm brake; 750 with 9Nm brake; 1000 with 18Nm brake; 1100 with 36Nm brake.

Control section		
ADDITIONAL absorbed current @ 24Vdc (with outputs ON)	mA	See Table 16.5
Internal fuse	-	4A-T not replaceable

iBMD features (flange of 82mm, 102mm)					
		iBMD 82 2.7	iBMD 82 3.8	iBMD 102 5.1	iBMD 102 6.2
Flange dimension	mm	82	82	102	102
MotorPoles	-	8			
MotorRatedSpeed @ 560Vdc	rpm	3000			
Stall torque (continuous supply with flanged motor on metallic heat sink 280Ø x 20mm)	Nm	2.7	3.8	5.1	6.2
Torque peak	Nm	8.4	11.0	16	23
Nominal torque @ 3000rpm e 560Vdc	Nm	2.4	3.3	4.5	5.5
Motor nominal power @ 3000rpm e 560Vdc	kW	0.75	1.04	1.41	1.73
Power consumption in continuous functioning ^a	kW	0.91	1.20	1.60	1.92
Motor inertia moment	kg m ² * 10 ⁴	1.40	1.70	3.70	4.70
Maximum radial load @ 3000rpm (applied on the shaft centreline)	N	470	500	610	650
Maximum axial load (applied on the shaft centreline)	N	94	100	120	130
Bearings duration	h	20000			
Mechanical Shock according to the IEC 60068-2-27 standard 3 shocks per direction, on 3 axes. Pulse duration of 11ms.	g	14			
Sinusoidal vibration according to the IEC 60068-2-6 standard from 5 to 500 Hz, on 3 axes.	g	2			
Class of insulation	-	F			
Weight without brake	kg	4.0	5.1	6.3	7.9
ADDITIONAL weight in version with brake	kg	0.7	0.6	1.2	1.0
ADDITIONAL weight in versions with fly-wheel	kg	0.7	0.7	1.3	1.3
Brake static torque at 20°/100°	Nm	4.5/4	4.5/4	9/8	9/8
ADDITIONAL moment of inertia in version with brake	kg m ² * 10 ⁴	0.18	0.18	0.54	0.54
ADDITIONAL moment of inertia in version with fly-wheel	kg m ² * 10 ⁴	3	3	7.5	7.5
Working ambient temperature	°C	0 ÷ 40			
Storage ambient temperature	°C	-20 ÷ 70			
Humidity related to storage and working (without condensation)	%	5 ÷ 95			
Maximum installation altitude (without adding devices that can limit the overvoltage ^b)	m	2000 m.s.l.			

iBMD features (flange of 82mm, 102mm)					
		iBMD 82 2.7	iBMD 82 3.8	iBMD 102 5.1	iBMD 102 6.2
Ventilation	-	Natural			
Pollution degree	-	3 ^c			
Protection degree	-	IP65 ^d if the connectors are inserted			

^aat 3000rpm, at the overtemperature limits and with environment temperature of 40°C

^bfor an installation altitude between 2000m and 4000m m.s.l., it's necessary to install an overvoltage limiter device on the machine to oppose the transient overvoltages, so that the power circuit overvoltages are limited to the overvoltage category II. It can be achieved with a galvanic insulation transformer.

^cConductive pollution or dry non conductive pollution that can become conductive in case of condensation

^danterior flange excluded.

iBMD features (flange of 145mm, 170mm)					
		iBMD 145 14.5	iBMD 145 18.5	iBMD 170 29	iBMD 170 36
Flange dimension	mm	145	145	170	170
MotorPoles	-	8			
MotorRatedSpeed @ 560Vdc	rpm	3000			
Stall torque (continuous supply with flanged motor on metallic heat sink 390Ø x 20mm)	Nm	14.5	18.5	29	36
Torque peak	Nm	39	45	62	70
Nominal torque @ 3000rpm e 560Vdc	Nm	11	12.5	14.7	21
Motor nominal power @ 3000rpm e 560Vdc	kW	3.45	3.93	4.62	6.60
Power consumption in continuous functioning ^a	kW	3.85	4.33	5.05	7.16
Motor inertia moment	$\text{kg m}^2 * 10^4$	12.8	17.6	28.2	47.5
Maximum radial load @ 3000rpm (applied on the shaft centreline)	N	1150	1200	1400	1500
Maximum axial load (applied on the shaft centreline)	N	229	240	285	305
Bearings duration	h	20000			
Mechanical Shock according to the IEC 60068-2-27 standard 3 shocks per direction, on 3 axes. Pulse duration of 11ms.	g	14			
Sinusoidal vibration according to the IEC 60068-2-6 standard from 5 to 500 Hz, on 3 axes.	g	2			
Class of insulation	-	F			
Weight without brake	kg	17.6	20.6	27.4	32.4
Additional weight in version with brake	kg	2.6	2.6	4.5	4.5
ADDITIONAL weight in versions with fly-wheel	kg	3.6	3.6	5.5	5.5
Brake static torque at 20°/100°	Nm	18/15	18/15	36/32	36/32
Additional moment of inertia in version with brake	$\text{kg m}^2 * 10^4$	1.66	1.66	5.56	5.56
ADDITIONAL moment of inertia in version with fly-wheel	$\text{kg m}^2 * 10^4$	36	36	70	70

		iBMD features (flange of 145mm, 170mm)			
		iBMD 145 14.5	iBMD 145 18.5	iBMD 170 29	iBMD 170 36
Working ambient temperature	°C	0 ÷ 40			
Storage ambient temperature	°C	-20 ÷ 70			
Humidity related to storage and working (without condensation)	%	5 ÷ 95			
Maximum installation altitude (without adding devices that can limit the overvoltage ^b)	m	2000 m.s.l.			
Ventilation	-	Forced with integrated fans			
Pollution degree	-	3 ^c			
Protection degree	-	IP65 ^d if the connectors are inserted			

^aat 3000rpm, at the overtemperature limits and with environment temperature of 40°C

^bfor an installation altitude between 2000m and 4000m m.s.l., it's necessary to install an overvoltage limiter device on the machine to oppose the transient overvoltages, so that the power circuit overvoltages are limited to the overvoltage category II. It can be achieved with a galvanic insulation transformer.

^cConductive pollution or dry non conductive pollution that can became conductive in case of condensation

^danterior flange excluded.

NOTE

The torque values and the related power values are referred to the maximum allowed functioning environment temperature, that is 40°C.

5.2. iBMD dimensions and sizes




Figure 5.1. iBMD dimensions

Size	Shaft				
	D	E	DB	GA ^a	F ^a
82	11	23	M4	12.5	4
	14	30	M5	16	5

Size	Shaft				
	D	E	DB	GA ^a	F ^a
102	19	40	M6	21.5	6
	19	40	M6	21.5	6
	24	50	M8	27	8
145	19	40	M6	21.5	6
	24	50	M8	27	8
	28	60	M10	31	8
170	24	50	M8	27	8
	28	60	M10	31	8
	32	60	M12	35	10

^aAvailable in no-keyed shaft versions

Size	Flange					
	M	N	P	S	T	LA
82	100	80	82	6.5	3	10
	115	95	100	9	3	10
102	100	80	102	7	3	10
	115	95	102	9	3	10
145	165	130	145	11.5	3.5	12
170	165	130	170	11.5	3.5	12

Size	Motor with integrated drive										
	T0	AC	PA	LB2 ^a	LB3 ^b	LC	LD	LE	HA	HB	HC
82	2.7	82	80	121	174	117	16	202	144	142	62
	3.8		80	141	194						
102	5.1	102	80	141	191	117	16	202	164	142	62
	6.2		80	168	218						
145	14.5	145	142	228	275	120	-	300	225	222	80
	18.5		142	228	310						
170	29	170	142	233	305	120	-	300	225	222	80
	36		142	286	357						

^aStandard motor length

^bStandard motor length with brake or fly-wheel

5.3. Downgrading with altitude




Figure 5.2. Torque and current downgrading in relation to the altitude.

Chapter 6

STO safety function: Safe Torque Off

IMPORTANT

By “STO” is meant the safety function, while in order to refer to the physical input and to the external signal it is used the “/STO”. In this last definition the bar “/” represents the “NOT” logical function, to indicate that the safety function removes the motor torque if the signal voltage is at low logic level.

6.1. General informations

The STO integrated function is implemented in the drive according to the EN 61800-5-2:2007, EN ISO 13849-1:2008/AC:2009 standards. When, the digital input the function STO is linked to is switched to the low logic level, the motor torque is disabled according to a stop of category 0, as defined in the EN 60204-1:2006/A1:2009 standards.

WARNING

If the digital input with /STO function is disabled, the drive power section is disabled without cutting the DC bus voltage and it is not possible to control the motor motion anymore. Always stop the motor before to switch to the low logic level the /STO input. In case of suspended loads, some other measures in order to reduce the risk of load falling must be considered, for example installing a dynamic brake.

 WARNING

It must be made an evaluation of the risk about the particular machine in which the product is used. In consequence the user must take appropriate measures to avoid risks to the safety of the person. In order to guarantee the safe removal of the motor torque, it is recommended to use the “Safe Torque Off” function, by using only the provided input named /STO and the related instructions included in this guide.

The examples and the procedures described in this manual are based on the reaching of the de-energized state of the drive as safe state (e.g. in case of emergency).

In case there are external forces on the load (e.g. in case of vertical loads), some additional actions must be considered in order to prevent danger risks (e.g. by using a mechanical brake, eventually commanded by a safe output).


 DANGER

The Safe Torque Off function DOESN'T cut off the voltage nor in the drive power and logic circuits neither in the motor, therefore it CANNOT be considered as an insulation system of the drive from supply sources (DCbus). In order to execute the maintenance service on the drive electrical components or on the motor, it is necessary to insulate the supply system first.


 DANGER

The /STO input is not protected against overcurrent: the user, if he deems it appropriate, can provide external protections.

The STO function can be used to prevent an unintentional start of the motor: the STO function use is possible in case some quick operations have to be executed (e.g. the machine cleaning) and/or for maintenance services on NOT electrical parts of the machine, without cutting off the drive supply voltage.

 WARNING

It is recommended to not stop the drive and/or the motor by using the Safe Torque Off function. If the motor is stopped through the STO function, the drive cuts off the power to the motor and it stops due to the inertia. Furthermore, in the motors that are provided of the internal holding brake, the motor brake can be damaged. In order to avoid these dangerous/damaging situations, stop the drive and the motor with the provided modes before to use the STO function.

It has been provided a diagnostics system of the STO system status, that allows the anomalies report to the user.

NOTE

The **Safety system has been completely hardware realized: the STO functionality is independent from the software configuration and version of the drive. The software manages only the anomalies warning signal, but doesn't prevent the system safety setting.**

Environment conditions and EMI

The environment and operating conditions in which the **Safety system** functioning is provided and guaranteed, are the same ones of the entire system (see [Chapter 5, Technical features](#)).

Stop categories (IEC EN 60204-1)

Uncontrolled stop: the intervention of the STO function disables the drive and cuts off the torque from the motor, therefore the axis is free to move according to the uncontrolled stop of cat.0 (EN 60204-1).

Controlled stop: if the application requires a controlled stop according with the stop of cat.1 (EN 60204-1), the following actions must be executed respecting the listed order:

1. deceleration of the motor through the braking ramp, executed by the drive (see [Section 22.3, Carrying out a stop by using the master](#));
2. drive disable (this operation must be executed when the motor is in standstill)¹ (see [Section 22.2, Disabling by using the master](#));
3. motor torque safe removal through the /STO input switched to the low logic level;

In the following picture a graphic representation of the above described phases is reported.

¹The voltage must be cut off after a delay, that has to be programmed on the safety relay, that has to be sufficient to include the stop of the motor; otherwise the final part of the movement will be uncontrolled.




Figure 6.1. Steps of a controlled stop

NOTE

The digital inputs to which is possible to associate the **Enable** functionality are not part of the **Safety system** system and, consequently, the motor deceleration is not a safety function.

Residual risk

In case of fault for short circuit on one or more IGBT power semiconductors, despite the safe removal of the motor torque, there is the residual risk that the drive produces on the motor shaft a maximum rotation of $360^\circ / (2p)$, where $2p$ is the motor poles number.

6.2. iBMD functional specifications

Safety system

In the picture below the blocks that are part of the **Safety system** with STO function are included in the yellow/black dotted outline, marked with the «SAFETY SYSTEM» writing. The references in the picture, represented by the yellow circled numbers, are related to the following parts of the system:

1. /STO input on CN5 connector;
2. STO input circuit;
3. IC controller for the management of the converter that supplies the gate drivers;
4. Converter for the gate drivers voltage supply;
5. Gate driver for the IGBTs.




Figure 6.2. System block diagram

Mode of operation

The STO **Safety system** allows the deactivation of the control voltage of the power semiconductors (IGBT) of the drive output stage through the input /STO signal, avoiding the generation of enough voltage to provide power to the motor.

The states of the **Safety system** are the following:

- in case the voltage that's applied to the /STO input is at high logic level: the STO **Safety system** allows the drive enabling and so the torque may be present on the motor (**potentially not safe status**);

- in case the voltage that's applied to the /STO input is at low logic level: the STO [Safety system](#) cuts off the voltage on the motor phases, so that there is no torque and the automatic start-up is disabled (**safe status**);

After the disabling, the drive can be enabled after these operations have been executed:

- restore of the high logic level on the /STO external input;
- deleting of the alarms via software;
- sending of the command to switch the drive in the [Drive enable](#) state.

The safety function is independent of the status of the drive: it is always active and continuously executed. In fact there are no configurations able to temporary disable the safety function.

/STO input electric features

/STO INPUT	
Input type	PNP
Input current (typical) with $V_{in} = 24V_{dc}$	10.5 mA
Input voltage (low or high logic level)	
Nominal	+24Vdc
for low signals	-30V ÷ +5Vdc
for high signals	+20V ÷ +30Vdc

ATTENTION

The /STO input is compatible with the auto-diagnostic digital outputs of a command device, in which the test pulse has a maximum duration of 1ms. This implies that the motor torque is not removed if the /STO input receives a low logic level pulse with a duration lower than 1ms.

Led 6 diagnostics

The STO system logic state (for the meaning see [Mode of operation](#)) is monitored by a microcontroller and signaled through the software (bit 24 di [LogicalDigitalInputStatus](#)) and the Led 6, as reported in the following table:

STO logic status	Led 6
Voltage presence on the input and Fault absence	ON
Voltage absence on the input and/or Fault presence	OFF

IMPORTANT

In the boot and firmware start-up phases of the iBMD drives, the above description of the led is no more valid. Please refer to [Chapter 26, Software updating](#)

Continuous /STO input validation

The /STO input validation function continuously monitors the voltage level applied to the input: if this level keeps a value between the reference thresholds (+20V for the high level

and +5V for the low one, see [/STO input electric features](#)) for more than 500ms, the error is reported through the [MainError](#) (see the bit 14 in the [Table 24.1](#)).




Figure 6.3. Voltage levels of the /STO input

Environment conditions and EMI

The environment and operating conditions in which the [Safety system](#) functioning is provided and guaranteed, are the same ones of the entire system (see [Chapter 5, Technical features](#)).

Safety related data

The STO function is completely implemented via hardware as safety function with single channel.

It is furthermore provided a STO system status monitoring circuit that detects the presence of failures on the [Safety system](#).

Functional integrity level (EN 61800-5-2)	Performance level (ISO EN 13849-1)
SIL3	PLd

According to the EN 61800-5-2 standards it is guaranteed a probability of dangerous failure $PFHd = 6.27 \cdot 10^{-8}$ with safe failure fraction $SFF = 99\%$, obtaining a [Functional safety](#) integrity level equal to SIL3.

According to the ISO EN 13849-1 standard, the STO [Safety system](#) is characterized by an architecture that complies to the Cat. 2 with $DC=90\%$ reaching a performance level equal to PLd. The applied failure exclusions correspond to the ones that are reported in the Attached D of the EN 61800-5-2 standard.

Response time

 ATTENTION

The STO function has a maximum response time of 120ms. This time has been measured by cutting the voltage applied to the /STO input (the maximum allowed, 30V), with negligible external capacity.

The response time corresponds to the time interval between the instant of the /STO input state transition from high to low logic level and the instant in which the voltage that's present on the IGBT supply circuit is reset to zero, that coincides with the system safety state.

STO system diagnostics

The [Safety system](#) includes a diagnostics, that works via software, that detects the hardware faults of the STO circuit. For a description of the errors that are detected by the STO system, please refer to [/STO Management Error](#).

Risk mitigation

The STO function has a single channel architecture. It implies that if in the /STO external signal connection happens a single fault that provides to the input enough energy to keep it at the high logic level (e.g. a /STO signal short circuit with a voltage of 24V), and this fault is not detected, it may occur a STO function interruption: in order to reduce the risk due to any eventual failure, the external connection of the /STO signal must be protected from faults that accidentally may provide it a voltage that puts the system in a not safe condition. It can be obtained in several modes:

- a. by completely isolating the /STO signal from the output of the device that commands the iBMD input; or
- b. by shielding the /STO signal connection cable and connecting the shield to GND (/STO signal command voltage potential reference); or
- c. by monitoring the /STO signal status from the control device (e.g. by using a control device with an output, which can generate a test pulse, connected to the /STO) that allows an independent disabling of the drive.

/STO input connection examples

The connection examples in [/STO input connection examples](#) report the general scheme for the /STO input wiring and don't have to be intended as detailed and complete pictures. The integration of the STO function in the machine must be the result of the complete risks analysis of the machine made by the machine designer.

Test and periodic check of the STO function

The machine final assembly manager must do the test and the periodic check of the safety functions, verifying the correct functioning.

The periodic test/check procedure must be done with a frequency that respects the following situations:

- at the first safety function start-up;
- after every modification related to the safety function (wiring, settings, ecc.);
- after every system maintenance intervention;
- at least every 24 months (2 years), starting from the first put in service of the system and, in any case, after the machine has not been used for an equal or greater time period;

The test/periodic check of the safety functions must be executed only by expert and authorized personnel, that have the necessary competence related to the use of the functions and knows the risks in case the safety functions don't work as they should. The periodic test/check must be documented and undersigned by authorized personnel and the reports of the result of the test, eventual faults alarms and problems resolutions must be archived.

Test/periodic check procedure

- check that the STO circuit wirings related to the drive and the control circuit are correctly executed as reported in [/STO input connection examples](#);
- check that the shield of the /STO input cable is electrically connected to the GND in correspondence of the signal source and the drive connector (mandatory test in case the mode “b” has been adopted, in reference to the [Risk mitigation](#) paragraph);
- with /STO input at high logic level and the drive in the [Drive enable](#) status, check that the torque is present on the motor and that there are no safety alarms;
- disable the drive and, successively, cut off the voltage from the /STO input (through the control device/s suitable for this function). Check that the “/STO = 0V with drive enabled error” or other safety alarms are not presents (see [/STO Management Error](#)) and that the motor is free to move (torque absence);
- when the drive is disabled and the /STO input is at low logic level, enable again the drive. Check that the alarm report related to the enable attempt with /STO input at low logic level (“/STO = 0V with drive enabled error”) is present and that the motor is still free to move (torque absence - safe status);
- in these conditions switch the /STO input to the high logic level and check that the motor is still free to move (torque absence - safe status); furthermore, check that the fault written above is present;
- reset the alarm and, with the /STO input set to the high logic level, enable the drive. In these conditions the motor must be enabled (on torque) and neither the “/STO = 0V with drive enabled error” alarm nor other safety alarms must be present.

 **ATTENTION**

In case some inconsistencies are detected, in relation to the overwritten expected results, the [Safety system](#) cannot be considered intact and the drive mustn't be used. Contact Bonfiglioli Mechatronic Research S.p.a in order to obtain an adequate support and for the record of the fault event: in addition, it will be necessary to proceed with the repairing operation by the authorized personnel. This procedure is necessary to guarantee the safe use of the drive.

Chapter 7

Electrical connections, leds and dip switches

7.1. Installation notes

ATTENTION

The *i*BMD systems must be installed by specialized personnel only that must have an in-depth knowledge about the safety requirements and the electromagnetic compatibility (EMC). The planner has the responsibility to guarantee that the product or the final system comply to the pertinent regulations that are in force in the country in which the product (or the entire system) is used.

IMPORTANT

The producer must analyze the risks and apply the correct measures to avoid damages to people or things that may be caused by unexpected movements (due for example to a drive or its command system anomaly).

NOTICE

The *i*BMD system must be installed in an environment that guarantees the conditions that this manual prescribes (see [Section 2.3, Safety precautions and limits](#)), in particular it must be protected from excessive humidity and/or condensation. Furthermore it must be respected the maximum environment temperature (see [Chapter 5, Technical features](#)), considering that the heat that's produced by the system must be adequately dissipated in order to not exceed the maxi-

imum working temperature. To ensure the maximum reliability of the system and of the related installation, the regular controls for the maintenance of the overwritten conditions must be done.

IMPORTANT

Before to make any intervention (as for example the transparent cover removal for the settings of the communication bus) always disconnect the voltage supply through an approved isolation device and wait at least 1 minute to be sure that the residual voltages will revert to the security levels. Please consider also that the permanent magnets motors generate electric power if they are rotated, even when the system supply is disconnected. Therefore pay attention if the load connected to the motor may rotate it when the drive is not powered.

⚠ NOTICE

The removing of the transparent window to set the dip switches exposes the electronics to the external environment, causing the risk of an involuntary infiltration of foreign bodies that may cause damages. Limit the window opening to the strictly necessary time to set the dip switches.

7.2. Electrical connections

The section about the electrical connection includes both the connectors pins and the characteristics and the description of the different parts which the system is made of; in particular the supply section, with the related limits, and the interface section (communication bus, digital inputs and outputs, analog input, debug serial port).

⚠ NOTICE

A correct cable, ground and shield wiring is essential for the drive safety and correct functioning. It's better if the cables are not interrupted; if it is not possible, be sure that the interruptions are reduced to the shortest possible length. It's recommended to always wire the cables without voltage presence.

7.2.1. System Supply

For the system supply a voltage for the control section and another one, separated from the first one, for the power section are necessary. Both these voltages must be of DC type (direct voltage) The connector for the voltage supply is [CN5](#).

There are no restrictions about the supply sequence: it can be provided the control voltage supply first and then the power one, or vice versa. But without the control voltage the system doesn't turn on, therefore in this situation the leds don't light and it's not possible any communication (even if the power voltage is present). In the technical data table in the [Chapter 5, Technical features](#) there are the limits of the control and power sections voltage.

Connection notes

To connect the voltage supply use a shielded cable with an adequate section. The cable shield must be connected to the ground on the power pack side.

The grounding of the drive is made through the grounding wire of [CN5](#) that must be connected to the equipotential collector of the machine. In order to the safety, to a well functioning of the drive and to a better behaviour against the noises, it's necessary to make the

connection of the metallic structure, where the motor flange is fixed, to the ground equipotential network (through a low impedance conductor with a not lower than 4 mm² section).

 **ATTENTION**


NEVER apply neither an AC type voltage (alternating voltage), nor a DC type voltage (direct voltage) out of the described limits range or with a reverse polarity than the one described in the manual: this may cause the damage of the power and/or control sections of the drive, and imply electrical arcs or fire risk.

 **ATTENTION**

The drive is provided of a control in case of overvoltage or undervoltage, so that the drive is disabled if there are some supply problem, but this doesn't exclude to maintain the voltage between the limits, in particular in case of overvoltage. In fact, no "dump" circuit on the supply voltage is present.

 **ATTENTION**

The unit is **NOT** protected against the +HV supply polarity reverse: pay attention during the connector wiring.

 **NOTICE**

The control section voltage supply must be guaranteed "on the system connector level". Be sure that this range is respected in particular if a long cable is used (eventually compensate the voltage drop in the cable by giving a higher voltage upstream).

ADVICE

Refer to [Chapter 14, Power configuration](#).

7.2.2. Fuses

Control section

The drive is provided, internally to the control section, of a non replaceable fuse (SMT type): **DO NOT SUBSTITUTE FOR ANY REASON THIS FUSE**. In fact the fuse breaking probably implies a damage of the electronics: in this case please contact Bonfiglioli Mechatronic Research S.p.a

Power section

On the power section there are no fuses.

7.2.3. Field bus (CAN)

The CAN version drives are provided with a CANopen serial communication port for the connection with a network master with DS301 standard protocol and a maximum commu-

nication speed of 1MBaud. To facilitate the installation the dip switches for the baud rate and node ID selection and for the termination resistance insertion are presents on the drive (see [Section 7.4, Dip switches](#)).

On the system are also provided two connection connectors CAN-IN and CAN-OUT (CN2 e CN3) to which is possible to connect the CAN input cable from the previous node and the output cable to the next one.

In the next table there are the main characteristics of the serial connection. About the general characteristics of the serial connection, of the topology, of the maximum connectable nodes number, of the baud rate/length relationship, and of the transmissive device specifications, it's necessary to refer to the specific manual "CANopen Net peripherals".

CAN SERIAL CONNECTION CHARACTERISTICS	
Protocol	CAN (ISO-11898 Ver. 2.0 Part B)
Admitted Baud Rate	20, 50, 100, 125, 250, 500, 1000 Kbaud
Galvanic isolation	YES
Termination resistance	Can be inserted through the DP4 dip switch (see Table 8.2)
Communication protocol	CANopen DS301

Transmission medium: CAN cable

The transmission medium that has to be used for the physical connection must be a *shielded cable with 2 twisted pairs*. In particular you have to use *a pair for the CAN_H and CAN_L signals and the other one for the CAN_GND*. It's necessary to use only one type of cable on a single network.

In the [Table 7.2](#) and [Table 7.3](#). the characteristics for the realization of a cable for a physical CANopen network are described.

7.2.4. iBMD drive connectors





Figure 7.1. Connectors arrangement: flange rear view 82-102mm (left) and flange lower view 145-170mm (right).

CN1 Auxiliary bus (RS232 Serial port)

Connector for the auxiliary bus with Modbus protocol on RS232, M8 female, 4 poles (this serial port is insulated).

IMPORTANT

Make the serial cable connection when the drive is not powered. The cable shield must be connected to the ground both on the host (PC) side and on the drive side, by using the M8 connector chassis. If between the drive PE earth potential and the connected master system potential (e.g. a PC) there is a non zero difference, it's necessary to make equipotential the two references. When it is not possible, connect the serial cable shield on one side only.




Female

PIN	Signal	Description
1	TX232	Transmit Data RS232
2	RX232	Receive Data RS232
3	NC	Reserved, not connected
4	GND_COM	Ground RS232
Chassis	PE	Protection Earth

CN2 e CN3 Main bus (ETC)

Connectors for the main bus with EtherCAT protocol, M12 female, 4 poles, D-code, output and input respectively of CN2 e CN3.



Female, D - code

PIN	Signal	Description
1	TX Data+	Transmit Data +
2	RX Data+	Receive Data +
3	TX Data-	Transmit Data -
4	RX Data-	Receive Data -
Chassis	PE	Protection Earth

CN2 e CN3 Main bus (CAN)


Connectors for the main bus with protocol CANopen, M12 male and female, 5 poles, A-code.

IMPORTANT

The cable shield must be continuous on the whole line and must be connected to the earth through the network master, while on the iBMD peripherals the shield must be connected on the pin 1 of the M12 connectors.



Male, A - Code



Female, A - code


PIN	Signal	Description
1	SHIELD	Shield
2	NC	Reserved, not connected
3	GND_CAN	Ground CAN
4	CAN-H	CAN High
5	CAN-L	CAN Low
Chassis	PE	Protection Earth

CN4 Input/Output

Connector for the digital and analog inputs and outputs, M23 male, 19 poles (16+3), Hummel.

NOTE

The PNP digital inputs (24V) have the common ground internally connected to the system on the GND signal, that is the 24V supply ground present on **CN5**-pin B. For this reason it's sufficient to connect on the inputs a signal which level is referred to this ground.



Male, Hummel

PIN	Signal	Description
1	IN/OUT1 -	Differential digital Input/Output 1 (-)
2	IN/OUT2 -	Differential digital Input/Output 2 (-)
3	AN_IN -	Analog Input (-)
4	AN_IN +	Analog Input (+)
5	IN/OUT2 +	Differential digital Input/Output 2 (+)
6	GND_5V	Ground of +5V
7	+5V	+5V Supply (max 150mA) for master encoder
8	IN8	Digital Input 8
9	OUT5	Output 5
10	IN/OUT3	Digital Input/Output 3
11	IN7	Digital Input 7
12	IN/OUT0 -	Differential digital Input/Output 0 (-)
13	IN/OUT0 +	Differential digital Input/Output 0 (+)
14	IN/OUT1 +	Differential digital Input/Output 1 (+)
15	IN4	Digital Input 4
16	OUT4	Output 4
17	OUT6	Output 6
18	IN6	Digital Input 6
19	IN5	Digital Input 5 (the function Simulated GND is available)
Chassis		

IMPORTANT

In/Out0, In/Out1, In/Out2 are differential inputs they DON'T have to be connected to 24V signals. It's recommended to respect the maximum differential voltage and to report this voltage to the GND_5V ground [pin 6 of CN4].

IMPORTANT

Absolutely avoid to place the I/O signals cable in parallel to the power cables by suitably selecting separated paths. It's recommended to use a shielded cable for the connection and to connect the shield to the metallic part of the M23 circular connector. On the controller/PLC side follow the constructor instructions about the shield connection.

Example of PNP 24V inputs and outputs wiring

On the *iBMD* system PNP inputs may be connected some devices with PNP 24V output. The ground reference of these outputs must be the same on which the *iBMD* system control supply is referred (pin B of CN5, GND signal). In fact, as can be seen on the following diagram, the inputs have a system internal common ground that's connected on the GND signal. The *iBMD* system outputs are internally powered by the 24V with which the control section is powered (pin D of CN5). On this voltage there is a current limiter that is a protection in case of overload or short circuit on the outputs themselves. The ground of the loads that are connected to the outputs must be the same one of which the *iBMD* system control supply is referred (pin B of CN5, GND signal).

In the following figure an outputs and inputs connection example is reported in which the 24V voltage for the inputs supply and the outputs ground reference are made through connections that are external to the *iBMD*.




Figure 7.2. Example of inputs and outputs wiring with external supply.

It's possible to make these connections directly on the *iBMD* system (as reported on the [Figure 7.3](#) example). Through the software settings it's possible to configure the IN5 input (pin 19 of CN4) as "SIMULATED GROUND". In this case the IN5 can't be no more used as input because it is, internally to the system, connected to the GND (the same ground of pin B of CN5). This pin can be used to connect the output ground references. In the same way on one (or more) outputs it's possible to configure through software the "SIMULATED 24V" functionality. In this case the configured as described output can't be no more used as output because it is, internally to the system, connected to the 24V (the same 24V of pin D of CN5). The pin that's related to this output can be used to provide the supply 24V.




Figure 7.3. Example of inputs and outputs wiring with internal supply.

The current limits of the pins that have been used as SGND ("SIMULATED GROUND") and S24V ("SIMULATED 24V") are reported on the [Table 16.5](#). On the S24V configured pins a protection for the overcurrent or short circuit is present. The pin 19 of CN4 (IN5) configured

as SGND is not protected from the overcurrent. It is therefore recommended to respect the maximum declared current absorption. If a greater absorption is needed it is necessary to connect the ground externally from the iBMD, as showed in [Figure 7.2](#).

Generic differential IN/OUT

The IN/OUT0, IN/OUT1, IN/OUT2 inputs (line-driver differentials), can be even used as normal digital inputs (generic input functionality) The voltage levels are not 24V as for the PNP inputs, but they are referred to the line-drive specific levels that are described in the [Table 16.3](#).




Figure 7.4. Example of IN/OUT wiring with generic input functionality.

⚠ NOTICE

The differential IN/OUT, even if used with generic input functionality, are differential line-drive type. Do not connect signals with 24V levels! Please refer to the electrical features described in the [Table 16.3](#).

Master Encoder Input (differential IN/OUT)

The IN/OUT0, IN/OUT1, IN/OUT2 inputs (line-driver differentials), as well as with generic input functionality, can be used as incremental encoder inputs (phase A and phase B): to select the functionality please refer to [Chapter 16, Digital inputs and outputs](#). If used as encoder inputs, IN/OUT0 and IN/OUT1 must be respectively connected to the encoder phase A and phase B and IN/OUT2 can be eventually used for the [Index](#) connection. They can be used incremental encoders whose supply can be provided externally or directly by the drive. For this purpose on the CN4 connector of the iBMD is available a 5V voltage (max 150mA). In case the encoder is externally powered, or a simulated encoder is used, in addition to the differential signals (phase A, phase B and eventually the [Index](#)) the encoder ground must be connected to the GND_5V signal of the iBMD (pin 6 of CN4).

For the external encoder connection on CN4 please refer to the [Figure 7.5](#) in which are showed both the wirings when the supply is provided by the iBMD and when the supply is external.




Figure 7.5. Master encoder to differential IN/OUT wiring example.

NOTE

In this figure only one pair of twisted wires is showed. For informations about the cable see [Table 7.4](#).

NOTICE

The encoder outputs must be differential line-driver, compatibles with the [Table 16.3](#)described characteristics. Do not connect signals with 24V levels!

ADVICE

It is suggested the usage of a shielded cable with twisted pairs to make the connection. To ensure the maximum noise immunity it can be used a double shielded cable (shield on each single twisted pair plus whole cable shield). It's suggested to connect the shield to the ground (connector chassis) only on the *iBMD* side. If possible the cable must not be interrupted. If the interruptions cannot be avoided, ensure that the shield is continuous and that the not shielded part has the minimum possible length.

Analog input

The drive has a differential analog input (CN4 connector: pin 3 and 4) to which different functionalities can be associated (see [Section 17.3, Conversion](#) and [Section 22.16, Profile Velocity AI Mode](#)).

ADVICE

For the analog input configuration please see the [Chapter 17, Analog input](#).
 For the analog input electric characteristics see the [Table 17.2](#).

⚠ ATTENTION

The maximum common-mode voltage of the differential analog input must not exceed the value that is reported in [Table 17.2](#). For that reason it's recommended to refer the analog device supply ground to the GND_5V signal [pin 6 of CN4], as reported in the [Figure 7.6](#) connection diagram.




Figure 7.6. Analog input wiring example (on CN4).

NOTE


In this figure only one pair of twisted wires is showed, relative to the pins 3 and 4. For informations about the cable see [Table 7.4](#).

ADVICE

It is suggested the usage of a shielded cable with twisted pairs to make the connection. To ensure the maximum noise immunity it can be used a double shielded cable (shield on each single twisted pair plus whole cable shield). It's suggested to connect the shield to the ground (connector chassis) only on the iBMD side. If possible the cable must not be interrupted. If the interruptions cannot be avoided, ensure that the shield is continuous and that the not shielded part has the minimum possible length.

CN5 DC Power and Control supply, /STO, IN9

Connector for the supply of the power section and of the control section, plus two digital inputs /STO and IN9, M23 male, 8 poles (4 + 3 + PE), Hummel.



Male, Hummel

PIN	Signal	Description
1	HV -	DC Power supply (negative pole)
3	-	Not connected
4	HV +	DC Power supply (positive pole)
T	PE	Protection Earth
A	/STO	Safe Torque Off Input (this is an active-low logic signal)
B	GND	Ground Control supply
C	IN9	Digital Input 9
D	+24 V	+24Vdc Control supply
Chassis		

/STO input connection examples

The external connection of the /STO input must be protected and this can be obtained by isolating the connection or by using more simply a shielded connection with the shield connected to PE. Alternatively the /STO input can be driven by an output of a safe PLC with a test pulse duration of 1 ms.




Figure 7.7. Example of connection of the /STO input for stop of category 0 without module fuse relay: stop not controlled.




Figure 7.8. Example of connection of the /STO input for stop of category 0 with fuse relay and interlock at the reboot: stop not controlled.

To obtain a stop of category 1 connect the /STO input as shown in the following picture. The request for emergency stop initially causes the disabling of the digital input of **Enable**. This causes a motor stop according to the settings in the parameter **DisableOption**. After having programmed a delay on the fuse relay, the voltage on the input /STO is cut off and the power section is deactivated. The programmed delay must be enough to stop the motor, otherwise the final part of the motion becomes uncontrolled.

IMPORTANT

The digital inputs to which it is possible to associate the functionality of **Enable, are not safe inputs and consequently the deceleration is not safe.**




Figure 7.9. Example of connection of the /STO input for stop of category 1 with fuse relay and interlock at the reboot. The functionality of **Enable** is associated to the input N9.

7.2.5. Cables for iBMD

Connector	Cable	
<p style="text-align: center;">Male</p> <p style="text-align: center;">Flying connector on iB-MD side, connection view</p>	iBMD side	host side
<p>Example: Productor: Binder Connector: 9933630004</p>		
	<ul style="list-style-type: none"> Total shielding 3 or 4 wires maximum total length 5m 	

Table 7.1. Specifications for the RS232 serial cable (CN1).






Connector	Cable	
 <p>Male, D - code</p> <p>Flying connector on iB-MD side, connection view</p>	<p>iBMD side</p>  <p>to connector chassis</p>	<p>master side</p>  <p>TX Data+ RX Data+ TX Data- RX Data-</p> <p>to connector chassis</p> <p>ETC</p>
 <p>Female, A - code Male, A - Code</p> <p>Flying connector on iB-MD side, connection view</p>		<p>CAN</p>
<p>Example: Connector: M12, D-code (ETC) / M12, A-code (CAN)</p>	<ul style="list-style-type: none"> • Total shielding (mixed: film and sock) • 2 twisted pairs • maximum total length: 30m (CAN) / 100m (ETC) • Conductive material: tinned copper <p>Added requirements for the CAN cable</p> <ul style="list-style-type: none"> • Characteristic impedance Z_0: 120Ω ($100 \Omega \leq Z_0 \leq 150 \Omega$) • Net termination: Resistor 120Ω, 1/4 W (equal to Z_0) 	

Table 7.2. Specifications for the Main bus cable for the iBMD - master connection (CN2 e CN3 and CN2 e CN3)








Connector	Cable	
 <p>Male, D - code</p> <p>Flying connector on both sides, connection view</p>	<p>iBMD side</p>  <p>iBMD side</p>	<p>ETC</p>
 <p>Female, A - code Male, A - Code</p> <p>Flying connector on both sides, connection view</p>		<p>CAN</p>
<p>Example: Connector: M12, D-code (ETC) / M12, A-code (CAN)</p>	<ul style="list-style-type: none"> • Total shielding (mixed: film and sock) • 2 twisted pairs • maximum total length: 30m (CAN) / 100m (ETC) • Conductive material: tinned copper <p>Added requirements for the CAN cable</p> <ul style="list-style-type: none"> • Characteristic impedance Z_0: 120Ω ($100 \Omega \leq Z_0 \leq 150 \Omega$) • Net termination: Resistor 120Ω, 1/4 W (equal to Z_0) 	

Table 7.3. Specifications for the Main bus cable for the iBMD - iBMD (for CAN version CN2 e CN3 and for ETC version CN2 e CN3)

Connector	Cable	
 <p>Female, Hummel</p> <p>Flying connector on <i>iB-MD</i> side, connection view</p>	<p><i>iBMD</i> side</p>  <p>to connector chassis</p>	<p>Command devices or actuators side</p>  <p>IN/OUT0+ IN/OUT0- IN/OUT1+ IN/OUT1- IN/OUT2+ IN/OUT2- AN_IN+ AN_IN- IN5 - +5V GND_5V IN8 IN4 OUT5 OUT4 IN/OUT3 OUT6 IN7 IN6 Shield</p>
<p>Example: <i>Product</i>or: Hummel <i>Connector</i>: 7.106.500.000 <i>Insert</i>: 7.003.919.102 <i>Contacts</i>: (3x, pin 12, 19, 6) 7.010.901.512; (16x) 7.010.901.012</p>	<ul style="list-style-type: none"> • Total shielding • 10 twisted pairs (as an alternative 11 fili + 4 twisted pairs^a) • maximum total length 30m 	

^aThe wires pairs that must be twisted are the ones that correspond to the differential IN/OUT and to the analog input.

Table 7.4. Specifications for the Input / Output cable (CN4).




Connector	Cable	
 <p>Female, Hummel</p> <p>Flying connector on <i>iB-MD</i> side, connection view</p>	<p><i>iBMD</i> side</p>  <p>to connector chassis</p>	<p>supplier side</p>  <p>HV- HV+ PE /STO GND Shield IN9 +24V Shield Shield</p>
<p>Example: <i>Product</i>or: Hummel <i>Connector</i>: 7.106.500.000 <i>Insert</i>: 7.084.943.102 <i>Contacts</i>: (3x, pin 1, 4, T) 7.010.942.002, (4x) 7.010.941.002</p>	<ul style="list-style-type: none"> • Total shielding • 2 wires + PE + 2 shielded and twisted pairs • low capacity (example: UNIKA UNIDRALL 5005 cod. 3J049) • maximum total length 30m 	

Table 7.5. Specifications for the DC bus, control, STO and IN9 cable (CN5)

7.3. Leds

The leds can have the following statuses:

- *OFF*: led switched off;
- *ON*: fixed led switched on;
- *BLK* (blinking): led 200 ms on, 200 ms off;
- *1 FL* (1 flash): led 200 ms on, 1 s off;
- *2 FL* (2 flash): led 200 ms on, 200 ms off, 200 ms on, 1 s off;
- *3 FL* (3 flash): led 200 ms on, 200 ms off, 200 ms on, 200 ms off, 200 ms on, 1 s off;
- *FLK* (flicker): led 50 ms on, 50 ms off.

The notifications meaning, shown through the leds, can be found in the link in the following table:

<div style="background-color: #00FF00; padding: 5px; display: inline-block;">IMPORTANT</div> <p>In the boot and firmware start-up phases of the description of the six leds L1-L6 is not the one indicated below. Please refer to Chapter 26, Software updating</p>

Leds	Description	Link
L1, L2	Drive status (Fault, Warning, enabling)	Table 8.10
L3, L5	Reserved (led off)	-
L4	Limitation status I2T	Table 14.2
L6	STO logic status	<i>iBMD</i> : Led 6 diagnostics
LA	CANopen error led (ERR)	Table 8.3
LB	CANopen run led (RUN)	Table 8.4
L/A 0	Status of the Physical link/activity of the EtherCAT port on the CN3 connector (for <i>iBMD</i>).	Table 8.6
L/A 1	Status of the Physical link/activity of the EtherCAT port on the CN2 connector (for <i>iBMD</i>).	
ERR	EtherCAT error led (ERR)	Table 8.7
RUN	EtherCAT run led (RUN)	Table 8.8

Table 7.6. Leds description.

7.3.1. Leds arrangement in the iBMD




Figure 7.10. Leds and dipswitches arrangement in the transparent window of the iBMD.

7.4. Dip switches

7.4.1. Arrangement and characteristics of the dipswitches of the iBMD

The dip switches arrangement for the iBMD drives is shown in Figure 7.10. The parameters defined by the dip switches can be found in the following charts.

Dip sw	Description	Link
DP1	EtherCAT user address (station alias) x100	Configured station alias
DP2	EtherCAT user address (station alias) x10	
DP3	EtherCAT user address (station alias) x1	

Table 7.7. Description of the dip switches for iBMD/ETC drives.

Dip sw	Description	Link
DP1	Baud rate CANopen	Baud rate through dip switch
DP2	Node identification x10	Node number through dip switch
DP3	Node identification x1	
DP4	Termination of the CANopen network	Table 8.2

Table 7.8. Description of the dip switches for iBMD/CAN drives.

In the iBMD/CAN system the node number setting (Node Identification) is possible through DP3 (marked with “x1” and used to set the units) and DP2 (marked with “x10” and used for the tens). The factory default has all the switches on the 0 position. Through the dip switches it's possible to set a valid node number from 1 to 99 (in decimal format).

The communication speed (baud rate) in the CANopen network of the *iBMD* system can be set through [DP1](#). The maximum settable baud rate is, in general, function of the network length and of the peripherals number that are connected on the network. It is furthermore possible to configure this velocity via software (for further informations see [Access with MotionDrive from Tab Bus](#)).

To insert the termination resistance in the *iBMD*/CAN drives use the [DP4](#).

NOTE

Remember that the termination resistance has to be inserted on both the extremities of the CAN network and also that the value of the resistance, if measured, is about 60 Ω when the network is offline.

Chapter 8

Communicating with the drive

WARNING

Connect and disconnect the communication connectors only when the drive is switched off. Check if the pin Ground Control supply of [CN5](#), the drive, the master, the PC and all devices are correctly connected to the protective conductor.

8.1. Communicate with master CANopen

NOTE

The information in this paragraph are valid only for the drives version CAN. The details on the protocol implementation are described in [Chapter 9, Communication port CANopen](#).

Connect the cables of the network CANopen a [CN2](#) e [CN3](#). For further information see [Section 7.2, Electrical connections](#).




Figure 8.1. Communication scheme with CANopen Master.


Configure the communication port CANopen by setting the node number and the baud rate (communication speed). The node number and the baud rate are set by dip switch (Figure 7.10) or by writing the parameters **CANopenPortSetup**: the choice of the configuration to use is made by using the **CANopenPortSwitchSetup** parameter.

NOTE

Any modifications to the configuration of the CANopen port (dip switch, **CANopenPortSwitchSetup** and **CANopenPortSetup**) are applied only after a drive reset (see **Enabled parameters after reset**).

Access with MotionDrive from Tab Bus.


The node number and the Baud Rate of the drive can be assigned via software through the *Programmed value* fields as an alternative to the configuration through physical dip switches. To enable the configuration through *Programmed value* fields you have to check the *Use programmed value at start-up* box. In this way the dip switches will be ignored.



NOTE

Therefore the node number setting has to be done via dip switches or via software. If the node number that is set with the dip-switches is 0, and the box "Use programmed value at startup" is not checked, it will be used the last saved configuration in the permanent memory, related to the **CANopenPortSetup** parameters.

Configuration from dip switch



With the dip switches installed in the drive it is possible to configure:

- the node number, through DP2 and DP3, according to the formula:
Node number = DP3 + DP2 x 10;
- The baud rate, through DP1, as shown in the following table:

Switch 4	Switch 3	Switch 2	Switch 1	Baud rate [bit/s]
OFF	OFF	OFF	OFF	1000000
OFF	OFF	OFF	ON	500000
OFF	OFF	ON	OFF	250000
OFF	OFF	ON	ON	125000
OFF	ON	OFF	OFF	100000
OFF	ON	OFF	ON	50000
OFF	ON	ON	OFF	20000
OFF	ON	ON	ON	Reserved
ON	X	X	X	

Table 8.1. Selection of the baud rate of the port CANopen through DP1.

Termination resistance

If the drive is the last **Node** of the network CANopen it is necessary to insert the termination resistance through the dip switch DP4.

Switch 2	Switch 1	Termination resistance
OFF	OFF	Not inserted
OFF	ON	Configuration not allowed
ON	OFF	Configuration not allowed
ON	ON	Inserted


Table 8.2. Setting the termination resistance of the port CANopen through dip switch DP4.

NOTE

Remember that the termination resistance has to be inserted on both the extremities of the CAN network and also that the value of the resistance, if measured, is about 60 Ω when the network is offline.

To configure and map the PDOs, see [Section 9.5, Process data object \(PDO\)](#).

To monitor any errors at frame level and any errors generated by the services, read the group of parameters [CANopenCounters](#) (types of detected errors and error frame counters) or enter in the **Tab Bus** of MotionDrive.



To check the emergencies sent, see the parameters [CANopenEmcyRegister](#).

To check the status of the [NMT state machine](#), enable the [Error control services](#).

Status of the **LA** and **LB** leds

Interpretation of the leds status:

LA: status of the errors detected by the CANopen port; the coding is reported in [Table 8.3](#);

LB: status of the [NMT state machine](#); the encoding is taken to [Table 8.4](#).

Errors of the port CANopen	Description	LA
No error	The port CANopen is working correctly.	OFF
Warning limit reached	At least one of the error counters (TEC or REC, see CANopenStatusRegister) reached or overcame the warning level at 96.	1 FL
Error control event	The communication port has a Life Guard error.	2 FL
Sync error	Error in the SYNC controller.	3 FL
Bus-off	The communication port is in the Bus-off status.	ON

*Table 8.3. Encoding of the status of the led **LA** (ERROR).*

Status of the NMT state machine	LB
PRE-OPERATIONAL	BLK
STOPPED	1 FL
OPERATIONAL	ON

*Table 8.4. Encoding of the status of the led **LB** (RUN).*

8.2. Communicate with master EtherCAT

NOTE

The information in this paragraph are valid only for the drive version ETC. The details on the protocol implementation are described in [Chapter 10, Communication port EtherCAT](#).

Connect the cables of the EtherCAT network to **CN2 e CN3**: connect the output cable on the first connector and the input cable on the second one. For further information see [Section 7.2, Electrical connections](#).




Figure 8.2. Communication scheme with EtherCAT Master.

Configure the communication port EtherCAT, by defining the node number. The baud rate (communication speed), according to its technical feature, is set to 100Mbit/s. To define the node number, the master can choose one of the following modes:

- *Positional (Position Address)*: this method is generally used by the masters for the automatic detection of the drives in the EtherCAT network; the master gives to every node an address which is coherent with the physical position owned by the drive in the network;
- *Fixed (Node Address)*: For the fixed addressing it's necessary that the master writes in the "Configured Station Address" register (address 0x0010-0x0011 of the [ET1100](#) memory) the address with which it wants to identify, in univocal way, the drive. This address can be set before (according to an own algorithm in the master) or can be read from the "Configured Station Alias" register (address 0x0012-0x0013 of the [ET1100](#) memory).


The "Configured Station Alias" register has the following behaviour:

- it takes the value of the rotative dip-switches (DP1, DP2 e DP3) if their total value is different from 0
- it takes the value that's contained in the word address 0x0004 of the ESI eeprom if the rotative dip-switches total value is 0.

node number = DP3 + DP2 x 10 + DP1 x 100 (refer to [Figure 7.10](#) and to [Section 7.4, Dip switches](#)).


NOTE

Every time the dip-switches and/or the "Configured Station Alias" value is changed, it's necessary to reset the drive (or to execute a turn-off/turn on sequence, see [Enabled parameters after reset](#)).



Access with MotionDrive from Tab Bus.

In the *Bus address* field you can find the node number given to the drive while in the *Dip switches value* field you can find the node number calculated on the basis of the value of the dip switches.



Text in the page	(EtherCAT_Diagnostics parameter)
Configured Station (actual address)	EtcConfiguredStation
Configured Station alias	EtcConfiguredStationAlias
Application Layer status	EtcRegAlStatus
Application Layer status code	EtcRegAlStatusCode
ESI eeprom control	EtcRegEEpromConfiguration
Synchronization	SM2_SynchronizationType
Cycle time (ns)	SM2_CycleTime
Pdo Rx received	EtcPdoRxTotal
Pdo Rx lost	EtcPdoRxLostTotalReset

Text in the page	(EtherCAT_Diagnostics parameter)
Pdo Rx lost consecutively	EtcResetPdoRxLostMaxConsecReset
Pdo Rx lost (no reset)	EtcPdoRxLostTotal
Pdo Rx lost consecutively (no reset)	EtcPdoRxLostConsecutive
Input port	EtcRegDllStatus, port A
Output port	EtcRegDllStatus, port B

Table 8.5. Correspondence to the EtherCAT_Diagnostics parameters of the "Bus" page.

Status of the L/A 0, L/A 1, ERR and RUN leds

Interpretation of the leds status:

L/A 0 and **L/A 1**: link status and possible ongoing activity in the **CN2 e CN3** physical ports; L/A 0 takes the status of the accessible input port from the connector CN3, L/A 1 takes the status of the accessible output port from the connector CN2; the encoding of the two leds is taken to [Table 8.6](#);

ERR: error status found by the port EtherCAT; the encoding is taken to [Table 8.7](#);

RUN: status of the [EtherCAT state machine](#); the encoding is taken to [Table 8.8](#).

Link of the physical port	Activity of the physical port	L/A 0 and L/A 1
No connection	-	OFF
Connected	No message	ON
Connected	Communication enabled	FLK

Table 8.6. Encoding of the leds status L/A 0 and L/A 1.

Errors of the port EtherCAT	Description	ERR
No error	The port EtherCAT is working correctly.	OFF
Configuration not valid	Wrong settings of the communication port EtherCAT: the change of the state of the EtherCAT state machine requested by the master is not possible.	BLK
Change of status not requested	The drive has automatically changed the state of the EtherCAT state machine without any command by the master. This solution is generally chosen when there is an error in the synchronization.	1 FL
Sync Manager watchdog expired	The watchdog of the Sync manager (SM) of the PDO RX has expired.	2 FL
Hardware failure	Serious error in the ET1100; please contact Bonfiglioli Mechatronic Research S.p.a	ON

Table 8.7. Encoding of the leds status ERR.

Status of the EtherCAT state machine	RUN
INIT	OFF
PRE-OPERATIONAL	BLK
SAFE-OPERATIONAL	1 FL
OPERATIONAL	ON
BOOTSTRAP	FLK

Table 8.8. Encoding of the leds status RUN.

8.2.1. File access over EtherCAT (FoE) protocol

The FoE protocol is implemented in the drive, but its use is limited only to update the firmware.

8.3. Communicate with master Modbus RS232 (auxiliary communication port)

Connect the serial cable RS232 of the master to [CN1](#). For further information see [Section 7.2, Electrical connections](#).




Figure 8.3. Point-to-point communication scheme with master.

Set the features of the serial as follows:

- Character length: 8 bits
- Type of parity: even
- Number of stop bits: 1 bit.
- Default baud rate: 57600bit/s.

The drive answers on the auxiliary communication port with node-ID equal to 1. The other features of the port are configured with the parameters of the group [AuxiliaryPortSetup](#). The details on the protocol implementation are described in [Chapter 11, Auxiliary communication port Modbus](#).

NOTE

To analyse the latest communication error of the protocol Modbus, read the parameters of the group [AuxiliaryPortError](#).

8.4. Errors in reading / writing of the parameters

When there is an error in the reading or writing of the parameter, in order to understand which problem occurred it is necessary to get the error code:

- auxiliary communication port: you can find the error code of the last failed access in [AuxiliaryPortErrorCode](#);
- main communication port CANopen and EtherCAT: the error code is contained in the frame **SDO abort**.

SDO abort code	Auxiliary-PortErrorCode	Error	Description
0x0	0x00	No error	No error.
-	0x01	Modbus protocol error: illegal function	Code function Modbus not supported. In Table 11.1 you can see the accepted codes.
-	0x02	Modbus protocol error: address not existent	Address not existing: the combination of the Modbus address and the data to write/read is not valid; the addresses included in the requested range must be contained in the vocabulary of the parameters.
-	0x03	Modbus protocol error: data dimension too large	Quantity of data not admitted: too large or equal to 0.
-	0x10	Modbus protocol error: illegal upload/download code	Upload/download code not valid.
-	0x11	Modbus protocol error: unexpected upload/download state	Upload/download status unexpected.
-	0x12	Modbus protocol error initializing upload/download	Wrong initialization of the upload/download.
-	0x13	Modbus protocol error during upload/download	Error during data upload/download.
-	0x14	Modbus protocol error closing upload/download	Error during upload/download closing.
-	0x15	Modbus protocol error: memory overflow during upload/download	Memory overflow to complete upload/download.
0x05030000	0x16	Unexpected toggle bit	Toggle bit not alternated during upload/download.
0x05040001	-	Client / server command specifier not valid or unknown	Command specifier of the frame SDO not valid.
0x05040005	0x20	Memory not available	Memory overflow to run the requested operation.
0x06010000	0x21	Access denied	Access denied to the parameter.
0x06010001	0x22	Attempt to read a write only object	Reading failed, parameter only for writing.
0x06010002	0x23	Attempt to write a read only object	Writing failed, parameter only for reading.
0x06040043	0x24	General parameter incompatibility	General incompatibility of the datum.
0x06040047	0x25	General internal incompatibility	General internal incompatibility of the drive.
0x06060000	0x26	Hardware error	Access failed because of a hardware error.
0x06070010	-	Data type does not match	Datum dimension not correct.
0x06090011	0x27	SubIndex not existing	CANopen or EtherCAT sub-index not existing.
0x06090030	0x28	Parameter out of range	Parameter value out of range accepted.
0x08000000	0x29	Generic error	Generic error.
0x08000021	0x2A	Internal control refuse data	Access denied because of a local control.
0x08000022	0x2B	Internal state refuse data	Access denied because of the drive current status.
0x06020000	0x2C	Object does not exist	CANopen or EtherCAT index not existing.
0x06040041	0x2D	Object not mappable on PDO	Parameter not mappable in the PDOs.

SDO abort code	Auxiliary-PortErrorCode	Error	Description
0x06040042	0x2E	Length of object mapped exceed PDO length	The dimension of the mapped parameter in the PDOs is too large.

Table 8.9. Encoding the errors of reading/writing of the parameters.

8.5. CiA402 state machine

The drive of the iBMD series, follow the CiA-402 specification. For the drive management, the CiA-402 specification needs the implementation of a state machine, which scheme can be found in the following picture. The drives of the iBMD series follow the CiA-402 specifications.





Figure 8.4. CiA402 state machine implemented in the iBMD drives.

To enable or disable the drive and the motor motion, to stop and reset any error, it's necessary to ask for the right transitions to the CiA402 state machine so that it can reach the desired state. The Statusword parameter reports the CiA402 state machine status.

Access with MotionDrive:

Tab Main > Drive status



The CiA402 state machine status is partly also shown with the L1 and L2 leds, according to the following chart. The encoding of the errors can be found in [Section 24.2, Monitoring the errors on the status leds](#).

IMPORTANT

In the boot and firmware start up phases of the iBMD the below description of the leds is no more valid. Please refer to [Chapter 26, Software updating](#)

Status of the drive	Led L1 drive iBMD	Led L2 drive iBMD
Drive enable no error	GREEN ON	GREEN ON
Drive disable no error	GREEN ON	BLINKING GREEN
There are some errors of Warning type and not of Fault type	ORANGE VARIOUS STATUS (see Table 24.2)	
There are some errors of Fault type	RED VARIOUS STATUS (see Table 24.2)	

Table 8.10. Status of the CiA402 state machine visualized with the L1 and L2 leds.

In the following chart you can find all the possible states and their features. The bits shown with an 'x' are not important to determine the state.

Statusword	State	Description	Drive enable	Operation enable	PLC running	Communication active
xxxx xxxx x0xx 0000	Not Ready to Switch On	Initializing	-	-	-	-
xxxx xxxx x1xx 0000	Switch On Disabled	Disabled drive	-	-	YES	YES
xxxx xxxx x01x 0001	Ready to Switch On	Preparation to enabling	-	-	YES	YES
xxxx xxxx x01x 0011	Switched On	The drive can be enabled or disabled, depending on the SwitchedOnOptionCode parameter value.	See Description.	-	YES	YES
xxxx xxxx x01x 0111	Operation enable	Drive enabled and possibility to command the motor motion	YES	YES	YES	YES
xxxx xxxx x00x 0111	Quick Stop Active	Running a stop <i>Quick stop</i>	YES	-	YES	YES
xxxx xxxx x0xx 1111	Fault Reaction Active	Reaction to a Fault situation. The drive can be enabled or not, depending on the situation before the error occurred	See Description.	-	YES	YES

Statusword	State	Description	Drive enable	Operation enable	PLC running	Communication active
xxxx xxxx x0xx 1000	<i>Fault</i>	Fault state, finished reaction	-	-	YES	YES

Table 8.11. States of the CiA402 state machine.

In the following table you can find the description of the single bits of the **Statusword** parameter; some bits have a different meaning depending on the value of **ModesOfOperationDisplay**, indicated in the Mode column.

Bit	Mode	Name	Description
0	All	<i>Ready to switch on</i>	Encoding the state of the CiA402 state machine (see Table 8.11).
1		<i>Switched on</i>	
2		<i>Operation enabled</i>	
3		<i>Fault</i>	Bit which is set when a retentive Fault is detected (FaultRetentive)
4		<i>Voltage enabled</i>	Bit that indicates if the HV supply voltage is applied or not on the drive power section
5		<i>Quick stop</i>	Encoding the state of the CiA402 state machine (see Table 8.11).
6		<i>Switch on disabled</i>	
7		<i>Warning</i>	Bit which is set when a dynamic Warning is detected (WarnDynamic)
8			Reserved
9		<i>Remote</i>	Bit which is set when the Controlword is processable from the CiA402 state machine. If you write the parameter Controlword when this bit is equal to 0, the operation does not have any effect.
8,9,10		Reserved	
10	Others	<i>Target reached</i>	Bit which is set when the motor reaches the set-point (see Position reached target , Speed target reached or Torque target reached). In the homing mode it is set when the procedure ends. It's always reset on the homing operative mode entrance (writing 6 on the operative mode, when the ModesOfOperationDisplay has a different value) or when a new procedure is started.
11	All	<i>Internal limit active</i>	Bit that must be set when at least one position limit is reached, speed or torque (see Chapter 19, Motion limits).
12	1	<i>Set-point acknowledge</i>	Status of capture / processing of the position set-point (see Section 22.9, Profile Position Mode).
	3, -113 and -111	<i>Speed</i>	Bit which is set to Stopped motor .
	6	<i>Homing attained</i>	Bit which is set when the homing procedure is regularly completed (see Section 22.19, Homing Mode). It continues to indicate the last executed homing status, until a new procedure is started. For the drives with an absolute encoder installed, the homing status remains stored in the drive even if it is turned off and on again.
	7	<i>Ip mode active</i>	Status of the <i>Interpolated Position Mode</i> (see Section 22.10, Interpolated Position Mode).
	8	Target Position ignored	Bit which is set when the TargetPosition is used (see Section 22.11, Cyclic Synchronous Position Mode).
	9	Target Velocity ignored	Bit which is set when the TargetVelocity is used (see Section 22.12, Cyclic Synchronous Velocity Mode).
10	Target Torque ignored	Bit which is set when the TargetTorque is used (see Section 22.13, Cyclic Synchronous Torque Mode).	

Bit	Mode	Name	Description
	Others		Reserved
13	1, 8	<i>Following error</i>	Presence or absence of the Error of position tracking .
	6	<i>Homing error</i>	Bit which is set when an error is detected during the homing procedure (see Section 22.19, Homing Mode). It continues to indicate the last executed homing status, until a new procedure is started. For the drives with an absolute encoder installed, the homing status remains stored in the drive even if it is turned off and on again.
	Others		Reserved
14	All		Reserved
15	All		Reserved

Table 8.12. Meaning of the bits of the [Statusword](#).

To run some operations with the CiA402 state machine, it's necessary to write some commands in the [Controlword](#) parameter. The bits of the parameter [Controlword](#) are divided in the following way:

- *Bit 0 - 3 and 7* to command the [Transition](#) of the CiA402 state machine.
- *Bit 8* to manage the *Halt* command.
- *Bit 4 - 6* to ask for some specific commands that change depending on the value of [ModesOfOperationDisplay](#).
- *Bit 9 - 15* Reserved

In order to change the state of the CiA402 state machine, write in the parameter [Controlword](#) the commands in the following chart. The bits shown with a 'x' are not important to determine the command and the symbol \uparrow shows a transition from 0 to 1 of the related bit.

Command	Controlword	Transitions	Related link
Shutdown	xxxx xxxx 0xxx x110	2, 6, 8	Section 22.2, Disabling by using the master
Switch On	xxxx xxxx 0xxx 0111	configurable ^a	Section 22.1, Enabling by using the master
Switch On + Enable Operation	xxxx xxxx 0xxx 1111	3 + 4	
Disable Voltage	xxxx xxxx 0xxx xx0x	7, 9, 10, 12	Section 22.2, Disabling by using the master
Disable Operation	xxxx xxxx 0xxx 0111	5	
Enable Operation	xxxx xxxx 0xxx 1111	4, 16	Section 22.1, Enabling by using the master
Quick Stop	xxxx xxxx 0xxx x01x	7, 10	Section 22.2, Disabling by using the master
		11	Section 22.3, Carrying out a stop by using the master
Fault Reset	xxxx xxxx \uparrow xxx xxxx	15	Section 24.5, Resetting the errors

^aSee [SwitchedOnOptionCode](#).

Table 8.13. Commands for the state transitions of the CiA402 state machine.

NOTE
In the command Switch On + Enable Operation, the transition 4 is automatically run after the running of the transition 3.

In the following chart you can find the description of the single bits of the parameter **Controlword**; some of them have a different meaning depending on the value of **ModesOfOperationDisplay**: the column Mode shows the value that the parameter **ModesOfOperationDisplay** must have so that the bit shown has the specified meaning.

Bit	Mode	Name	Description
0	All	Switch on	Bit used to encode the commands of the state transitions of the CiA402 state machine (see Table 8.13).
1		Enable voltage	
2		Quick stop	
3		Enable operation	
4	1	New set-point	A rising edge of this bit enables the trajectory generator that controls the profile parameters, processes them and runs the positioning (see Section 22.9, Profile Position Mode).
	6	Homing operation start	Bit enabling the start/stop of the homing procedure (see Section 22.19, Homing Mode).
	7	Enable ip mode	Bit used for the enabling/disabling of the <i>Interpolated Position Mode</i> (see Section 22.10, Interpolated Position Mode).
	Oth-ers	Reserved	
5	1	Change set immediately	Selector of the positioning mode between Single set-point and Set of set-point, to be set with the transition of the bit <i>New set-point</i> (see Section 22.9, Profile Position Mode).
	Oth-ers	Reserved	
6	1	Absolute / Relative	Selector of the mode used to interpret the position target, to be set with the transition of the bit <i>New set-point</i> (see Section 22.9, Profile Position Mode).
	Oth-ers	Reserved	
7	All	Fault reset	Bit used to encode the commands of the state transitions of the CiA402 state machine (see Table 8.13).
8		Halt	Bit used to run a stop of the motor (<i>Halt</i> , see Section 22.3, Carrying out a stop by using the master).
9 - 15		Reserved	

Table 8.14. Meaning of the bits of the *Controlword*.

Please remember that a single writing of the **Controlword** cannot run either a transition or the start of a motion at the same time. In particular if the bits causing changes of the state (bit 0 - 3 and 7) are different from those written with the precedent access to the **Controlword**, the other bits (bit 4 - 6, 8 - 15) are not taken into consideration. Vice versa, if the bits causing changes of the state (bit 0 - 3 and 7) do not change, other bits are also taken into consideration, but only if the drive is in the **Operation enable** state.

IMPORTANT

During the access in writing to the **Controlword no bits changes are accepted during a state transition of the CiA402 state machine. This condition is reported by the Remote bit of the **Statusword** (see [Table 8.12](#)).**

8.6. System manager

To run some operations or commands different from those offered by the **CiA-402** it is necessary to use the System manager. To run a command you must respect the following rules:

1. write the code of the desired command of the parameter **SysMngCommand**;
 - if during the writing of the parameter **SysMngCommand** you get the error code **Attempt to write a read only object**, it means that the command cannot be run since you are already running another command
 - if during the writing of the parameter **SysMngCommand** you get the error code **Generic error**, it means that the command cannot be run; the reason of this is specified by the parameter **SysMngError**
 - if during the writing of the parameter **SysMngCommand** you get the error code **No error**, the command is accepted and immediately run
2. wait for the end of the command, that is when the parameter **SysMngCommand** is equal to 0
3. check if the command was correctly run by reading the possible cause of the error in the parameter **SysMngError**
4. when a command is running (parameter **SysMngCommand** different from 0), the drive cannot be taken to the **Operation enable** state
5. when an axis motion command is active it's not possible to write in the **ModesOfOperation** parameter, and the **ModesOfOperationDisplay** parameter assumes the value -127 (*Tuning Mode*).

System manager safety conditions

The following safety conditions are needed to run some commands:

1. disabled drive
2. setting the functionality **Generic Output (I/O X - Out X)** for the digital outputs and for the digital I/O (bidirectional peripheral) programmed as outputs
3. digital outputs and digital I/O (bidirectional peripheral) programmed as outputs, switched off
4. capture unit in stop

System manager command forcing

To ask the drive to go automatically in the **System manager safety conditions**, write the value 1 in the parameter **SysMngEnForcing** before writing the command. The safety conditions are forced *solo* only for those commands of the System manager requesting it.



You may force the commands only after having seen the **System manager safety conditions.**

SysMngCommand	Description
2200	Permanent memory: restore to default of all parameters (permanent)
2201	Reset to default of all parameters (temporary)
2250	Permanent memory: delete motor and sensor data
2300	Permanent memory: reload value of all parameters
5000	Hard firmware reset
5001	Soft firmware reset
5100	Request download firmware
6000	Downloading parameters file

SysMngCommand	Description
8000	Request download PLC program
8100	Request erase PLC program

Table 8.15. Commands of the System manager requesting the System manager safety conditions.

NOTE

The safety conditions can be set manually. In these cases it is not necessary to force the commands.

Reset of the Watchdog of the System manager

Some System manager commands need a cyclic writing in the [ResetWatchdogTimeout](#) parameter to inform the drive that the connection with the interlocutor that has been required by the command is still active and it's working. If the time between two writing operations is longer than 2 seconds, the current command is terminated and [SysMngError](#) assumes the value 1001. The commands which need the writing of [ResetWatchdogTimeout](#) are listed in the [Table 8.16](#). In the [ResetWatchdogTimeout](#) parameter it has to be written the value of [SysMngCommand](#) to reset the timeout.

SysMngCommand	Description
1001	Tuning: extended inertia estimator
1002	Tuning: inertia estimator
1003	Tuning: RL estimator
1010	Function Generator current D
1015	Function Generator current Q
1020	Function Generator velocity
1030	Function Generator position
1040	Function Generator profile velocity
1050	Function Generator profile position

Table 8.16. System manager commands that require the watchdog reset.

Chapter 9

Communication port CANopen

NOTE

About the communication settings with a CANopen Master, please refer to [Section 8.1, Communicate with master CANopen](#).

NOTE

All the information in this chapter are valid only for the drives of version CAN.

The communication port CANopen is the interface of the main bus for the drives, version CAN. The main bus must be connected to the connectors [CN2 e CN3](#). The implemented CANopen protocol meets the specifications of the [CAN in Automation](#) organization ([CiA-301](#) rev. 4.2.0 and [CiA-402](#) edit. 3.0).

NMT state machine

To check the messages flow of the communication port, the nodes CANopen are equipped with a state machine (*NMT state machine*).




Figure 9.1. State diagram of the NMT state machine.

The states of the NMT state machine have the following meaning:

- **INITIALIZATION:** drive initialization; at the end of these stage, the drive sends the message *Boot-up* to show its presence in the network;
- **PRE-OPERATIONAL:** drive and PDOs configuration; all the communication services are enabled, except from the PDOs;
- **OPERATIONAL:** all the services CANopen are enabled;
- **STOPPED:** the drive communication is effectively stopped; only the NMT services are working.

After the Power on, the drive runs the operations that are scheduled in the INITIALIZATION state and later it goes to the PRE-OPERATIONAL state, ready to carry out the master's requests. The led **LB** shows the state of the NMT state machine, according to what is reported in ID_TAB_CANopenLedRun.

In the drives of the series *iBMD*, the communication port CANopen manages the following objects:

- Network management objects (NMT)
- Emergency object (EMCY)
- Synchronization object (SYNC)
- Service data object (SDO)
- Process data object (PDO).

State	Value	Available services				
		NMT	SYNC	EMCY	SDO	PDO
INITIALIZATION	-	-	-	-	-	-
PRE-OPERATIONAL	127	YES	YES	YES	YES	-
OPERATIONAL	5	YES	YES	YES	YES	YES
STOPPED	4	YES	-	-	-	-

Table 9.1. Available services in the states of the NMT state machine.

In order to use the different services of the port CANopen it is necessary to command and check the **NMT state machine** state. To edit or check the state of the NMT state machine, use the NMT objects.

NOTE

The following paragraphs describe how the **CiA-301** services are implemented in the drives *iBMD*.

9.1. Network management objects (NMT)

Node control services

These services allow the state change of **NMT state machine**. The message sent out by the master contains the node number which the message is addressed to and the command that it must run (command specifier). In the following table you can find the commands and transitions allowed by the state machine (please refer to **Figure 9.1**):

Command	Command specifier	Description	Transitions
Start Remote Node	1	Take the drive to the OPERATIONAL state	(3), (6)
Stop Remote Node	2	Take the drive to the STOPPED state	(5), (8)
Enter Pre-Operational	128	Take the drive to the PRE-OPERATIONAL state	(4), (7)
Reset Node	129	Take the drive to the <i>Reset Application</i> substate in the INITIALIZATION state	(9), (10), (11)
Reset Communication	130	Take the drive to the <i>Reset Communication</i> substate in the INITIALIZATION state	(12), (13), (14)

Table 9.2. Node control services commands

Error control services

These services control the right working of the network and of the present nodes. The implemented protocol has two services:

1. Service node guarding event: the master sends a reading message to the drive in the **NMT state machine** state. This request is sent at regular intervals, with a **GuardTime** period. If the master does not receive any answer or the state does not coincide with the expected one, this means that there have been some problems in the drive or in the network. In this case the master is facing the error condition *Node guarding event*.
2. Service life guarding event: if this service is enabled, the drive must wait for the periodic reading of the **NMT state machine** state carried out by the master. The drive answers with the numerical code linked to its current state (see **Table 9.1**). If the drive does not receive any reading request for a longer time than the product between the **GuardTime** parameter and the **LifeTimeFactor** parameter, it enters in the condition *Life guard error* and it reports the **CAN communication error**.

To enable these services, please run the following procedure:

- write the value of the period of the message sending in **GuardTime**;
- write the **LifeTimeFactor** parameter with the tolerance factor (number of periods that the drive must wait for before reporting the error);
- send periodically the request of reading the state of the NMT state machine.

9.2. Emergency object (EMCY)

When some errors are found in the drive, an emergency message is immediately sent. The message contains all the useful information to identify the error type and it is made up by 8 bytes divided into four fields: *Emergency Error Code* (EEC, byte 0-1), *ErrorRegister* (byte 2), *Manufacturer Specific Error Code* (MSEC, byte 3) and Reserved (byte 4-7, not used). In the following table you can find the values of the EEC and MESC fields of the emergencies according to the error found:

EEC	MSEC	Description
0x0000	0x00	Reset error or no error.
0x2250	0x50	Power or motor short circuit.
0x2310	0x51	Power or motor over current.
0x2350	0x52	I2T limit reached.
0x3210	0x42	DC bus over voltage.
0x3220	0x43	DC bus under voltage.
0x4210	0x60	See (bit 1) of Thermal management .
	0x62	See (bit 2) of Thermal management .
0x4310	0x61	See (bit 0) of Thermal management .
0x5113	0x48	See (bit 1) of Logic voltage error .
0x5114	0x49	See (bit 0) of Logic voltage error .
0x5115	0x4A	See (bit 2) of Logic voltage error .
0x6320	0x91	At least one of the bits of Parameters serious error is active.
	0x92	At least one of the bits of Digital IO configuration error is active.
	0x93	See (bit 10) of Thermal management .
0x7200	0xA7	See (bit 6) of Thermal management .
	0xA8	See (bit 7) of Thermal management .
	0xA9	See (bit 8) of Thermal management .
0x8110	0x01	Overwritten message, please check the related overwriting notifications in the parameters CANopenEmcyService (Table 24.7) and CANopenEmcyProcess (Table 24.8).
0x8120	0x02	CAN in error passive state
0x8130	0x03	Life guard error
0x8140	0x04	Recovered from bus-off
0x8210	0x10	PDO RX 1 too short
	0x11	PDO RX 2 too short
	0x12	PDO RX 3 too short
	0x13	PDO RX 4 too short
0x8220	0x20	PDO RX 1 too long
	0x21	PDO RX 2 too long
	0x22	PDO RX 3 too long
	0x23	PDO RX 4 too long
0x8611	0x70	Position following error.
0x8700	0x05	Sync controller error.
0xFF00	0xA0	Real time mode error.
0xFF01	0xA6	User Fault.
0xFF04	0xAA	Vedere bit 0 di /STO Management Error .
0xFF05	0xAB	Last command requested failed.

EEC	MSEC	Description
0xFF06	0xB0	See (bit 4) of Internal Error .

Table 9.3. Codes for the field Emergency Error Code (EEC) and Manufacturer Specific Error Code (MSEC).

It is possible to enable or disable this service by operating on the [EMCY_CobID](#) parameter.

9.3. Synchronization object (SYNC)

SYNC is a periodic broadcast-type message that does not imply any answer. SYNC synchronizes all drives in the CANopen network by using the incoming PDOs and sending the outgoing PDOs, that are synchronized with the SYNC itself.

The SYNC message is sent to the node *producer* and it is addressed to all the other nodes, called *consumer*. Any network node can be service producer but this role is normally carried out by the master. The drives of the series *iBMD* can only be consumer nodes.

The service must be configured in the PRE-OPERATIONAL state before being used. In order to do this it is necessary to write the two parameters [SYNC_CobID](#) and [CommunicCyclePeriod](#).

Once the master has enabled the SYNC service, if the time interval between two consecutive SYNC messages is different from the time set by the [CommunicCyclePeriod](#) ($\pm 50\%$) parameter, the drive notifies [CAN communication error](#).

PDO transmission/sending/analysis sequence

The order with which the messages are transmitted/sent/analyzed is the following:

- the master sends the PDO(s) RX;
- the synchronism signal is activated. This signal is the SYNC message;
- the drive composes and sends the PDO TX.
- the drive analyzes and executes the operations that are required by the PDO RX.

NOTE

Example with CANopen drive:
if a command is sent to [Controlword](#) with the PDO RX, the drive analyzes it on the following SYNC and indicates its effect through the [Statusword](#) on the next SYNC only.

9.4. Service data object (SDO)

The SDOs are objects whose aim is exchanging data with confirmation and are used to access all the parameters of the vocabulary ([Chapter 27, Parameters vocabulary](#)). The size of their messages is set at 8 bytes: some are used as control bytes and others for sending data.

The drives of the series *iBMD* support two types of data transfer with this service:

- mode *expedited*: SDO is made up by a single request message and a single answer message, in which 4 bytes are used for the control (type of operation to be run, indexes and subindex). You can transfer up to 4 bytes of effective data;

- mode *normal*: the transfer is an initial negotiation between master and slave where you can find the size of the data to be transferred; the data are later sent through the transmission of 8-byte-messages containing one single control byte and 7 data bytes.

The SDO are appropriate to configure the drive and the PDOs (see [Section 9.5, Process data object \(PDO\)](#)), and in general for the low priority communication between the drive and the master.

9.5. Process data object (PDO)

The PDOs are used for the exchange of data in real time without any confirmation by the one receiving them; in this way the network is less overloaded.

The PDOs, like the SYNC, are based on the relation *producer - consumer*, in which the producer sends the PDO message and the consumer receives it. The outgoing PDO messages, sent by the producer node, are called PDO TX, while the incoming messages in the consumer node are called PDO RX. The drives of the series iBMD imply the possibility of managing up to 4 incoming PDOs (PDO RX) and 4 outgoing PDOs (PDO TX).

Any network node can send a PDO message linked to an ID (COB-ID). Any other network node, that finds a correspondence between the COB-ID of the PDO in the network and one of its PDOs RX, accepts the message and interprets it.

The PDOs must be configured and enabled in the PRE-OPERATIONAL state before being used. Their configuration implies the writing of two parameter groups:

- *Communication parameters*: parameters for the management of the transmission and the receiving of the PDOs (addresses CANopen from 0x1400 to 0x1403 for PDO RX and from 0x1600 to 0x1603 for PDO TX);
- *Mapping parameters*: parameters for the management of the mapping in the PDOs of the mappable parameters (addresses CANopen from 0x1800 to 0x1803 for PDO RX and from 0x1A00 to 0x1A03 for PDO TX).

NOTE

PDOs are enabled only in the OPERATIONAL state.

IMPORTANT

the inhibit time parameter (for example `PdoTx1_InhibitTime`) is used to inhibit the sending of the related TPDO for a time period equal to `inhibit value * 100us`. The period starts since when the last related TPDO has been sent, unless there is already one waiting to be transmitted. In this case the period has yet to begin to elapse. The sending inhibition even causes the event loss.

9.5.1. PDO Mapping

Every PDO can contain up to 8 bytes of informations. For that reason a single PDO can be mapped with up to 8 parameters of 1 byte each one, or with a number of parameters that have an overall dimension of at maximum 8 bytes.

The parameters that can be mapped are identified by the written "YES" in the "PDO" field of the table that describe them (see [Section 27.1, Agreements on the parameters description](#))

Both the incoming PDO RX interpretation and the outgoing PDO TX construction have to respect the order in which the parameters are mapped in the PDO, starting from the 1° till, at maximum, the 8°. So it's important to pay attention on the parameters insertion order during the PDO mapping operation.

In particular, to use the PDO RX to execute an axis movement, it's necessary to insert the moving parameters first (e.g. Velocity, target Position, ...) and at last, as last parameter mapped on PDO, the ControlWord to command the movement. (please refer to the [PdoRx3_MappingParameters](#) and [PdoRx4_MappingParameters](#) default PDO RX).

The full list of all the parameters for the PDOs configuration can be found in [Section 27.23, PDO managed by the port CANopen \(10000-11999\)](#).

NOTE

The procedures for the PDOs management are in compliant with the [CiA-301](#) specific.

Chapter 10

Communication port EtherCAT

NOTE

About the communication settings with a EtherCAT Master, please refer to [Section 8.2, Communicate with master EtherCAT](#).

NOTE

All information in this chapter are valid for the drives of version ETC.

The communication port EtherCAT is the interface of the main bus for the drives of version ETC. The main bus must be connected to the connectors [CN2 e CN3](#). The implemented protocol EtherCAT respects the specifications of the organization [EtherCAT Technology Group \(ETG\)](#). In the drives of the series *iBMD* the interface towards the network EtherCAT is constituted by the ASIC [ET1100](#). To communicate with the drive you can refer to the data sheet of the [ET1100](#).

EtherCAT state machine

To check the flow of the messages of the communication port, the nodes EtherCAT are equipped with a state machine.




Figure 10.1. Status diagram of the EtherCAT state machine.

The states of the EtherCAT state machine have the following meaning:

- INIT: initialization of the drive; no protocol and no service are enabled; to recognize and set the drive the master can have access only to the registers of the ET1100;
- PRE-OPERATIONAL: configuration of the drive and of the PDOs; all communication protocols are enabled but the PDO service is disabled;
- SAFE-OPERATIONAL: all communication protocols are enabled and the PDO service is enabled only during transmission (PDO TX);
- OPERATIONAL: all communication protocols are enabled and the PDO service is completely enabled;
- BOOTSTRAP: only the update of the drive firmware with the protocol [File access over EtherCAT](#) is enabled.

After the Power on the drive runs the operations scheduled in the INIT state and remains in such state waiting for the commands coming from the master. The led [RUN](#) shows the state of the EtherCAT state machine, according to what is reported in [Table 8.8](#).

State	Available services			
	CoE	FoE	PDO TX	PDO RX
INITIALIZATION	-	-	-	-
PRE-OPERATIONAL	YES	YES	-	-
SAFE-OPERATIONAL	YES	YES	YES	-
OPERATIONAL	YES	YES	YES	YES
BOOTSTRAP	-	YES	-	-

Table 10.1. Available services in the states of the EtherCAT state machine.

NOTE

In the data sheet of the [ET1100](#) you can find the available registers used to monitor the status of the communication in all its aspects.

Sync manager (SM)

The management of the messages of the communication port EtherCAT is carried out through the [Sync manager \(SM\)](#). In the following table you can find the features of the Sync managers that can be used in the drives of the series [iBMD](#).

SM	Communication mode	Starting address	Dimension (byte)	Available services
0	Mailbox RX	0x1000	128	CoE, FoE
1	Mailbox TX	0x1080	128	
2	Buffered RX	0x1100	64	PDO RX
3	Buffered TX	0x1180	64	PDO TX

*Table 10.2. Features of the managed **Sync manager (SM)**.*

The communication modes of the Sync managers show how the data are exchanged between the master and the drives:

- *Mailbox mode*: mechanism of handshake guaranteeing the complete reading of the message before sending next message; it is used for the communication protocols;
- *Buffered mode*: access to the buffers of the data in a substantial way in any moment; it is used for the PDOs.

The parameters of the Sync managers are described in [Section 27.24, Sync manager and PDOs managed by the port EtherCAT](#).

NOTE

The following paragraphs describe how the functionalities for the communication port EtherCAT have been implemented in the drives *iBMD*.

10.1. Protocol **CANopen over EtherCAT (CoE)**

The CoE implements in the drives EtherCAT the application layer of the protocol CANopen (see specifications of [CiA-301](#)).

The CoE provides the Service data object (SDO) to exchange data with confirmation. The SDOs are used to access all parameters of the vocabulary ([Chapter 27, Parameters vocabulary](#)). Their messages have the same dimension as the whole mailbox of the protocol CoE (see [Table 10.2](#)). The drives of the series *iBMD* support two types of data transfer with the SDOs:

- mode *expedited*: SDO is composed by one message of request and one message of answer; it is possible to transfer up to four bytes of data through this mode.
- mode *normal*: it is used for the transfer of data with a dimension bigger than four bytes.

The SDO are appropriate to configure the drive and the PDOs (see [Section 10.3, Process data object \(PDO\)](#)), and in general for the low priority communication between the drive and the master.

The CoE also provides the service *SDO information* to read the information on the parameters of the vocabulary: the whole list of all parameters, the list of the parameters mappable on PDO, information on the single parameters, etc.

10.2. Emergency Error Code

In the drive ETC the emergency management is not implemented. Through the [ErrorCode](#) parameter the code of the last error is reported. The code contains all the informations that

are useful to indentify the error type, and is composed by 8 bytes that are divided in three parts: *Emergency Error Code* (EEC, byte 0-1), [ErrorRegister](#) (byte 2) and Reserved (byte 3-7, not used). In the following table the values of the EEC part, according to the detected error, are reported:

EEC	Description
0x0000	Reset error or no error.
0x2250	Power or motor short circuit .
0x2310	Power or motor over current .
0x2350	I2T limit reached .
0x3210	DC bus over voltage .
0x3220	DC bus under voltage .
0x4210	Thermal management (one of the following): - Over temperature of logic section (bit 1) - Over temperature of motor (bit 2)
0x4310	See (bit 0) of Thermal management .
0x5114	See (bit 0) of Logic voltage error .
0x6320	At least one of the following situations has occurred: - At least one of the bits of Parameters serious error is active; - At least one of the bits of Digital IO configuration error is active.
0x7200	Thermal management (one of the following): - Power Temp Sensor hardware failure (bit 6); - Logic Temp Sensor hardware failure (bit 7); - Motor Temp Sensor hardware failure (bit 8).
0x8611	Position following error .
0x8700	Sync controller error
0xFF00	Real time mode error .
0xFF01	User Fault .
0xFF04	See (bit 0) of /STO Management Error .
0xFF05	Last command requested failed .

Table 10.3. Codes for the Emergency Error Code (EEC) part.

10.3. Process data object (PDO)

The PDOs are used for the exchange of data in real time without any confirmation by the one receiving them; in this way the network is less overloaded.

The PDOs are based on the relation *producer - consumer*, in which the producer sends the PDO message and the consumer receives it. In the network EtherCAT it is always the master who starts the communication and sends the PDOs; depending on the type of PDOs, the drives in the network can be producer and complete the outgoing PDOs, or consumer with the incoming PDOs. The iBMD drives offer the possibility to manage up to 4 outgoing PDOs (PDO TX) and 4 incoming PDOs (PDO RX). Every PDO must be assigned to a [Sync manager \(SM\)](#). The association of type of PDO and number of [Sync manager \(SM\)](#) is reported in [Table 10.2](#).

The PDOs must be configured and enabled in the PRE-OPERATIONAL state before being used. Their configuration implies the writing of two parameter groups:

- *Mapping parameters*: parameters used to manage the mapping in the PDOs of the mappable parameters (addresses CANopen from 0x1800 to 0x1803 for the PDO RX and from 0x1A00 to 0x1A03 for the PDO TX);
- *Sync manager PDO assignment parameters*: parameters to assign the PDOs to the [Sync manager \(SM\)](#) (addresses CANopen from 0x1C10 to 0x1C13).

NOTE

The PDOs TX are enabled in the SAFE-OPERATIONAL and OPERATIONAL states; the PDOs RX are enabled only in the OPERATIONAL state.

10.3.1. PDO Mapping

The PDOs allows the overall exchange of 64 bytes in reception (for the 4 PDO RX) and others 64 byte in transmission (for the 4 PDO TX). Each PDO can contain up to 8 parameters independently by their dimension. If, for example, 2 PDO TX are mapped with 8 parameter of 4 byte each, will be used all the 64 bytes that are available in the PDOTX reserved exchange area and, therefore, it's not possible to map other PDOs (naturally the same applies for PDO RX).

The parameters that can be mapped are identified by the written "YES" in the "PDO" field of the table that describe them (see [Section 27.1, Agreements on the parameters description](#))

Both the incoming PDO RX interpretation and the outgoing PDO TX construction have to respect the order in which the parameters are mapped in the PDO, starting from the 1° till the last one. So it's important to pay attention on the parameters insertion order during the PDO mapping operation.

In particular, to use the PDO RX to execute an axis movement, it's necessary to insert the moving parameters first (e.g. Velocity, target Position, ...) and at last, as last parameter mapped on PDO, the ControlWord to command the movement. (please refer to the [PdoRx3_MappingParameters](#) and [PdoRx4_MappingParameters](#) default PDO RX).

The whole list of all useful parameters to manage the PDOs is reported in [Section 27.24, Sync manager and PDOs managed by the port EtherCAT](#).

NOTE

The procedures to manage the PDOs are in compliance with the specifications shown by [EtherCAT Technology Group \(ETG\)](#).

10.3.2. Missing or corrupted PDO RX management

The EtherCAT field bus is not tolerant about the messages that are lost in the network and, on consequence, doesn't manage their automatic re-transmission (as instead happens in the CANopen field bus). That implies that if a PDO RX is corrupted or doesn't arrive in correspondence of the synchronization reference (see [Section 10.4, Synchronization](#)), the drive immediately generates an alarm and disables the motor. To avoid this inconvenience Bonfiglioli has implemented in the *iBMD* drive series a PDO RX monitoring and management system.

This system has been introduced to avoid that the drive goes in alarm state if the consecutive missing of a certain number of PDO RX is not considered serious (see [EtcPdoRxMiss-](#)

ingTolerance). Until the loss is lower or equal to this value the movement will proceed with the last valid received data. In the particular case of *Interpolated Position Mode* the drive cannot command to continue the motion because it needs to receive regularly the velocity and position targets (see [Section 22.10, Interpolated Position Mode](#)), then it will move the motor by reconstructing the profile coherently with the last received valid data (then referring to the last valid PDO RX), and so continuing the movement that it was making before the PDO RX loss.

This means that the more is high the number of tolerated consecutive and not valid PDO RX, the more long may be the movement that's defined by the previous parameters and not controlled by the master.

NOTE

The corrupted or missing PDO RX management is active only when the drive is in OPERATIONAL state (see [EtherCAT state machine](#)). Exceeded the corrupted or missing PDO tolerance (see [EtcPdoRxMissingTolerance](#)) the drive goes in synchronization error (see bit 3 of [Table 24.9](#)). The occurrence of this alarm condition implies the transition from the OPERATIONAL to the SAFE-OPERATIONAL state.

NOTE

If the PDOs RX arrive too close each other, the alarm is immediately generated independently of the set tolerance (see bit 3 of [Table 24.9](#)). For a complete diagnostic see the [EtherCAT_Diagnostics](#) parameter group.

10.4. Synchronization

In the drives ETC the synchronization of the PDOs is managed through the [Sync manager \(SM\)](#) by setting the related registers of the [ET1100](#). The related settings can be read in the parameters *Sync manager synchronization* (see [Section 27.24, Sync manager and PDOs managed by the port EtherCAT](#)).

In the drive of the *iBMD* series have been implemented three synchronization modes:

- [Free run](#);
- [Soft sync](#);
- [Hard sync](#).

Free run

The Free run mode does not have any mechanism of synchronization of the PDOs, they are managed at low priority.

Soft sync

The Soft sync mode synchronizes the outgoing PDOs TX with the incoming PDOs RX. This synchronization way is useful when the master does not support the synchronization of [Hard sync](#) and/or when there is no need for a correction because of the delays of the network EtherCAT (for example on networks of small dimension). To use this mode

it is necessary to set the Sync managers of the PDOs in order to get in the parameters [SM2_SynchronizationType](#) and [SM3_SynchronizationType](#) the values respectively 1 and 34 and it is necessary to set the T_{SYNC} through the parameter [CommunicCyclePeriod](#).

Hard sync

The Hard sync mode can be used only with the masters that manage the functionality [Distributed clocks](#). The distributed clocks is used to synchronize the drive more precisely by cancelling any errors generated by propagation times, offset and derive. With the synchronization way Hard sync it is possible to synchronize up to 65535 drives (highest limit allowed by a network EtherCAT). To use this mode it is necessary (for every drive):

- to run with the master the sequence of operations to calculate the corrections of the times for the distributed clocks and to apply them;
- to write the cycle time T_{SYNC} in the registers of the ET1100 for the cyclic generation of the [Sync Signal](#) signal;
- to set the registers of the Sync managers of the PDOs in order to get the value 2 in the parameters [SM2_SynchronizationType](#) and [SM3_SynchronizationType](#).

NOTE

For a correct setting of the synchronization it is advisable to use the settings as described in the file EtherCAT Slave Information (ESI) that can be downloaded in the DOWNLOAD AREA of the website <http://www.bonfiglioli.com>

PDO transmission/sending/analysis sequence

The order with which the messages are transmitted/sent/analyzed is the following:

- the master sends the PDO(s) RX;
- the synchronism signal is activated. This signal is the SyncSignal if the used synchronism is the [Hard sync](#) or the same PDO RX message if the used synchronism is the [Soft sync](#);
- the drive composes and sends the PDO TX.
- the drive analyzes and executes the operations that are required by the PDO RX.

Chapter 11

Auxiliary communication port Modbus

NOTE

For the communication settings with a Modbus Master, please refer to [Section 8.3, Communicate with master Modbus RS232 \(auxiliary communication port\)](#).

The drives of the *iBMD* series provide an auxiliary communication port on which the Modbus protocol is implemented. Through the [CN1](#) connector it's possible to connect to the port, which purpose is the configuration of the drive through MotionDrive. For further details please see [Section 8.3, Communicate with master Modbus RS232 \(auxiliary communication port\)](#).

NOTE

The Modbus protocol that's implemented in the drives respects the regulations of the [Modbus organization](#): in this section are only reported the implemented functionalities indications.
In the protocol only the transmission mode of RTU type has been implemented.

Modbus frame

The protocol Modbus uses a frame composed by many fields, in [Figure 11.1](#) you can find the scheme.




Figure 11.1. Modbus frame

The field *Function code* shows which operation the drive must run, once received and checked the whole frame, it checks it is not damaged. This information occupies 1 byte and has a range of valid values from 1 to 127; the codes between 128 and 255 are used for the **Exceptions** but the value 0 is not accepted. In [Table 11.1](#) you can find all the accepted codes.

Funct. Code	Name	Description
3	Read Holding Register	Reading one or more parameters (at 16/32 bits) starting from the Modbus address shown in the frame (such as <i>Read Input Register</i>).
4	Read Input Register	Reading one or more parameters (at 16/32 bits) starting from the Modbus address shown in the frame (such as <i>Read Holding Register</i>).
6	Write Single Register	Writing a parameter at 16 bits near the Modbus address shown in the frame. If the Modbus address refers to a parameter higher than 16 bits the operation is not run and the drive finds an exception.
7	Diagnostics	The diagnostics is only simulated and it has been implemented only to be compatible with the terminals requesting it.
16	Write Multiple Register	Writing one or more parameters (at 16/32 bits) starting from the Modbus address shown in the frame.

Table 11.1. Function Codes supported by the drives.

The function codes (3, 4, 6 and 16), described in the previous chart, give full access to all drive parameters through the vocabulary in [Chapter 27, Parameters vocabulary](#).

Exceptions

If the drive receives a message without communication errors, but it cannot run the requested operation or there is an error in the protocol, the drive answers to the request with an exception frame. In [Table 11.2](#) you can find the implemented exception codes.

Funct. Code	Name	Description
1	Illegal function	Function code not supported.
2	Illegal data address	Modbus address not accepted. More precisely, the combination of the Modbus address and of the number of data to write / read is not valid (all addresses included in the requested range must be in the vocabulary).
3	Illegal data value	Data quantity not accepted (too high or equal to 0).
4	Slave device failure	Error in the running of the requested action.

Table 11.2. Exception codes implemented in the drive.

NOTE

The details on the error condition can be found in the group of parameters [AuxiliaryPortError](#).

Chapter 12

Communicating with MotionDrive

12.1. MotionDrive via RS232 (auxiliary communication port)

Connect the PC serial port to [CN1](#). For further information see [Section 7.2, Electrical connections](#).





Figure 12.1. Point-point communication scheme with MotionDrive.

Start MotionDrive from: **Start menu > Programs > Bonfiglioli > MotionDrive**.
Set the connection parameters in the window *Drive connection*.



If the programme has already been started, run a new connection. Access:

Main menu > File > New connection ...

Toolbar > 


Connection parameters

1. *PC connection*: choosing the connection physical port (COM1, COM2...)
2. *Baud rate*: choosing the communication speed (the drive default value is 57600bit/s).
3. *PC time out*: if the drive does not answer during a longer time period than this value, the communication is interrupted and it is necessary to reconnect (the default value is 500 ms).
4. *Node id*: set the value 1.




ADVICE


In case of more connection interruptions it may be necessary to increase the PC time out. It is advisable not to increase the timeout more than 5 seconds.

12.2. Offline mode

Through the Offline mode it is possible to connect to a virtual drive through MotionDrive. To enable this mode, start MotionDrive or request a new connection by pressing .

In the window *Drive connection*:

1. Choose *OFFLINE* in the pull-down menu *PC connection*
2. Select the drive type by pressing  or a parameters file previously saved by pressing .
3. Start the Offline mode by pressing .



NOTE


The Offline mode is the best way to debug the system remotely by analysing the parameters file containing the problem.

How to choose the drive

Choose in the window *Select configuration file* the firmware Configuration file and the related version you are going to work with by exploring the stem-and-leaf diagram.

ADVICE

Always choose the latest available firmware version. After having selected the file, check that the drive data shown in the field below are the wanted ones.



What you cannot do in the Offline mode

In the Offline mode you can run all the operations foreseen by MotionDrive, except from:


- Tab Main
 - enabling the drive
 - downloading the firmware

- Tab Program
 - enabling/disabling the integrated PLC
 - downloading/deleting the integrated PLC programme
 - displaying the variables of the programme in the Watch
- Drive setup
 - enabling the capture peripherals
 - running the Tuning commands of the regulation loops
- Oscilloscope
 - enabling a data capture
 - running motions by the Function Generator
 - running Tuning commands of the regulation loops.

12.3. Communication errors with MotionDrive


New connection

If during the connection the following window appears check carefully the electrical connections, the correctness of the [Connection parameters](#) and if the drive is correctly supplied; then try again.




Configuration file not found

If the following window appears it is necessary to update the MotionDrive Configuration files according to what is reported in [Section 26.5, Updating the Configuration File](#).



Configuration file not update


If the following window appears it is advisable to update the MotionDrive Configuration files according to what is reported in [Section 26.5, Updating the Configuration File](#).



In case of urgency and if it is not possible to update the Configuration files, you can connect to the drive by using the Configuration file proposed only to expert users. By using not updated Configuration files, Bonfiglioli Mechatronic Research S.p.a does not guarantee the correct working of MotionDrive.


Generic errors

When you have communication errors, MotionDrive shows some specific messages. To understand the information in the error generic message see the following picture and the [Table 8.9](#).




12.4. Connection status with MotionDrive

The connection status is made up by the Configuration File and by the [ManufacturerDeviceName](#) which can be found in the last line below in the tab Main. For further information see [Section 26.5, Updating the Configuration File](#) and [Section 29.1, OrderCode](#).



12.5. Disconnection of MotionDrive

When the connection between MotionDrive and the drive is interrupted you will see the following window.



Retry try to connect again with the last [Connection parameters](#) used.

Offline go to mode [Offline](#).

Reconnect open a new connection.

Close close the programme.

12.6. MotionDrive options

The MotionDrive options refer to the program working mode, particularly with its messages transmission. Access:

Main menu > View > Options > General options.

The choices done by the user by interacting with the MotionDrive message service are saved in this page and can be modified in any moment.




Figure 12.2. Default configuration of MotionDrive options

- *Connect drive*: notice of obsolete firmware connection (only for some firmwares)
- *Large fonts and Screen*: notice at the start-up in case some screen graphical options are not compatible with MotionDrive
- *Download parameters*: error notice during the download of the parameters file (only for some firmwares)
- *Autotune*: confirmation for the motion which will be run at the requested tuning command
- *Function Generator start button*: confirmation of the motion you are going to run by the function generator
- *Compiler*: notice during saving of the internal PLC programme in the permanent memory when it is downloaded in the drive (only for some firmwares)
- *Program watch variables*: control of the congruence between the variables file and the programme in the internal PLC
- *Extended autotune*: confirmation for the motion which will be run by the requested tuning command
- *Decimal symbol for cvs exportation*: choice of the separating character to export the oscilloscope data to a file
- *Permanent memory*: notice of firmware reboot when the default parameters in the permanent memory are restored (only for some firmwares)
- *On save all parameters button*: saving confirmation in the permanent memory of the modifications to the parameters
- *Drive setup close window*: automatic saving of the modifications to the parameters in the permanent memory at the Drive setup closure.

Chapter 13

Units of measurement

13.1. Units of measurement of the parameters

In the drives of the series *iBMD*, the parameters are expressed with the units of measurement of the following table. The first column shows the symbol, the second the name in detail, the third a short description.

Unit	Name	Description
ns	nano second	Time unit of measurement
μs	micro second	
s	second	
h	hour	
inc	increment	Motor position unit of measurement. A complete revolution of the motor shaft for the rotary motors, or a movement equal to PolePitch for the linear motors, corresponds to the number of increments that is reported in the EncoderIncrements parameter
cnt	count	Unit of measurement of the position obtained by counting the number of edges of the encoder phases it is referring to
pulse	pulse	Quadrature encoder resolution unit of measurement [1pulse = 4count]
deg	degree	Position unit of measurement in sexagesimal degrees
inc/s	increment/second	Speed unit of measurement, calculated as incremental ratio expressed in increment

Unit	Name	Description
cnt/s	count/second	Speed unit of measurement, calculated as incremental ratio of a position expressed in count
rev/s	revolution/second	Speed unit of measurement, expressed in revolutions per second
rad/s	radian/second	Speed unit of measurement, expressed in radians per second
rpm	revolution/minute	Speed unit of measurement, expressed in revolutions per minute
mm/s	millimeters/second	Linear velocity unit of measurement, expressed in millimeters per second
inc/s ²	increment/second ²	Acceleration unit of measurement, calculated as incremental ratio of a speed expressed in inc/s
rev/s ²	revolution/second ²	Acceleration unit of measurement, calculated as incremental ratio of a speed expressed in rev/s
rad/s ²	radian/second ²	Acceleration unit of measurement, calculated as incremental ratio of a speed expressed in rad/s
%IS	%I Stall	Torque unit of measurement. The 100% corresponds to the motor stall torque, considering the torque constant equal to the TorqueConstant(ForceConstant) parameter value. The sign shows the torque application direction in accordance with the Polarity parameter (it does not show if the couple is supplied or absorbed by the motor)
V	Volt	Voltage unit of measurement
A	Ampere	Current unit of measurement, values RMS
mH	milli Henry	Inductance unit of measurement
Ω	Ohm	Unit of measurement of the electric resistance
g	gram	Mass unit of measurement
g cm ²	gram cm ²	Inertia moment unit of measurement
Jm	J motor	Inertia moment unit of measurement. 1Jm corresponds to the motor inertia moment
°C	degree Celsius	Temperature unit of measurement
bit/s	bit/second	Communication speed unit of measurement
-	-	Dimensionless unit



IMPORTANT


All the torque values are obtained from a current measure multiplied per [TorqueConstant\(ForceConstant\)](#). If the torque constant does not correspond to the value of the [TorqueConstant\(ForceConstant\)](#) parameter, the obtained torque value is not correct.

13.2. Revolution resolution

The revolution resolution shows the exact inc number for every revolution of the motor shaft. The revolution resolution defines the resolution describing the position, speed and accelerations, expressed respectively in inc, inc/s and inc/s². To modify the revolution resolution modify the parameter [EncoderIncrements](#). The modification of the parameter [EncoderIncrements](#) does not imply the change of the drive performance but only the meaning of the values in which the above-mentioned variables are expressed.

Access with MotionDrive:

Main menu > Drive > Drive setup ... > Motor and drive

Toolbar >  > Motor and drive

 WARNING

If the **EncoderIncrements** is changed it's necessary to execute a new homing procedure and set again the **SoftwarePositionLimit**.

13.3. Polarity

The polarity shows the direction of the motor shaft rotation in which the values increase. The signs of the speed, acceleration and torque values show if the related parameter is concordant or not with the polarity value. To modify the polarity, modify the parameter **Polarity**. Changing the parameter **Polarity**, the value of **PositionActualValue** does not change.

 WARNING

If the **Polarity** is of Reverse type, the roles of **Positive limit switch (FC +)** and **Negative limit switch (FC -)** are reversed: **Positive limit switch (FC +)** behaves like **Negative limit switch (FC -)** and **Negative limit switch (FC -)** behaves like **Positive limit switch (FC +)**. This is true both in the text of this manual and in the MotionDrive.


 ATTENTION

If the **Polarity** is changed it will be necessary to re-execute the homing procedure. By selecting the reverse mode, the limits are inverted, and **PositionActualValue** is consequently modified (see **Figure 15.1**).

Access with MotionDrive:

Main menu > Drive > Drive setup ... > Polarity

Toolbar >  > Polarity



13.4. MotionDrive units

It is possible to select the unit of measurement with which some quantities are displayed in MotionDrive. To do this go to the page Custom units.

Access:

Main menu > View > Options > Custom units.

Select to change program units:																	
Program units	Drive units	Custom units configuration															
Position unit: <input type="text" value="inc"/>	<input type="text" value="inc"/>	<table border="1"> <thead> <tr> <th>Name</th> <th>Conversion multiplier</th> <th>N. decimals</th> </tr> </thead> <tbody> <tr> <td><input type="text"/></td> <td><input type="text" value="1.000000"/></td> <td><input type="text" value="0"/></td> </tr> <tr> <td><input type="text"/></td> <td><input type="text" value="1.000000"/></td> <td><input type="text" value="0"/></td> </tr> <tr> <td><input type="text"/></td> <td><input type="text" value="1.000000"/></td> <td><input type="text" value="0"/></td> </tr> <tr> <td><input type="text"/></td> <td><input type="text" value="1.000000"/></td> <td><input type="text" value="0"/></td> </tr> </tbody> </table>	Name	Conversion multiplier	N. decimals	<input type="text"/>	<input type="text" value="1.000000"/>	<input type="text" value="0"/>	<input type="text"/>	<input type="text" value="1.000000"/>	<input type="text" value="0"/>	<input type="text"/>	<input type="text" value="1.000000"/>	<input type="text" value="0"/>	<input type="text"/>	<input type="text" value="1.000000"/>	<input type="text" value="0"/>
Name	Conversion multiplier	N. decimals															
<input type="text"/>	<input type="text" value="1.000000"/>	<input type="text" value="0"/>															
<input type="text"/>	<input type="text" value="1.000000"/>	<input type="text" value="0"/>															
<input type="text"/>	<input type="text" value="1.000000"/>	<input type="text" value="0"/>															
<input type="text"/>	<input type="text" value="1.000000"/>	<input type="text" value="0"/>															
Velocity unit: <input type="text" value="inc/s"/>	<input type="text"/>																
Acceleration unit: <input type="text" value="inc/s²"/>	<input type="text"/>																
Torque unit: <input type="text" value="%IS"/>	<input type="text" value="%IS"/>																

NOTE

The settings modified in the Custom units page are linked to the MotionDrive program and not to the single drive you are connected to.

To personalise the display of some MotionDrive variables, choose Custom in the Combo box of the Program units area and define the related fields in the box Custom units configuration. The Conversion multiplier value expresses the multiplicative factor converting the drive units in custom units.

If for example, you must match a value of 32mm to an exact revolution of the motor shaft, when the [EncoderIncrements](#) is equal to 8000inc/rev, the Conversion multiplier must be set at $32 / 8000 = 0.004$ mm/inc.

Select to change program units:								
Program units	Drive units	Custom units configuration						
Position unit: <input type="text" value="custom"/>	<input type="text" value="inc"/>	<table border="1"> <thead> <tr> <th>Name</th> <th>Conversion multiplier</th> <th>N. decimals</th> </tr> </thead> <tbody> <tr> <td><input type="text" value="mm"/></td> <td><input type="text" value="0.004000"/></td> <td><input type="text" value="3"/></td> </tr> </tbody> </table>	Name	Conversion multiplier	N. decimals	<input type="text" value="mm"/>	<input type="text" value="0.004000"/>	<input type="text" value="3"/>
Name	Conversion multiplier	N. decimals						
<input type="text" value="mm"/>	<input type="text" value="0.004000"/>	<input type="text" value="3"/>						


Example 13.1. Enabling the custom units for the position: 1inc = 0.004mm.

Chapter 14

Power configuration

14.1. *i*BMD series drives supply: Y topology

The power section of the *i*BMD series drives has been projected in order to be supplied through a continue voltage that can be easily obtained from the network voltage through the AC/DC power supplier named *i*BMD-DC. It is however possible to realize an installation with a different power supplier that respects the [Section 14.1.2, “Supply with a generic power supplier”](#) requirements.



*Figure 14.1. Connection scheme of the *i*BMD-DC to the network*

Make the connections of the network and of the grounding as required by the regulations in force: on the contrary subsists the electric shock danger.

The system voltage (phase-ground voltage) mustn't exceed 300VAC: in particular it may be necessary to insert an appropriate insulation transformer upstream of the drives in case of supply with not grounded networks or with networks that are grounded asymmetrically.

14.1.1. Supply with iBMD-DC

In order to supply the iBMD series drives it's better to use a power supplier of the iBMD-DC series: for further details see the dedicated user manual.

 **WARNING**

Make the connection of the power supplier only after the correct sizing of the electrical wiring and the related protections and after having read the user manual of the used devices.

The power supply is designed for a fixed connection on a three-phase electric network of TT and TN type. The rated current of short-circuit of the electric line must be < 5kA.

Be sure that the protection devices on the iBMD-DC input have an adequate interruption capacity.

To use this power supplier has the following advantages:

- the iBMD-DC has been designed to supply the iBMD series drives;
- the overcurrent protections are integrated;
- The DC bus voltage levelling characteristics are adequate to the iBMD series drives;
- Protections integration:
 - Overcharge on the DC bus outputs;
 - Braking circuit short-circuit;
 - Braking energy overcharge;
 - Charging energy overcharge;
 - Undervoltage / overvoltage / DC bus excessive ripple;
 - Power and control section overtemperature;

The iBMD-DC series suppliers are provided of 2 DC bus outputs; it's possible to maintain these outputs separated by making 2 branches or by connecting them in parallel: in this last configuration it's necessary to adequate the cables flow, downstream of the union of the cables to the maximum suppliable current of the supplier.

A simplified scheme for the iBMD connection to the DC bus generated by the iBMD-DC is reported in [Figure 14.2](#): this scheme represents the iBMD-DC output separated connection (HVDC CH1 and HVDC CH2); the DC bus cables can therefore be connected to a terminal box, represented by the "A" and "B" details in figure.

A wiring example of HVDC CH1 to the terminal box is reported in [Figure 14.3](#).

The cable that's identified by the orange colour allows to make in the same way the connection to the DC bus and to the control voltage for all the iBMD drives; furthermore this cable allows to connect to the iBMD drive 1 input channel for the STO inputs control and the IN9 input.




Figure 14.2. Scheme of the iBMD-DC connection to iBMD drives




Figure 14.3. Scheme of the iBMD-DC connection to iBMD - particular A

The duct drives supply network topology and the cables selection must be done according to the prescriptions contained in the *iBMD-DC* manual and by respecting the current regulations. In particular it's necessary the conformity to the IEC 60364-5-52 (Low-voltage electrical installations – Part 5-52: Selection and erection of electrical equipment – Wiring systems) and the IEC 60364-4-43 (Low-voltage electrical installations – Part 4-43: Protection for safety – Protection against overcurrent).

It's important that during the realization of the duct the maximum drives connection cables length is respected: for further informations see [Section 7.2.5, “Cables for iBMD”](#).

14.1.2. Supply with a generic power supplier

The drives can be supplied by a DC bus generated by a generic supplier, as indicated in [Figure 14.4](#): in this case it's necessary to make the complete sizing of the ducts and of the protections.



WARNING

Make the connection to the network only after the correct sizing of the electrical wiring and the related protections and after having read the user manual of the used devices.

The drive is designed to be used with a supplier connected to an electric network of three-phase or single-phase TT or TN type (depending on the performances required to the motor).

In particular, to supply the drives with a generic supplier, over the requirements of [Section 14.1.1, “Supply with iBMD-DC”](#), it's necessary to guarantee the conformity to the requirements reported in [Table 14.1](#).




Figure 14.4. Scheme of connection to a generic supplier to iBMD drives

Supplier electrical requirements

Supplier features	Symbol	Requirement
Output voltage range	Vdc	Minimum 275VDC; Maximum 730VDC ^a
Output voltage ripple	DVdc	The supplier must guarantee a levelling of the output voltage adequate to the performance requirements ^b .
Maximum output voltage while braking	Vdc _{max}	785VDC ^c
Soft start	-	It's necessary a soft start system through which the supplier limits the capacitors charging current at the turn on so that to avoid overcurrent and overvoltage peaks on the DC bus.
Output current	Idc	The supplier must provide a rated and peak currents adequate to the type and the absorption of each single drive ^d and to the coincidence factor
Protection from overcurrent and short-circuit of the output.	-	The supplier must be provided of internal protections, adequate to the installation, against the short-circuit and the overvoltage on the DC bus. Otherwise protect the cables of the DC bus with external devices (es. fuses) adequate to the load, to the installation electrical features and to the requirements of the current regulations.

^aThe supplier must be installed in a TT or TN system network. The system voltage must be equal or lower than 300 VAC. The output voltage of the DC bus must be adequate to the electrical features of the drives that are connected

in order to guarantee to reach the required performances of velocity and torque. Typically a decreasing of the DC bus voltage determines a proportional reduction of the motor rotation.

^bA decreasing of the DC bus voltage determines a proportional reduction of the motor rotation velocity.

^cThe maximum voltage must be adequate to the electrical features of the drives that are connected: in particular it's necessary to guarantee a margin to avoid the DC bus overvoltage Fault.

^dThe maximum absorption of each drive is related to the I2T parameter (for further information see [Section 14.6, I2T](#)).

Table 14.1. Supplier electrical requirements for compatibility with iBMD drives

14.2. Supply voltages

The drives of the iBMD series have two separated sections, control and power, that must be separately supplied with direct voltages (galvanic isolation). Check that the values of the voltage, that are reported in the [Chapter 5, Technical features](#), are respected.

While choosing the voltage of the DC bus (power section supply) you need to consider:

1. any possible voltage changes in order to avoid any unwanted notifications of Faults or Warnings
2. the drive cannot dissipate the energy of regeneration (see [Section 14.3, Regeneration](#))
3. the drop in the motor performances, decreasing the supply voltage

ADVICE

Supplying the power section with the rated voltage value.

When the supply voltage of the control section decreases below the lowest threshold, the drive is disabled. In the previous chart you can find the value of this threshold.

There is a threshold, on brake-equipped motors, causing the drive Fault when the supply voltage of the control section is not sufficient to ensure the safe brake release. In the previous chart you can find the value of this threshold.

NOTE

DC bus under voltage it can be of self-restoring type. Furthermore you can choose if enabling or not the Fault in case of **Logic voltage error**. For further details please see [Chapter 24, Fault and Warning](#).

14.3. Regeneration

The regeneration is a drive working phase in which the drive brings energy to the DC bus during the motor deceleration. If this energy is not absorbed or dissipated, the DC bus voltage can increase and cause the drive Fault. The drives iBMD are not enabled to dissipate this energy internally. In order to dissipate the regeneration energy, it is necessary to supply the DC bus with a bidirectional power supply or with brake resistances, which can limit the DC bus voltage and let the drive work normally also during the motor deceleration.

ADVICE

To evaluate the level of the drive regeneration, it is necessary to take into account the peak of kinetic energy generated by the motor during its deceleration and the total ener-

gy continuously generated. These data are fundamental in order to choose the DC power supply. It is advisable to read the manual and the power supply technical documents.

14.4. Drive currents


The drives of the series *iBMD* regulate the motor current depending on the torque requests and speed. The parameters related to the drive currents can be found in the following table:


Parameter	Description
MotorStallCurrent	Motor stall current
MotorPeakCurrent	Motor peak current
MaxRatedCurrent	Drive nominal current, power section
MaxPeakCurrent	Drive peak current, power section
UserPeakCurrent	Peak current set by the user to limit the current supply to the motor
NominalCurrent	Real nominal current: lower value between MotorStallCurrent and MaxRatedCurrent
PeakCurrent	Real peak current: lower value than MotorPeakCurrent , MaxPeakCurrent and UserPeakCurrent
ActualMotorCurrent	Actual motor current
ActualFieldCurrent	Actual motor current, field component
ActualTorqueCurrent	Actual motor current, torque component
OverCurrentAValue	Current of the motor A phase in condition of Power or motor over current
OverCurrentBValue	Current of the motor B phase in condition of Power or motor over current
OverCurrentCValue	Current of the motor C phase in condition of Power or motor over current
RMSMotorCurrent	Motor RMS current
RMSMotorCurrentFilter	Filtering time to get the motor RMS current

The only writable parameter of the previous chart (after [RMSMotorCurrentFilter](#)) is [UserPeakCurrent](#) and it is used to limit the current supplied to the motor (see [Section 19.1, Electricity limit](#)).

Access with MotionDrive:

Main menu > Drive > Drive setup ... > Motor and drive

Toolbar >  > Motor and drive




14.5. Power PWM

In the drives of the series *iBMD* it is possible to modify the sampling frequency of the three-phase bridge steering the motor currents and the loops sampling period. Increasing the sampling frequency of the three-phase bridge can increase the drive dynamic performances as

well as the losses in the power section and the power section heating. Vice versa, decreasing the sampling frequency of the three-phase bridge can damage the drive dynamic performances but decreases the power section heating. In order to modify these variables, use the parameters in the following table:

Parameter	Description
PwmMotionLoopCode	Unique code to set the three-phase bridge frequency and the loops period (it automatically sets the PwmBridgeFrequency, PwmModulationMethod and PwmMotionLoopDivider parameters values)
MotionLoopPeriod	Motion loop period
CurrentLoopPeriod	Current loop period



The current loop period can be obtained through the following expression:

$$\text{CurrentLoopPeriod [s]} = \frac{1}{\text{PwmBridgeFrequency} \times \text{PwmModulationMethod}}$$

while the motion period can be obtained with the following expression:

$$\text{MotionLoopPeriod [s]} = \text{CurrentLoopPeriod [s]} \times \text{PwmMotionLoopDivider}$$

ADVICE

Modify these parameters only if strictly needed. Do not go below 100µs with MotionLoop-Period. After the modification of these parameters it is necessary to tare the loops again.

14.6. I2T

For a limited time period, the current supplied to the motor can be more than *NominalCurrent* (**overload**). To protect the drive motor and power section during the overload periods, the drive controls the energy transferred to the motor and can limit the current. The parameter *I2TValue* shows the level of the energy transfer according to the following table:

I2TValue	Drive energy status.
0	The drive is not overloaded
>0 and <100	The drive is overloaded

I2TValue	Drive energy status.
>50	The drive is overloaded and too much exploited: application in case of working critical conditions
100	The drive has reached the highest level of overload and the current falls at the value NominalCurrent (only if the limitation does not cause any Fault)

The maximum energy that the drive can supply in overload condition can be found in the parameter **UserMaxI2T**. The value is limited by the parameter **DriveMaxI2T**.

The value **UserMaxI2T** is directly connected to the product between **UserPeakCurrent** and **I2TTime**. So for example it is possible to oversupply a motor with 20A for 1s or with 10A for 4s, by keeping limited the value of **UserMaxI2T**.


To set correctly the parameters of the I2T follow these instructions:

1. choose the value of **UserPeakCurrent** as current limit used to overload the motor and the drive (with MotionDrive, "Motor and drive" page of Drive Setup)
2. choose the value of **I2TTime** as maximum current overload time **PeakCurrent**
3. check that **UserMaxI2T** is lower than **DriveMaxI2T**; if it is not so decrease **UserPeakCurrent** and/or **I2TTime**
4. choose **I2TWarningThreshold** equal to the level of **I2TValue** in which you wish to be warned through the **I2T Warning threshold reached** Warning
5. consider if enable the Fault **I2T limit reached** when **I2TValue** reaches the 100% (with MotionDrive, Errors page of Drive Setup).

Access with MotionDrive:

Main menu > Drive > Drive setup ... > Limit and windows settings

Toolbar >  > Limit and windows settings



Active errors	Led L4 drive iBMD	I2TValue	ActualMotorCurrent
-	GREEN, 1 FLASH	0	0
	GREEN, ON		> 0 and ≤ NominalCurrent
	ORANGE, ON	> 0 and < I2TWarningThreshold	≤ PeakCurrent
I2T Warning threshold reached	ORANGE, BLINKING	≥ I2TWarningThreshold and < 100	
I2T limit reached	RED, ON	≥ 90	≤ NominalCurrent

Table 14.2. Status of the I2T.

⚠ ATTENTION

If the Fault for **I2T limit reached is active, the current is limited but the motor motion stops and the drive enters the Fault status.**

IMPORTANT

In the boot and firmware start-up phases of the iBMD drives, the above description of the led is no more valid. Please refer to **Chapter 26, Software updating**

Chapter 15

Configuring motor, sensors and brake

15.1. Motor parametrization

To parametrize the motor follow the order of the tabs that are presents in the *Drive Setup* window

Access with MotionDrive:

Main menu > Drive > Drive setup ...

Toolbar > 

Motor and drive		Brake	Polarity	Digital I/O	Analog input	Captures	Lim
Motor:	iBMD 82.2.7.3000.560 - M1C F24						
Model:	--						
Manufacturer:	Bonfiglioli						
Motor parameters:							
Motor motion type:	Rotary						
Poles:	8 poles						
Stall current:	1.84 A						
Peak current:	7.50 A						
Inertia:	1580 g cm ²						
Inductance:	79.00 mH						
Resistance:	14.50 ohm						
Torque constant:	1.470 Nm/A						
Cogging torque:	0.000 Nm						
Rated speed:	3000 RPM						
Fault temperature:	140 °C						
Temperature sensor type:	KTY84						
Brake							
Release time:	35 ms			Close time:	7 ms		

NOTE

In the iBMD drives the motor is already selected and cannot be modified.

The parametrization consists of the following operations:

1. if necessary, define the parameters in the *Motor and drive* page;
2. continue with the parameterisation of the drive functionalities in the other pages;
3. execute the loop tuning (see [Chapter 20, System tuning](#));
4. Save the parameters in the internal memory or in a parameters file (see [Chapter 21, Saving, restoring or cloning the drive configuration.](#)).

15.2. Sensor of the feedback position

NOTE


In the iBMD drives the feedback sensor is already selected and cannot be changed.

The code that selects the installed feedback sensor type is in the `FeedbackSensorCode` parameter. The order codes of the available feedback sensors are listed in the [Table 29.1](#). The feedback sensor type is reported in the *Motor and Drive* tab of the *Drive Setup*.

Access with MotionDrive:

Main menu > Drive > Drive setup ... > Motor and drive

Toolbar >  > Motor and drive



Phasing types

Four types of phasing are defined:

- *Phasing type 0 (phased)*: of this category are part the sensors that are installed on the motor with a mechanical phasing that's defined and recognized by the drive. For these sensors it's not necessary to execute the phasing;
- *Phasing type 1 (pre-phased)*: of this category are part the sensors that are installed on the motor with a mechanical phasing that's defined but not recognized by the drive. For these sensors it's necessary to execute the phasing at least one time; The phasing informations can be exported to other drives through the parameters file without having to repeat the phasing procedure, but it has to be installed the same sensor type and phasing type must be the same. The correct phasing must be guaranteed and verified during the feedback sensor mechanical installation;
- *Phasing type 2 (not pre-phased)*: of this category are part the sensors that are installed on the motor without a defined mechanical phasing. For these sensors it's necessary to execute the phasing on each single motor at least one time. Once the phasing has been executed the phasing informations can be saved in the drive, without having to repeat it at every startup;
- *Phasing type 3 (not savable)*: of this category are part the sensors that are installed on the motor without a defined mechanical phasing and that don't provide any absolute information about the shaft position related to the motor revolution. For these sensors it's necessary to execute the phasing on each single motor at every drive startup.

NOTE

In the motors that mount Hiperface sensors the phasing is saved directly by the encoder, so, once it has been executed, it is no more necessary to repeat it even if that motor is connected to another drive of the same series.

15.3. Feedback sensor phasing check.

To check the feedback sensor phasing, even in case of sensor anomalies, follow the instructions contained in the *Test feedback sensor phasing* field.

Access with MotionDrive:

Main menu > Drive > Drive setup ... > Phasing

Toolbar >  > Phasing

- through the [FeedbackSensorPhasingAngleTest](#) parameter the angle position on which the test will be executed is specified;
- through the button the test starts (to execute the test through [System Manager](#) use the command 5310);
- through the field on step 4 (that returns the value contained in the [FeedbackSensorPhasingAngleError](#) parameter) the phasing angle error is read. If the value of this parameter exceeds a drive internally defined threshold, it is signaled the error 5301 of the [SysMngError](#).

ADVICE

Repeat the operation by trying different values of [FeedbackSensorPhasingAngleTest](#).

Check the phasing through [System Manager](#)

In order to manage the phasing test from controller through the [System Manager](#) commands, it is sufficient to perform the following procedure:

- Start: write the value of [FeedbackSensorPhasingAngleTest](#) first and then execute the command 5310 of the [SysMngCommand](#) (Test phasing of feedback position sensor)
- Save: execute the command 5320 of the [SysMngCommand](#) (Save phasing of feedback position sensor)
- Disable: as every operative mode according to the [CiA-402](#) specifications

ADVICE

Repeat the operation by trying different values of [FeedbackSensorPhasingAngleTest](#).

15.4. Absolute feedback position sensor

IMPORTANT

if a MULTITURN absolute encoder is set, the [FeedbackSensorAbsMode](#) parameter is set to 1 by default, consequently the drive will effectively manage it as an absolute sensor. Otherwise if a SINGLETURN absolute encoder is set, the [FeedbackSensorAbsMode](#) parameter is set to 0 by default, consequently the drive will manage it as an incremental sensor. To use the sensor as absolute, set to 1 the [FeedbackSensorAbsMode](#) parameter.

The provided absolute encoders are listed in the following table.

Description	Functioning range	Accuracy ^a	Precision (repeatability) ^b
Absolute encoder Hiperface multiturn SKM36 128sin/rev.	4096rev	1/10000 rev	1/40000 rev
Absolute encoder Hiperface singleturn SKS36 128sin/rev.	1rev	1/10000 rev	1/40000 rev
Absolute encoder Hiperface multiturn SEL37 16sin/rev.	4096rev	1/4000 rev	1/10000 rev

Description	Functioning range	Accuracy ^a	Precision (repeatability) ^b
Absolute encoder Hiperface singleturn SEK37 16sin/rev.	1rev	1/4000 rev	1/10000 rev

^a"Accuracy" is the proximity of measurement results to the true value.

^b"Precision" is the repeatability or reproducibility of the measurement in the same conditions.

Table 15.1. Supported absoluted feedback sensors

To align the absolute sensor position with a specific mechanical position it's necessary to execute a homing procedure (see [Section 22.19, Homing Mode](#)).

The absolute position sensors keep the position value even if the drive is turned off. The maintenance of the position at the turn on of the drive is guaranteed only within the operating range of the sensor.

⚠ WARNING

If the sensor works as an incremental encoder (parameter [FeedbackSensorAbsMode](#) equal to 0), after the [EncoderIncrements](#) and/or [Polarity](#) modification, it will be necessary to re-execute the homing procedure.

Functioning of the absolute sensor: [EncoderIncrements](#), [Polarity](#) and homing

In the [Figure 15.1](#) is shown an example of how the homing procedure (with [HomingAbsRangeMode](#) parameter equal to 0) and the [Polarity](#) act on the feedback absolute sensor position (the [FeedbackSensorAbsMode](#) parameter must be equal to 1 in order to work in this way). In the example an offset is set between the sensor physical position and the one that's read by the drive.

- On the top the machine physical range is represented (red reference) compared with the position sensor range (blue triangle)
- In the first image the read position coincides with the sensor physical position. In this condition the machine physical range is not completely included in the sensor range, therefore the absolute position is not guaranteed
- In the second image it's shown how the sensor range is shifted after the homing procedure, of 350000[inc] in the specific case (this offset is saved in the drive permanent memory and it will no longer be necessary to execute the homing procedure). Through this operation the machine physical range is completely included in the sensor range, therefore the absolute position is always guaranteed.
- In the third image it's shown how the Reverse function (see [Polarity](#)) reverses the position reference between the 0 and the sensor range maximum allowed value

⚠ ATTENTION

If during the functioning the motor exceeds, in positive or negative direction, the sensor working range, the drive is able to correctly reconstruct the position, but if the drive is turned off while the position read by the sensor is out of its working range, the position that has been read on the turn on of the drive will not be consistent with the executed homing and it will be necessary to re-execute the homing procedure.




Figure 15.1. Functioning range of absolute sensors, position preset and reverse.

15.5. Auxiliary position sensor

The drive can acquire an external physical encoder that can be used for example to control the position of another axis or in relation to the motion function. The incremental encoder is the only managed auxiliary position sensor type.

The drive internally provides even a virtual (simulated) encoder that generates a position that varies with a constant velocity that can be configured by the user.

If you want to use a physical encoder, this must be connected as follows (for further information about wiring please see [Chapter 7, Electrical connections, leds and dip switches](#)):

Encoder signal	iBMD HW input	Notes
Quadrature Input ChA (Ch A)	I/O 0 (connector CN4)	Compulsory
Quadrature Input ChB (Ch B)	I/O 1 (connector CN4)	Compulsory
Quadrature Input Index (Idx)	I/O 2 (connector CN4)	Optional

To acquire the physical auxiliary position sensor, the digital input must be configured as described in [Chapter 16, Digital inputs and outputs](#).

Here follows the list of the parameters that are provided to manage the master encoder functionalities:

Physical master encoder:

- [RealEncoderPosition](#)
- [RealEncoderVelocity](#)
- [RealEncoderPolarity](#)

Virtual master encoder:

- [VirtualEncoderPosition](#)
- [VirtualEncoderVelocity](#)
- [VirtualEncoderRunStop](#)

Selected master encoder:

- [AuxiliaryEncoderPosition](#)
- [AuxiliaryEncoderSpeed](#)
- [AuxiliaryEncoderSelector](#)

NOTE

If a physical master encoder is used and [RealEncoderPolarity](#) value is 0 (it's set on forward), [RealEncoderPosition](#) increments when [Quadrature Input ChA \(Ch A\)](#) anticipates [Quadrature Input ChB \(Ch B\)](#).

15.6. Brake

The brake installed in the *iBMD* drives is a holding brake. When the brake is configured, it's automatically managed by the drive, contemporary to the enable/disable operation. The brake parameters are in *Drive setup*.

Brake electrical features	
Rated voltage	24Vdc
Current absorbed by the control section	1.5A with control voltage = 24Vdc 0.85A with control voltage = 48Vdc
Internal fuse	2A-T not replaceable
Protections	Protection from short-circuit


Table 15.2. Brake features


NOTE

In the *iBMD* drives the brake is already configured therefore no parametrization is needed.

Access with MotionDrive:

Main menu > Drive > Drive setup ... > Motor and drive


Toolbar >  > Motor and drive




The parameter [BrakeReleaseTime](#) shows the time elapsed between the command to delay (disabling) the brake, occurring together with the motor enabling, and the moment when the drive accepts any motion commands. During this time interval the brake is exercising its braking power and the shaft motion could damage the brake.

The [BrakeCloseTime](#) parameter shows the time between the brake blocking command (activation), that happens after the motor disabling command, and the moment in which the drive cuts off the current to the drive. During this time, the brake is not exercising its brake power; if during this time the motor runs out of power the position could not be guaranteed.

See the timing in the following figure.



The brake can be manually commanded only when the motor is disabled. If the motor is enabled, it's not possible to activate the brake. The command can be reached through the [BrakeStatus](#) parameter or through the dedicated button that's present in the *Main* Tab of MotionDrive.



NOTE

The brake is active when it is not powered, so when it produces braking force (red led is on).

Chapter 16

Digital inputs and outputs

16.1. Digital inputs and outputs of the *i*BMD drives

In the *i*BMD drives are provided the following optoisolated digital inputs and outputs:

On the **CN4** connector (M23 male 19 poles) there are:

- 5 PNP digital inputs (24Vdc)
- 3 PNP digital outputs (24Vdc; max 300mA)
- 1 PNP bidirectional digital [with configurable direction]

On the supply connector **CN5** (M23 male 8 poles) there is:

- 1 PNP digital input (24Vdc)

It's therefore possible to have up to 7 inputs¹ and up to 4 PNP digital outputs² 24Vdc.

On the **CN4** connector there are also:

- 3 differential digital IN/OUT (type +5V/Line driver), isolated from the power section, [usable for example as master encoder input or step-dir input].

¹In this case the PNP digital outputs number is 3.

²In this case the PNP digital inputs number is 6.

Provided digital I/O for iBMD drive

Name	Type of resource / logic	Details	Default
I/O 0	Bidirectional, differential, Line Driver	Configurable functionality, connections: pin 13 (I/O+) and pin 12 (I/O-) of CN4	GPIN
I/O 1	Bidirectional, differential, Line Driver	Configurable functionality, connections: pin 14 (I/O+) and pin 1 (I/O-) of CN4	GPIN
I/O 2	Bidirectional, differential, Line Driver	Configurable functionality, connections: pin 5 (I/O+) and pin 2 (I/O-) of CN4	GPIN
I/O 3	Bidirectional, PNP, 24V	Configurable functionality, connection: pin 10 of CN4	GPIN
In 4	Input, PNP, 24V	Configurable functionality, connection: pin 15 of CN4	GPIN
In 5	Input, PNP, 24V	Configurable functionality, connection: pin 19 of CN4	GPIN
In 6	Input, PNP, 24V	Configurable functionality, connection: pin 18 of CN4	GPIN
In 7	Input, PNP, 24V	Configurable functionality, connection: pin 17 of CN4	GPIN
In 8	Input, PNP, 24V	Configurable functionality, connection: pin 8 of CN4	GPIN
In 9	Input, PNP, 24V	Configurable functionality, connection: pin C of CN5	GPIN
Out 4	Output, PNP, 24V	Configurable functionality, connection: pin 16 of CN4	GPOUT
Out 5	Output, PNP, 24V	Configurable functionality, connection: pin 9 of CN4	GPOUT
Out 6	Output, PNP, 24V	Configurable functionality, connection: pin 17 of CN4	GPOUT
/STO	Input, PNP, 24V	Not configurable. Connection: pin A of CN5	/STO

Table 16.1. Description of the iBMD drive digital I/O

Description of the terms used in the previous chart

Bidirectional: The resource cannot be configured to work as an input or output.

Input: The resource works as input but not as output.

Output: The resource works as output but not as input.

Differential: The status of the resource is linked to the difference of potential between two pins ([Section 7.2.4, iBMD drive connectors](#)).

PNP: The status of the resource is linked to the current voltage value as to the common mass ([Section 7.2.4, iBMD drive connectors](#)).

Configurable functionality: The resource can be configured to work as "Generic Input" (GPIN) or "Generic Output" (GPOUT), so the status of the resource can be read or written by the user through the [DigitalInputs](#) and [PhysicalOutputs](#) parameters, or it can be configured to run some special functions (see [Section 16.4, Functionalities](#)), so its status is directly managed by the drive.

/STO : See [Chapter 6, STO safety function: Safe Torque Off](#) .

Inputs ([Table 16.2](#)), differential IN/OUTs ([Table 16.3](#)) and outputs ([Table 16.5](#)) electrical characteristics.

24V PNP DIGITAL INPUTS CHARACTERISTICS	
Inputs maximum n°	7
Galvanic isolation	YES, through optoisolators
In/Out3, In4, In5, In6, In7, In8, In9	

24V PNP DIGITAL INPUTS CHARACTERISTICS	
Input type	PNP
Input voltage	<ul style="list-style-type: none"> Nominal : +24Vdc LOW signal (physical status 0) : -30 ÷ +3Vdc HIGH signal (physical status 1) : +15 ÷ +30Vdc
Input current (typical) with Vin = 24Vdc	<ul style="list-style-type: none"> 3,3 mA (IN8 and IN9 excluded) 7 mA (IN8 and IN9)
Maximum allowed current on IN5 if configured as SGND	2A
HW propagation delay (IN8 and IN9 capture inputs) ^a	<ul style="list-style-type: none"> Typical : rising edge=6,8µs , falling edge=1µs Minimum : rising edge=3,6µs , falling edge=1µs Maximum: rising edge=12µs , falling edge=1µs
Jitter on the SW acquiring of IN8 and IN9 capture inputs	max 1µs
HW propagation delay (generic input)	Typical : rising edge=15µs , falling edge=170µs

^a24V amplitude step signal

Table 16.2. Digital inputs electrical characteristics

DIGITAL IN/OUT CHARACTERISTICS (differential line drive type)	
Type	Differential IN-OUT (line driver/line receiver)
Galvanic isolation	YES, towards the power section
Maximum outputs n.	3
Maximum inputs n.	3
In/Out0, In/Out1, In/Out2	
<i>OUTPUT characteristics^a</i>	
Differential output voltage	min: 2V; max: 3,3V (with a 50Ω load)
<i>INPUT characteristics^b</i>	
Differential input voltage	max: -5V ÷ +5V (with enabled termination)
Common-mode voltage	-7V ÷ +12V
Typical input resistance	125kΩ (when the termination resistance is disabled)
Typical input current	110µA
Differential threshold voltage V _{thd} (input)	0,2V
Integrated termination resistance ^c	typ: 120Ω
Input maximum frequency (duty cycle: 40%÷60%)	300KHz

^aIf they are configured as outputs.

^bIf they are configured as inputs.

^cCan be activated by software command.

Table 16.3. Digital IN/OUT electrical characteristics

NOTICE

The In/Out0, In/Out1, In/Out2 inputs are differential and must NOT be connected with "24V" level signals. Please see the applicative diagrams of the CN4 connector. It's recommended to respect the maximum differential voltage and to report this voltage to the "GND_5V" ground [pin 6 of CN4].

NOTE

When the voltage that's applied to the differential input is greater than the differential threshold voltage V_{thd} (see Table 16.3), then the related physical status in the iBMD is 1. When instead the voltage that's applied to the differential input is minor than -V_{thd}, then the related physical status in the iBMD is 0. For values included in the ±V_{thd} range the physical status of the input is not guaranteed.

/STO INPUT FEATURES	
/STO input	See /STO input electric features .

Table 16.4. /STO input electric features

DIGITAL OUTPUTS CHARACTERISTICS	
In/Out3 ^a , Out4, Out5, Out6	
Output type	PNP
Output maximum n°	4
Galvanic isolation	YES, through optoisolators
Supply voltage	24V (internally obtained from the 24V that are presents on CN5)
Maximum output current (for each output) ^b	300mA
Voltage with OFF output	<1V

^aIf configured as output.

^bThat limit is true even if the output is configured as S24V (simulated 24V)

Table 16.5. Digital outputs electrical characteristics

NOTE

The maximum output current declared on [Table 16.5](#) is referred to each output, therefore it's possible to have a maximum overall absorption of about 24V (with all 4 outputs enabled and with the maximum connected load) equal to 1200mA. Inside the system a protection useful in case of the overcoming of this absorption limit is implemented. This protection disable all the outputs (even if the greater part of the absorption is due to only one of these). Therefore pay particular attention because the overcurrent on a single output may cause a Fault that causes the switch off of the others outputs too.

16.1.1. I/O functionality for iBMD drive

Here follows the functionalities given to the resources of I/O of the drive iBMD. Some functionalities can be given to more I/O at the same time, others can be given to only one resource per time.

Functionalities	Given to...
Generic Input (I/O X - In X)	I/O 0, I/O 1, I/O 2, I/O 3, In 4, In 5, In 6, In 7, In 8, In 9
Generic Output (I/O X - Out X)	I/O 0, I/O 1, I/O 2, I/O 3, Out 4, Out 5, Out6
Fault (Fault)	I/O 0, I/O 1, I/O 2, I/O 3, Out 4, Out 5, Out6
Home	I/O 0, I/O 1, I/O 2, I/O 3, In 4, In 5, In 6, In 7, In 8, In 9
Step	I/O 0
Dir	I/O 1
Positive limit switch (FC +)	I/O 0, I/O 1, I/O 2, I/O 3, In 4, In 5, In 6, In 7, In 8, In 9
Negative limit switch (FC -)	I/O 0, I/O 1, I/O 2, I/O 3, In 4, In 5, In 6, In 7, In 8, In 9
Enable	I/O 3, In 4, In 5, In 6, In 7, In 8, In 9
Quadrature Input ChA (Ch A)	I/O 0
Quadrature Input ChB (Ch B)	I/O 1
Quadrature Input Index (Idx)	I/O 2
Pwm out (Pwm O)	I/O 0, I/O 1, I/O 2
Motor Fan (M. Fan)	I/O 0, I/O 1, I/O 2, I/O 3, Out 4, Out 5, Out6

Functionalities	Given to...
Drive Fan (D. Fan)	I/O 0, I/O 1, I/O 2, I/O 3, Out 4, Out 5, Out6
Drive Ok (Drv OK)	I/O 0, I/O 1, I/O 2, I/O 3, Out 4, Out 5, Out6
Simulated 24V Out (S24V)	I/O 3, Out 4, Out 5, Out6
Simulated GND (SGND)	In5

Table 16.6. Functionalities given to the resources of I/O

NOTE

Each functionality has a code that can be assigned to the inputs and outputs. These codes are listed in the [Table 27.21](#)

The following table lists the parameters for the selection of the functionality related to each single I/O. The procedure for their use is described in [Section 16.3, Configuring the I/O by using the parameters](#).

Resource	Parameter
I/O 0	IO_0_Function
I/O 1	IO_1_Function
I/O 2	IO_2_Function
I/O 3	IO_3_Function
In 4	In_4_Function
In 5	In_5_Function
In 6	In_6_Function
In 7	In_7_Function
In 8	In_8_Function
In 9	In_9_Function
Out 4	Out_4_Function
Out 5	Out_5_Function
Out 6	Out_6_Function


Table 16.7. List of the configuration parameters of the functionalities supported by every resource in the iBMD drives

16.2. Configuring the I/O through MotionDrive

All the settings about I/O are available from MotionDrive. Access:

Main menu > Drive > Drive setup ... > Digital I/O > I/O settings

Toolbar >  > Digital I/O > I/O settings




The mask of the Faults related to the functioning of the **Drive Ok (Drv OK)** output, the selection of the working mode of the **Enable** functionality and the positive increment of the counting of the master encoder can be selected through MotionDrive. Access:

Main menu > Drive > Drive setup ... > Digital I/O > Function settings

Toolbar >  > Digital I/O > Function settings

IMPORTANT

If one of the three differential I/O (I/O 0, I/O 1 e I/O 2) is reprogrammed, even the other two will be reconfigured. This may cause, even if the set functionality will not be lost, some "glitches", that are involuntary short transitions of the digital signal.



In this page it is possible to select the Faults that causes the switching-off of the output programmed as **Drive Ok (Drv OK)**.

It is furthermore possible to set if the disabling, commanded by the digital input configured as **Enable**, must be anticipated by the motor stopping with the QuickStop ramp (see [Section 22.3, Carrying out a stop by using the master](#)).

16.3. Configuring the I/O by using the parameters

To configure the Digital I/O by writing directly the related parameters, follow these instructions:

1. Run the command of the [System Manager 6200](#) to start the configuration procedure.
2. Select the functionalities through the parameters listed in [Table 16.7](#); the codes of the functionalities are listed in the description of the parameters.
3. Configuring the polarity ([PolarityInputValue](#)).
4. Run the command of the [System Manager 620](#) to end the configuration procedure.
5. Check any possible error.

The running of the settings related to the filtering and the termination resistance do not require any particular modes or commands of the [System Manager](#). Refer to [Section 16.5, Filters, polarities and terminations](#).

16.4. Functionalities

Generic Input (I/O X - In X)

The resource works as input for general use. The physical status of the input can be read through the parameter [DigitalInputs](#). The parameter [LogicalDigitalInputStatus](#) shows the input status after the application of the polarity (see [Selection of the polarity of the digital inputs](#)).

Generic Output (I/O X - Out X)

The resource works as output for general use. The output status can be read and written through the parameter [PhysicalOutputs](#). To prevent the accidental modification of one or more bits of the parameter [PhysicalOutputs](#) it is possible to block the writing, every bit through the parameter [DigitalOutputsBitMask](#).

Fault (Fault)

The *Fault* functionality enables the output when a retentive Fault is active. When the Fault is reset, the status of the digital output is set to zero. See [Chapter 24, Fault and Warning](#).

Home

Input used to carry out the homing of the shaft. (See [Section 22.19, Homing Mode](#)). Through the parameter [HomeStatus](#) it is possible to read the status of the limit switch, irrespective of the resource used for such functionality.

Step³

The functionality *Step* is used to get information on position and speed, gaining them from the frequency of the applied signal. This functionality can be used with the functionality [Dir](#). In this way it is possible to link the drive to third part controllers.

Dir⁴

The functionality *Dir* is used to get the direction of the reference gained through the functionality [Step](#). This functionality can be used with the functionality [Step](#). In this way it is possible to link the drive to third part controllers.

Positive limit switch (FC +)

Input of positive limit switch. The sensors used as limit switches must work when the contact is normally closed. The drive, for safety reasons, automatically selects the polarity of the input configured as limit switch, so that it can correctly work with this kind of sensor (see [Selection of the polarity of the digital inputs](#)). Through the parameter [FcStatus](#) it is

³This functionality is not yet available

⁴This functionality is not yet available

possible to read the status of the limit switch, irrespective of the resource used for such functionality.

 **WARNING**

If the **Polarity** is of Reverse type, the roles of **Positive limit switch (FC +)** and **Negative limit switch (FC -)** are reversed: **Positive limit switch (FC +)** behaves like **Negative limit switch (FC -)** and **Negative limit switch (FC -)** behaves like **Positive limit switch (FC +)**. This is true both in the text of this manual and in the MotionDrive.

Negative limit switch (FC -)

Input of negative limit switch. The sensors used as limit switches must work when the contact is normally closed. The drive, for safety reasons, automatically selects the polarity of the input configured as limit switch, so that it can correctly work with this kind of sensor (see [Selection of the polarity of the digital inputs](#)). Through the parameter **FcStatus** it is possible to read the status of the limit switch, irrespective of the resource used for such functionality.

Enable

The functionality Enable is a consent to enable the drive. When the functionality Enable is associated to one of the digital inputs, such input must be at the logical status '1' in order to take the drive to the [Operation enable](#) state. The consent to enable the drive can be read through the parameter [EnableInputStatus](#) irrespective of which input has been used for the Enable function. When [EnableInputStatus](#) value is 0, the CiA402 State Machine cannot be taken to the *Switched On* and [Operation enable](#) states (see [Section 8.5, CiA402 state machine](#)).

If the drive is in the [Operation enable](#) state and the Enable input is disabled then the following sequence takes place:

1. deceleration of the motor according to the settings of the parameter [DisableOption](#);
2. waiting for the motor stopping and enabling of the brake, if present;
3. the CiA402 State Machine enters the *Switch On Disabled* state (see [Section 8.5, CiA402 state machine](#));
4. activation of the [Drive is in disable state, since the enable input is or has been in not active state](#) Warning.

IMPORTANT


For some operating modes, when the Enable input is enabled, the drive goes automatically to the [Operation enable](#) state, unless the drive is in Fault. This function is called **Automatic Enable**; the operating modes with automatic Enable are specified in [Table 22.1](#).

Quadrature Input ChA (Ch A)

The functionality *Quadrature Input ChA* is used, with [Quadrature Input ChB \(Ch B\)](#), to get a quadrature signal, typically used by the incremental encoders.

To reverse the sense of positive rotation of the master encoder without modifying the electrical connections you can work on the [RealEncoderPolarity](#) parameter.

If you select this functionality the parameter [PolarityInputValue](#) does not have any effect.

 NOTICE


To read the master encoder position or to capture its position, it's necessary to program this functionality (together with [Quadrature Input ChB \(Ch B\)](#)) in the digital inputs. See [Section 15.5, Auxiliary position sensor](#)

Quadrature Input ChB (Ch B)

Through the functionality *Quadrature Input ChB* it is possible, together with [Quadrature Input ChA \(Ch A\)](#), to get a quadrature signal, typically used on the incremental encoders.

To reverse the sense of positive rotation of the master encoder without modifying the electrical connections you can work on the [RealEncoderPolarity](#) parameter.

If you select this functionality the parameter [PolarityInputValue](#) does not have any effect.

 NOTICE


To read the master encoder position or to capture its position, it's necessary to program this functionality (together with [Quadrature Input ChA \(Ch A\)](#)) in the digital inputs. See [Section 15.5, Auxiliary position sensor](#)

Quadrature Input Index (Idx)

The *Quadrature Input Index* functionality is used to get the [Index](#) pulse of an incremental encoder. It must be used together with [Quadrature Input ChA \(Ch A\)](#) and [Quadrature Input ChB \(Ch B\)](#).

To reverse the sense of positive rotation of the master encoder without modifying the electrical connections you can work on the [RealEncoderPolarity](#) parameter.

If you select this functionality the parameter [PolarityInputValue](#) does not have any effect.

 NOTICE

To use the [Index](#) as the capture event to capture the master encoder position it's necessary to program this functionality in the digital input 2 (see [IO_2_Function](#)).

Pwm out (Pwm O)

The functionality *Pwm out* runs the output by creating a frequency square wave and duty cycles to be set. The configuration parameters depend on which resource is used to run this functionality; you can find a list on the following chart:

Re-source	Parameter for frequency setting	Parameter for Duty Cycle setting
I/O 0	PwmHwFrequencyIO0	PwmHwDutyCycleIO0
I/O 1	PwmHwFrequencyIO1	PwmHwDutyCycleIO1
I/O 2	PwmHwFrequencyIO2	PwmHwDutyCycleIO2

Motor Fan (M. Fan)

The functionality *Motor Fan* is used to run a fan to cool the motor. The output is automatically enabled when the motor temperature exceeds the warning threshold (see [Table 24.3](#)). When the temperature of the motor is lower than this threshold, the output remains enabled for one minute and then it switches off.

Drive Fan (D. Fan)

The functionality *Drive Fan* is used to run a fan to cool the drive. The output is automatically enabled when the temperature of the control section or the one of the power section exceeds the Warning threshold (see [Table 24.3](#)). When both temperatures are lower than this threshold, the output remains enabled for one minute and then it switches off.

Drive Ok (Drv OK)

The functionality *Drive Ok* enables the output when the drive has finished the start-up phase and it is ready to get any command. This output is switched off because of the presence of Faults, since the drive is no longer operative. The Faults switching this output off can be selected through the [DisableOkOutput](#) parameter.

Simulated 24V Out (S24V)

The *Simulated 24V Out* functionality transforms the selected resource in a 24V supply output. If used together with [Simulated GND \(SGND\)](#), it can be used to supply external devices.

IMPORTANT

This functionality is available on drives with hardware revision 17 or higher.

Simulated GND (SGND)

The functionality *Simulated GND* transforms the selected resource into a ground terminal. It is useful to close the circuit of the digital outputs. If used together with [Simulated 24V Out \(S24V\)](#), it can be used to supply external devices.

NOTICE

[Simulated GND \(SGND\)](#) input is not protected against overcurrent.

IMPORTANT

This functionality is available on drives with hardware revision 17 or higher.

16.5. Filters, polarities and terminations

Filtering of the digital inputs

The status of the digital inputs is updated every 250 μ s.

If it is necessary to filter the digital inputs, it is possible to set a time interval, every 250 μ s, during which the input status must remain stable to be validated (debounce time).

For example if, due to noises, on the inputs some unwanted status changing happens for a shorter time than the debounce time, these noises are filtered and the input status is unaltered.

After this debounce time the image stored in the digital inputs is updated with the new status. The highest filter value is 65 ms.

The debounce configuration takes place through two parameters:

- **DebounceTime**: time during which the input status must be stable to be validated. It can be set every 250 μ s.
- **EnableDebounce**: Mask used to select on which digital inputs you can apply the filtering.

The possibility to enable the debounce depends on the functionality given to the digital input; the functionalities used to enable the filtering are:

- **Generic Input (I/O X - In X)**
- **Positive limit switch (FC +)**
- **Negative limit switch (FC -)**
- **Home.**

Selection of the polarity of the digital inputs

For the inputs of PNP type the enabled physical status is reached when the applied voltage (referred to the ground signal) surpasses the activation threshold declared on the [Table 16.3](#). For the line-driver differential ones the enabled status is reached when the voltage difference between the positive and negative inputs is greater than $+V_{thd}$, and the not enabled status is reached when the voltage difference is lower than $-V_{thd}$ (see [Table 16.3](#)).

the inputs logical status (1 or 0 in the inputs image) depends on both their physical status and the polarity that's set through the **PolarityInputValue** parameter. If the polarity value is 0 then the logical status coincides with the physical one, otherwise if the polarity value is 1 then the logical status is inverted respect to the physical one. The **PolarityInputValue** parameter must be written during the Digital I/O configuration procedure (see [Section 16.3, Configuring the I/O by using the parameters](#)).




Figure 16.1. Inputs logical status in relation to the polarity.

The functionalities **Positive limit switch (FC +)** and **Negative limit switch (FC -)** force to zero the bits corresponding to the parameter **PolarityInputValue**.

Termination resistances

For the resources with logic of differential kind (Table 16.1) it is possible to enable the termination resistance through the parameter **TerminationResistance**.

Chapter 17

Analog input

The features of the analog input are summarized in the following table:

Analog input 0	Details
Electric features	Range $\pm 10V$; Precision $\pm 10mV$
Connections	Pin 3 and 4 of CN4
Updating time AI0Voltage	CurrentLoopPeriod
Updating time AI0FilteredVoltage	MotionLoopPeriod

Table 17.1. Features of AI0

The features of the analog input, related to the [CN4](#) connector, are summarized in the following table:

ANALOG INPUT FEATURES	
Maximum operating differential voltage	$\pm 10V$
Maximum absolute differential voltage	$\pm 15V$
Maximum common-mode voltage ^a	<ul style="list-style-type: none"> • with $V_{in} = +10V \rightarrow -18,9V < V_{cm} < +7,7V$ • with $V_{in} = -10V \rightarrow -2,3V < V_{cm} < +27,7V$
Input detection delay	max $300\mu s$
Resolution	$\pm 50mV$
Differential input resistance	$> 150k\Omega$

^arelative to the system power ground.

Table 17.2. Analog input electrical features on [CN4](#)

The parameters of the analog input are summarized in the following table:

Analog input 0	Parameter	Description
Capture	AI0Voltage	Not filtered value
	AI0FilteredVoltage	Filtered value
Calibration	AI0CalibrationStatus	Calibration status
	AI0CalibrationOffset	Calibration offset
	AI0CalibrationGain	Calibration gain
	AI0CalibrationVoltage	Calibration voltage
Filter	AI0FilterFrequency	Filter frequency
	AI0FilterType	Filter type
	AI0FilterQFactor	Filter Q factor
Conversion	AI0VSettings	Set-up of the voltage for the conversion
	AI0RSettings	Set-up of the conversion reference
	AI0VPolarity	Polarity of the voltage for conversion
	AI0RPolarity	Polarity of the conversion reference
	AI0VOZone	Half amplitude of the dead zone in the conversion
	AI0VRefLevel	Voltage value to define the conversion
	AI0TRefValue	Torque value to define the conversion
AI0WRefValue	Speed value to define the conversion	

NOTE

About the electrical connections please see the [Analog input](#) data in the related section.


17.1. Capture

The analog input is sampled every [CurrentLoopPeriod](#) and can be read in the parameter [AI0Voltage](#). The filtered value of [AI0Voltage](#) is updated every [MotionLoopPeriod](#) and can be read in the parameter [AI0FilteredVoltage](#).

Access with MotionDrive:

Main menu > Drive > Drive setup ... > Analog input

Toolbar >  > Analog input



17.2. Calibration

The analog input calibration is made on every single drive by Bonfiglioli.

ADVICE

Carry out the analog input calibration only after having precisely checked that the drive does not have a correct voltage value. It is possible to carry out the calibration to adapt the values of the analog input to the voltage generated by a generic source.

To carry out the calibration of the analog input follow these instructions:

- Step 1: analysis
 - switch off all circuits that can influence the reading accuracy of the analog input;
 - apply a direct constant voltage to the analog input;
 - make use of a voltmeter previously calibrated and enough precise;
 - check the reading accuracy of the analog input by making reference to the electric features in [Table 17.1](#). If accuracy is observed, it is not necessary to carry out the calibration; if accuracy is not observed and you think you shall carry out the calibration, go to step 2;
- Step 2: Offset calibration
 - apply a voltage 0V to the analog input (or firmly short-circuit the analog input);
 - run the command of [System Manager](#) 7200;
 - check if the value of [AIOCalibrationOffset](#) is between -10 e +10; if the value of [AIOCalibrationOffset](#) is in the specified interval then go to step 3, otherwise repeat more precisely the step 2 or contact Bonfiglioli;
- Step 3: Gain calibration
 - apply a direct voltage between +4 e +10V to the analog input;
 - measure the applied voltage through a voltmeter previously calibrated and enough precise and write its value in the parameter [AIOCalibrationVoltage](#) ;
 - run the command of [System Manager](#) 7201;
 - check if the value of [AIOCalibrationGain](#) is between 4950 e 5050; if the value of [AIOCalibrationGain](#) is in the specified interval then go to step 4, otherwise repeat more precisely the step 3 or contact Bonfiglioli;
- Step 4: checking
 - apply different voltage values to the analog input and check if the voltmeter and the parameter [AIOVoltage](#) give the same results according to the accuracy specified in the [Table 17.1](#); if all the comparisons give a positive result, go to step 5, otherwise repeat the calibration from the beginning or contact Bonfiglioli;
- Step 5: data storage
 - the calibration parameters of the analog input are of ES-type and they can be saved in the permanent memory by running the command of [System Manager](#) 2001.

IMPORTANT

By restoring the default values of the parameters, the calibration data of the analog input are overwritten with their related default values.

17.3. Conversion


The value of the filtered analog input ([AIOFilteredVoltage](#)) can be used as torque limit or torque or speed reference depending on the value of [TorqueLimitSelector](#) and of [Mod-](#)


esOfOperation. To convert the voltage values in torque or speed values, the parameters [AI0ConversionParameters](#) are used. In order to define the various conversion options, use MotionDrive, considering the reported conversion diagrams.

Parameters to define the conversion function

In the following MotionDrive page, the parameters used to convert the input voltage can be set. Access:

Main menu > Drive > Drive setup ... > Analog input


Toolbar >  > Analog input





References related parameters

In the following page of MotionDrive it's possible to choose the parameters related to the references (the [AI0TRefValue](#) parameter is even used by the torque limit). Access:

Main menu > Drive > Drive setup ... > Control mode

Toolbar >  > Control mode




Torque limit related parameters

In the following page of MotionDrive it's possible to choose the parameters related to the torque limit (the [AI0TRefValue](#) parameter is even used by the reference conversion). Access:

Main menu > Drive > Drive setup ... > Limits and windows settings

Toolbar >  > Limits and windows settings



Chapter 18

Capture Peripherals


The drives of *iBMD* series are equipped with two capture peripherals which allow to capture a maximum of 3 quantities each and which are driven by a trigger signal that causes the capture. This signal can be linked to a digital input or can be controlled by the user, through a parameter, to force the capture via software.

Furthermore the drive provides some particular filters and algorithms to detect and validate the capture events. In this way, through the capture peripherals, it is possible to carry out some complex functionalities or avoid undesired captures.

The currently available algorithms are:

- Filter on [CaptureSource0_A](#) and [CaptureSource0_B](#) (typically the position).

From now onwards we are going to call the two capture peripherals **Capture A** e **Capture B**.




If the desired capture is the one with the master encoder [Index](#), remember to program the digital input 2 (see [IO_2_Function](#)) with the [Quadrature Input Index \(Idx\)](#) functionality.

18.1. Configuring the capture by using MotionDrive

In the MotionDrive it's possible to make the capture configuration through the related page in the DriveSetup. Access:

Main menu > Drive > Drive setup ... > Captures

Toolbar >  > Captures



18.2. Configuration interface selection

In the iBMD series drives, 2 configuration interfaces have been integrated: CUSTOM interface and CiA-402 interface, that can be selected through the CaptureInterfaceMode parameter.

IMPORTANT

It's not possible to change the interface if the capture functionality is active:

- in case CaptureInterfaceMode value is 0 (CUSTOM interface): if at least one of the CaptureUnitState_A and CaptureUnitState_B parameters value is 1
- in case CaptureInterfaceMode value is 1 (CiA-402 interface): if both the bits 0 and/or both the bits 8 of TouchProbeFunction and of TouchProbeStatus are set to 1.

NOTICE

These two interfaces cannot be contemporary used because the contained informations are not consistent.

In fact these two capture interfaces differ in some details. Here follows the list of the main limits and differences:

- If case of access to the not selected interface, in reading operation the answer is 0, while in writing operation an ABORT is reported. More than this, the "Capture setup setting by using disabled parameters interface (look at parameter 'CaptureInterface-Mode')" warning bit is set, in the [ParamSoftError](#) parameter. This Warning doesn't automatically reset, it has to be reset by the user.
- When the interface is changed, the new one is re-initialized with the values that are memorized in the EEprom, if they are compatibles with the selected interface, or with the default values.
- The filter in space ([CaptureSource0_A](#) and [CaptureSource0_B](#)) is only available for the CUSTOM interface and cannot be used with the double side capture.
- In both the interfaces, the settings of the repetitive mode and of the trigger cannot be made with the capture enabled. If these selections are made, then the "Filter or trigger on both edges not allowed on selected trigger input" Warning bit is set in the [ParamSoftError](#) parameter. In the CUSTOM mode the enable operation is not allowed, in the [CiA-402](#) mode, considering that the setting and the enable operations are contemporary (because both are done through the same parameter), the parameter reports an Abort.

18.3. Configure the capture by using the CUSTOM interface parameters

The configuration of the capture peripheral must be carried out when the peripheral is disabled, otherwise the configuration parameters will not be writable.

The two capture peripherals available on the drives of *iBMD* series are identical. Here follow the configuration parameters for each peripheral:

Configuration	Capture A	Capture B
Trigger signal	CaptureTriggerInput_A	CaptureTriggerInput_B
First quantity to capture	CaptureSource0_A	CaptureSource0_B
Second quantity to capture	CaptureSource1_A	CaptureSource1_B
Third quantity to capture	CaptureSource2_A	CaptureSource2_B
Capture edge	CaptureTriggerEdge_A	CaptureTriggerEdge_B
Inhibit time	CaptureInhibitTime_A	CaptureInhibitTime_B
State of the capture peripheral	CaptureUnitState_A	CaptureUnitState_B
Capture peripheral control	CaptureUnitCommand_A	CaptureUnitCommand_B
Captured value, first quantity	CapturedValue0_A	CapturedValue0_B
Captured value, second quantity	CapturedValue1_A	CapturedValue1_B
Captured value, third quantity	CapturedValue2_A	CapturedValue2_B

Once trigger ([CaptureTriggerInput_A](#)), values to capture ([CaptureSource0_A](#), [CaptureSource1_A](#), [CaptureSource2_A](#)), capture edge ([CaptureTriggerEdge_A](#)) and inhibit time ([CaptureInhibitTime_A](#)) are configured, you can start the capture peripheral by properly writing the [CaptureUnitCommand_A](#) parameter.

Now, the capture state has to be verified through the [CaptureUnitState_A](#) parameter, and when it indicates that the capture has happened, the results can be read through the [CapturedValue0_A](#), [CapturedValue1_A](#) and [CapturedValue2_A](#) parameters.

To optimize the space, if the capture results are mapped on PDO, you can use some parameters having a different length, that you can use depending on the needs. In the following chart you can find the table:

Configuration	Capture A (word)	Capture A (byte)	Capture B (word)	Capture B (byte)
Captured value, first quantity	CapturedValue0_Word_A	CapturedValue0_Byte_A	CapturedValue0_Word_B	CapturedValue0_Byte_B
Captured value, second quantity	CapturedValue1_Word_A	CapturedValue1_Byte_A	CapturedValue1_Word_B	CapturedValue1_Byte_B
Captured value, third quantity	CapturedValue2_Word_A	CapturedValue2_Byte_A	CapturedValue2_Word_B	CapturedValue2_Byte_B

18.4. Filter on CaptureSource0_A and CaptureSource0_B

This kind of filter validates the capture if the trigger signal is enabled, until the value of the first quantity to capture evolves into a quantity set by the user. The capture is carried out on the edge of the trigger signal which has been programmed ([CaptureTriggerInput_A](#), [CaptureTriggerInput_B](#)), but the capture peripheral reports that the capture has been carried out and shows the results only after the validation.

At this point the trigger signal is on the active state. To go back to the "inactive" state and to carry out a new capture, the trigger signal undergoes the same validation. The filtering values for the enabled capture edge and for the restore edge can be different.

This kind of filter is normally used by selecting [PositionActualValue](#) on the first quantity to capture; in this way it is possible to apply a proportional filtering to the motor speed, in this case the capture is validated only if the trigger signal is enabled for a certain position range. The functioning of the filter is shown in [Figure 18.1](#).




Figure 18.1. Example of filtering of the trigger signal.

Configuration of the filtering

The configuration of this function is very easy, since it is just necessary to specify the value of the filtering (parameters [CaptureRestoreSlopeValidationFilter_A](#) and [CaptureActiveSlopeValidationFilter_A](#) for Capture A, and parameters [CaptureRestoreSlopeValidationFilter_B](#) and [CaptureActiveSlopeValidationFilter_B](#) for Capture B), and the mode of the symmetric/asymmetric filtering (parameters [CaptureValidationFilterMode_A](#) for Capture A, and [CaptureValidationFilterMode_B](#) for Capture B).

The value according to which the parameters are set is related to the first quantity to capture, so it has the same unit of measurement.

Chapter 19

Motion limits

19.1. Electricity limit

To reduce the motor electricity you need to write the parameter [UserPeakCurrent](#). Reducing the motor electricity means reducing the motion performances, so reducing the highest supplied torque ([ActualTorqueLimitP](#)).

Access with MotionDrive:

Main menu > Drive > Drive setup ... > Motor and drive

Toolbar >  > Motor and drive



19.2. Limit I2T

The I2T limit reduces the electric power which is transferred to the motor during the overload periods. For further details see [Section 14.6, I2T](#).

19.3. Torque limit


To reduce the highest supplied torque write the parameter [TorqueLimitSelector](#) so that you can select the source where the torque limit can be obtained. The torque limit can be limited by:


- the [PeakCurrent](#) parameter value only
- the combination between the [MaxTorque](#), [PositiveTorqueLimitValue](#) and [NegativeTorqueLimitValue](#) parameters
- the value that has been obtained from the analog input voltage conversion, according to what's reported in [Section 17.3, Conversion](#)

In any case, in the [ActualTorqueLimitP](#) and [ActualTorqueLimitN](#) parameters you can read the value of the torque limits that are really applied to the motor. When a torque limit intervenes, the [Limit reached](#) Warning activates with the [Torque limit reached](#) detail.

Access with MotionDrive:

Main menu > Drive > Drive setup ... > Limit and windows settings

Toolbar >  > Limit and windows settings



Example of torque limit use

In order to execute a homing with mechanical stop, it is necessary to activate the torque limit. For example, by setting the mode -1 in the [HomingMethod](#) parameter, the mode 2 in the [TorqueLimitSelector](#) parameter, it has to be set the conversion of the limit from the analog input, as described in the [Section 17.3, Conversion](#).

Torque values calculation procedure

In order to limit the torque to the value T_{Lim} , continue as follows:

1. read the torque constant K_T [TorqueConstant\(ForceConstant\)](#)
2. read the stall current I_S [MotorStallCurrent](#)
3. calculate the stall torque T_S [Nm] as K_T [Nm/A] * I_S [A]
4. calculate the T_{Lim} torque limit expressed in [% I_S] as $(T_{Lim}$ [Nm] / T_S) * 100 or as $(I_{Lim}$ [A] / I_S) * 100
5. multiply the obtained value per 10 to obtain the T_{Lim} torque limit expressed in [% I_S 10] and insert this value in the desired torque parameter

Calculation example of **PositiveTorqueLimitValue**

With a *iBMD* with a 2.8 Nm motor, we want to limit the torque, in positive direction, to 1Nm and to not limit the torque in the negative direction. by following the above described procedure we obtain:

$$K_T = 1.6 \text{ Nm/A}$$

$$I_S = 1.75 \text{ A}$$

$$\text{PeakCurrent} = 5 \text{ A}$$

$$T_S = K_T [\text{Nm/A}] * I_S [\text{A}] = 1.6 \text{ Nm/A} * 1.75 \text{ A} = 2.8 \text{ Nm}$$

$$T_{\text{LimP}} [\%I_S] = (T_{\text{Lim}} [\text{Nm}] / T_S [\text{Nm}]) * 100 = (1 \text{ Nm} / 2.8 \text{ Nm}) * 100 = 35.7 \%I_S$$

$$T_{\text{LimN}} [\%I_S] = (I_{\text{Lim}} [\text{A}] / I_S [\text{A}]) * 100 = (5 \text{ A} / 1.75 \text{ A}) * 100 = 285.7 \%I_S$$

$$\text{PositiveTorqueLimitValue} = T_{\text{LimP}} [\%I_S] * 10 = 35.7 \%I_S * 10 = 357 \%I_S10$$

$$\text{MaxTorque} = \text{NegativeTorqueLimitValue} = T_{\text{LimN}} [\%I_S] * 10 = 285.7 \%I_S * 10 = 2857 \%I_S10$$


19.4. Speed limit

To set the speed limit you need to write the parameter **MaxMotorSpeed**. The speed limit is an absolute value and it works in a symmetric way on the speed request of the drive. It works only with the operative modes speed or position. When a speed limit intervenes, the Warning **Limit reached** activates with the **Max motor speed limit reached** detail.

Access with MotionDrive:

Main menu > Drive > Drive setup ... > Limit and windows settings

Toolbar >  > Limit and windows settings



19.5. Limits of hardware position

To enable the limits of hardware position you need to set the functionalities **Positive limit switch (FC +)** and **Negative limit switch (FC -)** on two digital inputs of the drive (see [Chapter 16, Digital inputs and outputs](#)).



WARNING

If the **Polarity** is of Reverse type, the roles of **Positive limit switch (FC +)** and **Negative limit switch (FC -)** are reversed: **Positive limit switch (FC +)** behaves like **Negative limit switch (FC -)** and **Negative limit switch (FC -)** behaves like **Positive limit switch (FC +)**. This is true both in the text of this manual and in the MotionDrive.

When the drive is in **Operation enable**, **RequestedSpeed** (**TargetTorque** for torque modes) is higher than 0 and the **Positive limit switch (FC +)** input enables, or **RequestedSpeed** (**TargetTorque** for torque modes) is lower than 0 and the **Negative limit switch (FC -)** input is enabled, the motor stops with a deceleration ramp equal to **QuickStopDeceleration**.

During the deceleration ramp, the CiA402 State Machine goes to the **Quick Stop Active** state and, once the motor has stopped, it goes back to the **Operation enable** state (see [Section](#)

8.5, *CiA402 state machine*). When one of the hardware position limits is enabled, the **Limit reached** Warning activates with the related detail (**Positive hardware position limit reached** or **Negative hardware position limit reached**), and remains active until the limitation stops.

⚠ ATTENTION

When the drive is in **Operation enable**, **RequestedSpeed** (**TargetTorque** for torque modes) is higher than 0 and the **Negative limit switch (FC -)** input enables, or **RequestedSpeed** (**TargetTorque** for torque modes) is lower than 0 and the **Positive limit switch (FC +)** input enables, the motor does not stop and there are no further signals.

19.6. Limits of software position

To enable the limits of software position you need to write 1 in the parameter **PositionLimitEnable** and write the two limits, the positive and the negative one, in the group **SoftwarePositionLimit**.

When the drive is in **Operation enable**, **RequestedSpeed** (**TargetTorque** for torque modes) is higher than 0 and **PositionActualValue** is greater than **PositionLimitPositive**, the motor stops with a deceleration ramp equal to **QuickStopDeceleration**. When the drive is in **Operation enable**, **RequestedSpeed** (**TargetTorque** for torque modes) is lower than 0 and **PositionActualValue** is lower than **PositionLimitNegative**, the motor stops with a deceleration ramp equal to **QuickStopDeceleration**.

During the deceleration ramp, the CiA402 State Machine goes to the *Quick Stop Active* state and, once the motor has stopped, it goes back to the **Operation enable** state (see [Section 8.5, CiA402 state machine](#)). When one of the software position limits is enabled, the **Limit reached** Warning activates with the related detail (**Positive software position limit reached** or **Negative software position limit reached**), and remains active until the limitation stops.

Access with MotionDrive:

Main menu > Drive > Drive setup ... > Limit and windows settings

Toolbar >  > Limit and windows settings

Position limit		
<input checked="" type="checkbox"/> Enable limits	Positive limit: <input type="text" value="2147483647"/> inc	Negative limit: <input type="text" value="-2147483648"/> inc

NOTE

If you set **PositionLimitPositive** lower than **PositionLimitNegative** the error **Parameters soft error** enables with detail **Software position limits incompatibility**.

19.7. Profiles limit

The speed and acceleration parameters of the operating modes, aiming at running a profile to run a motion, are limited by the following parameters:

- **MaxProfileVelocity** and **MaxMotorSpeed**: the lowest value between these two parameters, it reduces all speed parameters of the profilers.
- **MaxAcceleration**: limit of all acceleration parameters of the profilers.

- **MaxDeceleration**: limit of all the deceleration parameters of the profilers.

When you have a limitation on at least one parameter of the profilers, the **Motion parameter limited** Warning enables. In [Table 24.16](#) you can find the error detail with the limited parameters.

Access with MotionDrive:

Main menu > Drive > Drive setup ... > Limit and windows settings

Toolbar >  > Limit and windows settings

Profiler limits			Speed limit		
Max accel.:	<input type="text" value="262143920"/> inc/s ²	Max decel.:	<input type="text" value="262143920"/> inc/s ²	Max velocity:	<input type="text" value="400000"/> inc/s
				Max motor speed:	<input type="text" value="3600"/> rpm

NOTE


The **MaxMotorSpeed** sets also the speed limit for all drive motions in the operating modes speed or position (see [Section 19.4, Speed limit](#)).

Chapter 20

System tuning

20.1. How to determine the tuning criterion

To tune the drives of the *iBMD* series follow the instructions in this and in the next paragraphs. The operations for adjusting the drive are summarized in the next flow chart.



1. Preliminary step A: system data

Before starting the tuning process it is necessary to gather all the data of the mechanical load; in particular you need to analyse the transmission typology and quality, the stiffness of the machine structure and size of the inertia moments, frictions, elasticity and backlashes. The more information you have, the easier the next tuning phases will be. Check if the requested performances are compatible with the system mechatronic features. Check if the electric connections are correctly connected and the mechanical transmission is perfectly working.

2. Preliminary step B: requested performances

Define the motion performances to be reached. Without these data, the tuning has no sense. Defining precisely the requested performances by including all evaluation criteria may simplify the tuning validation. You can include in the technical specifications also the non-scientific criteria as for example getting a visibly fluid motion with no bothering noise. Every parameter can be analysed for the tuning validation.

3. Move the motor

To check the basic performances it is necessary to move the motor with realistic motions in the foreseen load conditions. You can start with some easy and slow motions and then move to the motions the machine is designed for. The motion must be carried out by starting from low working speeds till over the requested limit in order to check the system solidity. In presence of variable load the motion must be tested in the different configurations and in particular in the extreme and more demanding ones. To move the motor you can start

with the internal references generator ([Section 20.6, Function Generator](#)) and then use the motion controller which produces the working cycle the machine is designed for.

⚠ WARNING

Before moving the motor check if you can stop it in safety. If some errors or anomalies happen during the tuning, the motor can quickly reach a non-controlled speed, reaching quickly the position limit and hitting violently some other mechanical parts. To avoid such inconveniences enable all the necessary precautions and configure precisely all drive limits ([Chapter 19, Motion limits](#)).

4. Performance reached?

To answer to this question you need to get the specifications about the requested motion performances; it is easier to understand when one motion is not acceptable than trying to understand the exact point where one acceptable motion becomes unacceptable. Most of the objective criteria are based on the numerical analysis of parameters as [PositionFollowingError](#) and [SpeedFollowingError](#), in some particular points of the working cycle. For example: [PositionFollowingError](#) lower than X increment after Y milliseconds at the end of the acceleration ramp; [SpeedFollowingError](#) limited in % during a motion at constant speed; [ActualTorque](#) never higher than X % as to the selected limit. It is important to concentrate on those criteria that can guarantee the system reliable performances.

5. Tuning the drive

The tuning of the drives of the *iBMD* series must be done by using MotionDrive. To tune the loops use one of the following criteria:

- [Section 20.3, Fast tuning guide](#)
- [Section 20.5, Detailed tuning guide](#)

The loops that have to be tuned depending on the operative modes are listed in the following table:

ModesOfOperationDisplay	CurrentLoop	VelocityLoop	PositionLoop
Torque	YES	YES	-
Speed	YES	YES	-
Position	YES	YES	YES
Homing	YES	YES	YES

Table 20.1. Loop that have to be tuned depending on the operative mode, reported in the .

⚠ WARNING

If the motor is controlled in one of the torque modes, it's necessary to tune the velocity loop, because the "halt" and "quick stop" commands (see [Section 22.3, Carrying out a stop by using the master](#)) and the non fatal Fault reactions execute a deceleration ramp, controlled in velocity, to stop the motor.

⚠ ATTENTION

Whatever is the selected [ModesOfOperation](#), the [Safety profile](#) executes a movement that's controlled in position. To use the Security profile it's always necessary to tune the position loop.

20.2. Reset the tuning


To take the tuning configuration back to a known condition, choose among the [System Manager](#) commands that are listed in the following table:

Name	SysMng-Command	Button	Description
Set all loops, tuning and estimated parameters at default	1101	Set all loops, tuning and estimated parameters at default	Set the loop parameters (CurrentLoop , VelocityLoop , PositionLoop) of the TuningConfigurations and of the estimated parameters (InertiaEstimator and RLEstimator) to the default values
Parameter recalculation of all loops	1102	Recalculate all loops	Recalculation of the loop parameters in relation to the TuningConfigurations and to the estimated parameters
Parameter recalculation of motion loops	1103	-	Recalculation of the motion loop parameters in relation to the TuningConfigurations , to the estimated parameters and to the CurrentLoopEstimatedBandwidth
Parameter recalculation of current loop	1110	Recalculate	Recalculation of the CurrentLoop parameters in relation to the TuningConfigurations and to the estimated parameters
Parameter recalculation of speed loop	1120		Recalculation of the VelocityLoop parameters in relation to the TuningConfigurations , to the estimated parameters and to CurrentLoopEstimatedBandwidth
Parameter recalculation of position loop	1130		Recalculation of the PositionLoop parameters in relation to the TuningConfigurations , to the estimated parameters and to VelocityLoopEstimatedBandwidth
Permanent memory: reload value of loops parameters and tuning configuration	2301	Load loops parameters from permanent memory	Updating the loops parameters and the TuningConfigurations with the values in the permanent memory

20.3. Fast tuning guide

This guide contains the quick criterion to tune the drives of the *iBMD* series. The tuning must be run together with MotionDrive from the *Fast Tuning* Tab by following step by step the instructions reported in [Section 20.1, How to determine the tuning criterion](#). Access:

Main menu > Drive > Tuning... > Tab Fast tuning


Toolbar >  > Tab Fast tuning.

ADVICE

In case of problems or unexpected situations please see the [Section 25.8, Tuning problems](#).


NOTE

The  button stops the tuning command according to Tuning end option settings.

The  button ends the tuning command by stopping the motor with maximum deceleration and resetting RequestedSpeed and then the drive enters the Switch On Disabled status.

0. Setting of the default configuration

The first operation to do is taking the drive in the default tuning configuration: push the

button . In this configuration the motor can move with lowest dynamic performances; if the motion satisfies the requested performances, it is not necessary to run further tuning operations. If the performances were not satisfactory, continue with the following points.

1. Options selection

- *Tuning current loop* must be activated to improve the current loop performances (usually it is not necessary). For further details please see [Section 20.7, RL estimator](#)
- *I can move the motor shaft of 10rev* must be activated if the system mechanics allows the motor to safely move for 10 revolutions. This option requires more accurate the estimation of [EstimatedInertia](#). If the motor can move for no more than 1 revolution, then it is however possible to proceed with the *Fast tuning* without selecting this

option. If, on the contrary, it is not possible to move the motor, it is necessary to abort the *Fast tuning* procedure and to execute the parameters calculation as reported in [Section 20.4, Gains calculation](#).

- *Direction of tuning movement* allows to select the motor movement direction during the tuning operation.
- [DynamicResponse](#) influences the motor dynamic performances. When the requested dynamic answer increases, the motor answering times and the following errors are reduced. As against, while the dynamic response increases, the stability margins are reduced and eventual electrical or mechanical resonances are amplified. These resonances are not always eliminated by using the filters but it has to be willing to accept a more limited dynamic answer.
- [Stiffness](#) modifies the motor stiffness when it is stopped in torque. When the stiffness increases, the motor is more able to stay steady; on the contrary the stability margins are reduced and any possible electrical and mechanical resonances amplified as happening for the option [DynamicResponse](#).
- The [VelocityLoopFilter1](#) works on the first filter of [VelocityLoop](#) and on the sensor filter and can take the following values:
 - User: the tuning commands don't modify the filter parameters
 - Soft filter: the filters are modified to make a *sweet* filtering action of the noise that's present in the loop.
 - Noise filter: the filters are modified to make a *heavy* filtering action of the noise that's present in the loop.
 - Disable: the filtering action for the noise that's present in the [VelocityLoop](#) is deleted. In this case it can be obtained a faster dynamic response.
- The [VelocityLoopFilter2](#) works on the 2 and 3 filters of the [VelocityLoop](#) and can take the following values:
 - User: the filters parameters are not modified.
 - Resonance filter: a single filter is inserted to eliminate the constant frequency mechanical resonances
 - Double resonance filter: 2 filters are inserted to *strongly* eliminate the constant frequency mechanical resonances,
 - Debounce filter: a single [Low-pass filter of the first order](#) is inserted, in order to limit the unwanted effects of the mechanical transmissions if it is not stiff or if it has backlashes.
 - Notch filter fixed: a [Band-eliminating filter](#) is inserted and set to 350Hz.
 - Disable: the filtering action is deleted.
- [TuningEndOption](#) and [TuningEndDeceleration](#) define the operation that are executed when the *End* button (command 100 of the [System Manager](#)) is pressed or at the end of the tuning movement.

2. Movement limits selection

If necessary, set the movement limits according to what's reported in [Chapter 19, Motion limits](#) and insert the values of [InertiaEstimatorVelocity](#) and [EstimatorTorque](#) that will be used during the tuning movement. In most cases it is not necessary to modify the default values of these two parameters.

3. Tuning movement

By pressing the *Start* button the tuning procedure starts, and automatically stops when the progress bar disappears.

4. Results verification

When the tuning movement is concluded, check that there are no anomalies reported in the *Drive information* field. The oscilloscope shows the step response of the *Velocity loop*. Evaluate the response and, eventually, modify the tuning, according to what's reported in [Section 20.4, Gains calculation](#).

To better calculate the total inertia moment as to the motor shaft, see what's reported in [Section 20.9, Inertia estimator](#).

To better calculate the mechanical resonances as to the motor shaft, see what's reported in [Section 20.8, Resonance estimator](#).

20.4. Gains calculation

This functionality allows to tune the loops parameters without to move the motor. Follow the instructions reported in the *Gains calculation* Tab.

Access with MotionDrive:

Main menu > Drive > Tuning ... > Tab Gains calculation

Toolbar >  > Tab Gains calculation

Channels | Loops settings | Function generator | Fast tuning | **Gains calculation** | Tuning current | Resonance estimator | Inertia estimator

Gains calculation (without motor movement)

1. Choose your options:

Loop: Dynamic response: Stiffness: Velocity loop filter 1: Velocity loop filter 2:

2. Calculate the total moment of inertia, compared to the motor shaft.

3. Write the total inertia calculated: Jm Motor inertia: g cm²
Reduction factor:

4. If you know it, write mechanical resonance frequency: Hz

5. Press Calculate button and look at the drive information below.

Position: inc Drive status:

Drive information:

1. Options selection

Select the desired configuration, selecting between the available options. The option selection criteria are reported on the point 1 of the [Section 20.3, Fast tuning guide](#).

2. Total inertia moment calculation

NOTE

If the "Fast Tuning" has already been executed, it's possible to directly jump to the next point.

[EstimatedInertia](#) is the total inertia moment and includes the motor, the brake, the mechanical transmission and the load. A precise analytical estimate of the inertia moment is often very complex: you can accept even a gross estimate but probable. Bear in mind the rules of the inertia moment calculation, in particular the conversions to do between linear motion and rotatory motion, the conversions in presence of reducers and mechanical connections in general and the formulae to calculate the inertia moment of the more common solid objects. If the mechanical allows the motor movement, it is advisable to execute the calculation of [EstimatedInertia](#) through the dedicated estimator (see [Section 20.9, Inertia estimator](#)).

3. Settings of the total inertia moment

Write the calculated inertia value in the dedicated field, and if one of the following cases happens:

- loads with inertia moment greater than 5 Jm, without friction or dumping
- Not rigid mechanical transmission
- consistent backlashes and tolerance in the mechanical transmission

that cannot be solved through the filters options, it's necessary to tune the motor as if the total inertia moment is lower than the estimated value. To do this it's necessary to decrease the value of the [InertiaReductionFactor](#) parameter (try with 0.8, 0.5, 0.3). Too low values of [InertiaReductionFactor](#) cut down the motor dynamic performances.

4. Mechanical resonance

NOTE

If the "Fast Tuning" has already been executed, it's possible to directly jump to the next point.

[EstimatedResonanceFrequency](#) is the mechanical resonance frequency estimated value. If there are mechanical resonances it's advisable to pay attention to the contents of [Section 20.8, Resonance estimator](#).

5. Parameters calculation

Execute the parameters calculation by pressing the *Calculate* button and verify that in the *Drive information* field there are no anomalies reported. If the desired performances have

not been reached, restart from the point 1 and select different options, or execute a tuning according to what's described in [Section 20.5, Detailed tuning guide](#).

20.5. Detailed tuning guide

This guide contains the detailed criterion described about the drive tuning of the *iBMD* series. The tuning must be carried out together with MotionDrive according to the instructions in the [Section 20.1, How to determine the tuning criterion](#): each tuning operation must be carried out together with the check of the performances through the motor motion.

ADVICE

In case of problems or unexpected situations please see the [Section 25.8, Tuning problems](#).

Unless differently specified the operations can be run from the tab Loops settings of MotionDrive. Access:

Main menu > Drive > Tuning ... > Tab Loops settings

Toolbar >  > Tab Loops settings

The screenshot shows the 'Loops settings' tab in the MotionDrive software. The interface is organized into several functional areas:

- Position loop:** Includes fields for KPp (40), KVff (1.000), and a 'Close position loop' checkbox. It also features a 'Position stand still' slider, a 'Stability' field (40), a 'Stiffness' field, and a 'Position error dead band' field (0 inc).
- Velocity loop:** Includes fields for KVp (101), KVi (67), KAff (1.000), KVd (34), and KVd filter frequency (15000). It also has a 'Velocity stand still' slider, a 'Stability' field (101), and a 'Stiffness' field.
- V filters:** Contains three filter settings (1, 2, 3) with dropdown menus for filter type and frequency fields. A 'Sensor' dropdown and frequency field are also present. An 'Estimated bandwidth' field (43 Hz) and a 'Recalculate' button are included.
- Current loop:** Includes fields for KCp_Q (2447), KCl_Q (1745), KCp_D (2447), and KCl_D (1745). It features a 'C filter' dropdown (Low pass 1st order) and frequency field (7048 Hz). Checkboxes for 'Enable predictive measure' and 'Enable EMF compensation' are present. An 'Angle observer bandwidth' field (891 Hz) and an 'Estimated bandwidth' field (458 Hz) are also shown.
- Field weakening:** Includes a dropdown menu set to 'Enable - Low pass 2nd order'.
- Buttons:** At the bottom, there are buttons for 'Load loops parameters from permanent memory', 'Recalculate all loops', 'End actual tuning command', 'Tuning', 'Save all parameters', 'Show errors', 'Help', and 'Close'.

If you cannot find a parameter in the page, use the parameters vocabulary ([Section 27.10, Loop \(1500-1599\)](#)).

1. Parameters estimation

The first operation to be executed is the parameters estimation according to the procedure described in [Section 20.7, RL estimator](#), [Section 20.8, Resonance estimator](#) and [Section 20.9, Inertia estimator](#).

2. PositionLoop inhibition

During this step the focus is on the *VelocityLoop* tuning. The *PositionLoop* must be strongly inhibited so that it doesn't influence the dynamic of the *VelocityLoop*. During this step it is accepted that *PositionFollowingError* is slowly controlled. Proceed in this way.

- disable the *EnablePositionStandStill* option
- set *KPp* equal to $4 \div 5$ units when you have *EstimatedInertia* lower than 8 Jm
- set *KPp* equal to $2 \div 3$ units when you have *EstimatedInertia* higher than 8 Jm
- prefer lower values than *KPp* in case of increase of *EstimatedInertia*
- *KPp* can be reset, if it is not important to hold the position or you are going to control the motor only in the velocity modes;

3. System stabilisation

If, on the motor enabling or during a low velocity movement, the system is not stable, it's necessary to stabilize it before to proceed with the tuning. There may be many causes for the instability:

- Presence of a mechanical resonance with a constant frequency. In this case through the *Resonance estimator* it must be obtained the *EstimatedResonanceFrequency* and it is necessary to cut it off by using the *Resonance filter* or *Double resonance filter* options, in the *Gains calculation* Tab.

IMPORTANT

The Resonance filter or Double resonance filter options use is useful only if the *EstimatedResonanceFrequency* is constant (see Section 20.8, *Resonance estimator*).

- Too high gains, compared to the load mechanical characteristics (loads with an inertia moment greater than 5 Jm without friction or damping, not rigid mechanical transmission, presence of heavy backlash or tolerance on the mechanical transmission, ...).

In this case it's necessary to decrease the required dynamic performances by lowering the *DynamicResponse* option and/or decreasing the *InertiaReductionFactor* parameter value (try with 0.8, 0.5, 0.3; too low values of *InertiaReductionFactor* cut down the motor dynamic performances) and/or by selecting the *Debounce filter* option in the *Gains calculation* Tab.

If the operations that have been made in the *Gains calculation* Tab are not sufficient to stabilize the system, pay attention to what's reported in 4. *Filters*.

IMPORTANT

On every action performed in the Gains calculation Tab, repeat the point 2(PositionLoop inhibition).

4. Filters

The filters of the **VelocityLoop** should be used only if strictly necessary in order to cut off any eventual regulation noise or resonance. To evaluate the need of a filter, try to disable it or, in case it is a low pass filter, try to increase its cutoff frequency. The filters right configuration depends on the load and transmission mechanical characteristics. There is no systematic regulation method, but it is advisable to act on the three regulator filters and then on the feedback sensor filter.

V filters	
1:	Low pass 2nd order Frequency: 480 Hz
2:	Low pass 1st order Frequency: 350 Hz
3:	None Frequency: 2000 Hz
Sensor:	Block all Frequency: 0 Hz

Proceed with some trials and progressively define the strategy to improve the performances. Test the following strategies (some may not be effective):

- remove the **Band-eliminating filter**; select *Type None*
- insert a **Low-pass filter of the second order** as first filter and increase or decrease the frequency with steps of 50-100-200 Hz; if there are improvements with frequencies higher than 1800 Hz, maybe it's possible to remove the filter, by selecting *Type None*
- insert a **Low-pass filter of the first order** instead of **Low-pass filter of the second order** as first filter; look again for an optimal filter frequency
- enable the other two filters to increase and modify the filtering action
- increase or decrease the sensor filter frequency with steps of 50 Hz
- insert a **Low-pass filter of the first order** in place of **Low-pass filter of the second order** as feedback sensor filter
- search again for the filter frequency on the feedback sensor
- if a **Band-eliminating filter** is used, check its performance and modify its selectivity through the quality factor Q (for example, for the filter 2, by using the **VFilter2QFactor** parameter).




Figure 20.1. Response to the step where can be observed the start of a resonance, then damped.

ADVICE


In order to reduce the velocity ripple, in presence of sin-cos feedback sensors with a limited sinusoids per revolution number, or in presence of resolvers, it is advised to decrease the **AngleObserverBandwidth** parameter of 50-100Hz at a time even until reach values near 50Hz, for very slow dynamics.

If **VFilterSensorType** is a low pass filter and **AngleObserverBandwidth** is lower than **VFilterSensorFrequency**, try to disable **VFilterSensorType** because it probably hasn't any effect on the system.

Keep in mind that decrease **AngleObserverBandwidth** causes an increasing of the velocity overshoot. Try to find a compromise between the velocity ripple limitation and the overshoots increasing.

5. Velocity stand still

Activate the **EnableVelocityStandStill** option and, by moving the motor with low velocity (with low velocity is meant velocities that are lower than the 30% of the **HighSpeed** parameter), move the **VelocityStandStill** bar as much as possible toward **Stiffness**, in order to increase the motor quickness and stiffness. Moving the bar towards **Stability** eventual noises or resonances are attenuated. Don't move the bar to values lower than 20 units, because the quickness of the motor will be deteriorated.



6. Special parameters

If the resonances persist, modify the following parameters (not all of them are reported in the *Loops settings* Tab), while continuing to test the motor with low speed. Please refer to [Figure 27.1](#):

- modify **KVd**, even up to set it to 0. Also try to modify only the filtering action through the **KVdFilterFrequency** parameter
- decrease **WVd** and **WVp** even up to set them to 0

- progressively increase **KVc** in order to increase the damping effect, try with steps of 20-50-100 units.

7. Stopped motor

Run some stability tests when the motor is stopped in torque. If possible, disturb the mechanical load from outside with the motor stopped in torque to test the motor ability to absorb and dampen the resonances. In case of unwanted effects, try to modify the filters or the **VelocityStandStill** parameter (verify that the **EnableVelocityStandStill** option is enabled).

8. Quick decelerations

When the deceleration increases, the possibility to get resonances increases when the motor ends the deceleration ramp. Run some tests with the requested decelerations, in case of unwanted effects readjust the filters or the parameter **VelocityStandStill**. If the resonances at the end of the ramp persist, it's necessary to limit the required working decelerations.




Figure 20.2. Step answer in deceleration with limited overshoot without resonances and prompt error resetting.

9. Working speed

Proceed with tests with greater velocities, but never greater than the limits; start with a velocity equal to 50% of the **HighSpeed** parameter and increase the velocity over the required working velocity. The speed profile to generate can be the one the machine is designed for. In these tests modify the parameters **KVp** and **KVi**, with the following criteria:

- Increase **KVp** and **KVi** to make the system more quick, try with steps of 20% till the system becomes unstable. These parameters have greater effect for speeds higher than **HighSpeed** if the **EnableVelocityStandStill** option is enabled.
- decrease **KVp** and **KVi** to make the system more stable and eliminate the resonances, proceed with decreases of 20% until the system becomes stable. If the option **EnableVelocityStandStill** is enabled, these parameters have less effect for speeds low-

er than **HighSpeed**. If there are some resonances for speeds much lower than **HighSpeed**, readjust **VelocityStandStill** and the filters.

Velocity loop			
KVp:	<input type="text" value="100"/>		
KVi:	<input type="text" value="100"/>	Acceleration feed forward:	<input type="text" value="1.000"/>
KVd:	<input type="text" value="54"/>	KVd filter frequency:	<input type="text" value="15000"/>

NOTE

If the movement noise level or the noise that's overlapped to **VelocityActualValue** don't have reached the desired levels, it's necessary to work again on the regulator filters and parameters. Check that the noise cause is not due to the noise present in the velocity reference (**RequestedSpeed**).




Figure 20.3. Step answer with acceptable overshoot without resonances and prompt error resetting.

10. Feed forward acceleration

To adjust the parameter **KAff** move the motor by commanding accelerations and decelerations similar to the machine working ones. Increase or decrease **KAff** in order to minimize **SpeedFollowingError** during the acceleration and deceleration ramps. If **FeedForwardAcceleration** is noisy, it may be useful to reset to zero **KAff** in order to reduce the noise that enters in the loop. If it's not necessary to tune the *PositionLoop*, then the tuning is finished.





Figure 20.4. Sign change of *SpeedFollowingError* at the ramp beginning: *KAff* too high.

11. PositionLoop (low velocities)

When the *VelocityLoop* is tuned in the best possible way, the *PositionLoop* tuning becomes very easy. Execute some movement with position reference with speeds lower than **HighSpeed** and with the motor stopped in torque, in order to check the following tuning operations:

- Push the *Recalculate* button in the *PositionLoop* area
- activate the **EnablePositionStandStill** option and modify **PositionStandStill** by valuing the effects on the **PositionFollowingError**. Increase its value to increase the resetting speed of the **PositionFollowingError**; decrease its value to eliminate not damped oscillations at low speeds. With the bar at 0, **PositionFollowingError** is not controlled



12. PositionLoop (high velocities)

Proceed with tests with greater velocities, but never greater than the limits; start with a velocity equal to 50% of the **HighSpeed** parameter and increase the velocity over the required working velocity. The position profile that has to be generated should be the one the machine is made for. Check the following tuning operations:

- set the value of **KPp** equal to the value of **PositionStandStill**

- modify **K_{Pp}** by valuing the effects on the **PositionFollowingError**. The effect of this parameter is greater for velocities higher than **HighSpeed**. Increase its value in order to maintain low the **PositionFollowingError**; decrease its value if vibrations or resonances appear
- check if **PositionLoopEstimatedBandwidth** is lower at least 0.7 times **VelocityLoopEstimatedBandwidth**.

20.6. Function Generator



WARNING

Before enabling the Function Generator when the drive is not adjusted yet, check if it is possible to stop the motor in safety. To avoid unwanted motions or collisions, take all the necessary precautions and configure precisely the drive limits (**Chapter 19, Motion limits**).

The Function Generator is an integrated functionality of the MotionDrive oscilloscope applying some particular references to the control loops. When a Function Generator command is requested, the oscilloscope capture is enabled to value the drive performances through the analysis of the progress of some particular parameters.

Access:

Main menu > Drive > Loops settings and tuning > Function Generator Tab

Toolbar >  > Tab Function Generator

Channels | Loops settings | **Function generator** | Fast tuning | Gains calculation | Tuning current | Resonance estimator | Inertia estimator

1. Activate enable input if it is present.
2. Select the function generator: Profile position
3. Select the reference: Relative, single target position
4. Set the parameters:

Profile target position	8000	inc
Profile velocity	382	rpm
Profile acceleration	1273240	inc/s ²
Profile deceleration	1273240	inc/s ²

Tuning end option: Deceleration ramp and previous state

Tuning end deceleration: 1273239 inc/s²

Start Stop Disable End

Position: 0 inc Drive status: Drive information: No error

Save all parameters Help Close

In the following table you can find the Function Generator functionalities:

Functionalities	Description	
Select the Function Generator	Choose the Function Generator type	CurrentLoop D applies to RequestedField the generated reference
		CurrentLoop Q applies to RequestedTorqueCurrent the generated reference
		Speed loop applies to RequestedSpeed the generated reference
		Profile velocity generates a speed motion with linear acceleration ramps
		Profile position runs some positionings with linear acceleration ramps
Load presets	Set some default values for the selected reference and the oscilloscope	
Select the reference	Select the reference type	Stop
		Step
		Step (time limited)
		Square wave
		Square wave (time limited)
		Sinusoidal wave
		Sinusoidal wave (time limited)
		Profile velocity unlimited standard
		Profile velocity time limited
		Profile velocity time limited, forward and backward, single sequence
		Profile velocity time limited, forward, multiple sequence
		Profile velocity time limited, forward and backward, multiple sequence
		Profile position, absolute target position
		Profile position, relative, single target position
		Profile position, relative, forward and backward, single sequence
Profile position, relative, forward, multiple sequence		
Profile position, relative, forward and backward, multiple sequence		
Start	Start the reference	
Stop	Stop the reference and keep the drive enabled	
Disable	It ends the Function Generator by stopping the motor with maximum deceleration and resetting RequestedSpeed and then the drive enters the <i>Switch On Disabled</i> status	
End	End the Function Generator following Tuning end option	
TuningEndOption	Options for the Function Generator end command	Immediately disable, the motor is stopped with maximum deceleration resetting RequestedSpeed to zero and then the drive has the <i>Switch On Disabled</i> state
		Deceleration ramp, the motor is stopped with deceleration equal to Tuning end deceleration
		Zero speed, the motor is stopped with maximum deceleration by resetting RequestedSpeed
TuningEndDeceleration	Deceleration for the Function Generator end command	
Drive status	Drive status (Statusword)	
Drive information	Function Generator status (SysMngError)	

When using the Function Generator, bear in mind as follows:

1. it is not possible to change Function Generator without using the End command
2. to modify the reference type or the reference parameters, when a reference is started, you have to use a command of Stop, End or Disable

3. before starting a reference, set its parameters and Tuning end option and Tuning end deceleration
4. at the references end, that end after a given period, the drive is always enabled
5. the references of time limited type end after a time period equal to the parameter Duration
6. the references of sequence type generate some profiles which are separated among them by a time period equal to the parameter Profile interval
7. when a reference is started and you close the window Oscilloscope, the End command is run
8. if the motor can run motions only in one direction, set properly the reference parameters
9. if the requested reference ends before the end of the answer transient, increase properly the reference parameters to increase its duration




Figure 20.5. Example of reference concluding before the end of the speed transient.

10. if the oscilloscope capture ends before the Function Generator has finished and it does not show all the reference and answer progress, increase the oscilloscope sampling time.




Figure 20.6. Example of too short capture ending before the Function Generator has finished.

20.7. RL estimator

To optimize the current loop performances it's necessary to estimate the effective value of the phase resistance and of the synchronous motor inductance. *RL Estimator* executes an offline estimation of these parameters through the application of some ramps and pulses of current to the motor phases. During the RL estimation command the drive may move the motor shaft up to 1 polar step. According to the estimated inductance value (see [RL Estimator](#) group parameters), the parameters of the speed and position loops are calculated again.

NOTICE

During the RL estimation, the motor is free to move. Therefore, in case of vertical load or relevant disturbing forces on the load, the estimation should be executed unmounting the motor and without mechanics and not with the motor connected to the machine mechanics.

IMPORTANT

The [EstimatedPhaseResistance](#), [EstimatedLDNominalP](#), [EstimatedLDNominalN](#), [EstimatedLDPeakP](#), [EstimatedLDPeakN](#), [EstimatedLQNominalP](#), [EstimatedLQNominalN](#), [EstimatedLQPeakP](#), [EstimatedLQPeakN](#) parameters cannot be downloaded through the parameters file because they are specific for every axis. On the contrary, the parameters file download reset them to the default value.

To estimate RL follow the instructions reported in the *RL Estimator* area in the *Tuning current* Tab.

Access with MotionDrive:

Main menu > Drive > Tuning ... > Tab Tuning current

Toolbar >  > Tab Tuning current

Channels | Loops settings | Function generator | Fast tuning | Gains calculation | Tuning current | Resonance estimator | Inertia estimator


RL estimator

1. Make sure that motor is free to turn and not moved by mechanical load.
2. Supply the drive with rated DC bus voltage.
3. Activate enable input if it is present.
4. Press the Start button.
5. Wait disable motor.

Motor phase resistance:	<input type="text" value="1.250"/> ohm	KC_Q reduction:	<input type="text" value="0.000"/>
Estimate phase resistance:	<input type="text" value="1.272"/> ohm	Over specific energy (I2T):	<input type="text" value="0 %"/>
Motor synchronous inductance:	<input type="text" value="8.74"/> mH		
Estimated synchronous D inductance (In+):	<input type="text" value="8.14"/> mH	Estimated synchronous Q inductance (In+):	<input type="text" value="8.47"/> mH
Estimated synchronous D inductance (In-):	<input type="text" value="9.89"/> mH	Estimated synchronous Q inductance (In-):	<input type="text" value="8.04"/> mH
Estimated synchronous D inductance (Ipk+):	<input type="text" value="6.33"/> mH	Estimated synchronous Q inductance (Ipk+):	<input type="text" value="8.76"/> mH
Estimated synchronous D inductance (Ipk-):	<input type="text" value="10.39"/> mH	Estimated synchronous Q inductance (Ipk-):	<input type="text" value="8.63"/> mH

Position: inc Drive status:

Drive information:

 NOTICE

During the RL estimation the **I2TValue** value, that can be read in the "Over specific energy (I2T)" box of the same page, increases. Always wait that it takes the 0 value.

The end of the RL estimation command, coincides with the automatic disabling of the motor. Always wait its disable.

IMPORTANT

Considering that the current pulses reach **MotorPeakCurrent**, be sure that the voltage supply **DCBusVoltage(+HV)** remains stable during the command.

ADVICE

To correctly estimate RL follow the instruction list in the Tuning current Tab.

NOTE

The oscilloscope is not activated because a video diagnostics is not necessary. The results are reported in the Tuning current Tab.

20.8. Resonance estimator

The *Resonance Estimator* serves to evaluate if some mechanical resonances with *constant frequency* are present. Through the application of a variable torque, with null average, with maximum amplitude of **EstimatorTorque**, in order to generate a controlled vibration, the drive obtains and shows the frequency response of the mechanical load and determines **EstimatedResonanceFrequency**. The main chart reading purpose is to point out the even-

tual resonance peaks, their frequency and their band width. The resonance peak can be eliminated by setting a band-stop filter with the peak central frequency.

IMPORTANT


During the mechanical resonances estimation, the motor is free to move. Therefore, in case of vertical load or relevant disturbing forces on the load, the estimation cannot be executed.

For a correct estimation of **EstimatedResonanceFrequency** follow the instructions reported in the *Resonance estimator* Tab:

Access with MotionDrive:

Main menu > Drive > Tuning ... > Tab Resonance estimator

Toolbar >  > Tab Resonance estimator



ADVICE


Try with different values of **EstimatorTorque**.

According to the machine structure and typology, try by positioning the load that's connected to the motor, in different positions of the working cycle.

IMPORTANT

If when the **EstimatorTorque** value or the axis position change, the resonance frequency peak moves in the chart for a significant quantity, don't use the Resonance filter or Double resonance filter options, in the Gains calculation tab, because a band-stop filter is not sufficient to cut off the resonance.

NOTE



To read more precisely the value of the frequency peaks showed on the chart, drag and drop the red cursor to the desired position.

20.9. Inertia estimator

⚠ WARNING

Before to activate the Inertia estimator, be sure that the motor can be safely stopped. To avoid unwanted motions or collisions, take all the necessary precautions and configure precisely the drive limits ([Chapter 19, Motion limits](#)).

The *Inertia estimator* executes a controlled movement of the motor in order to estimate the total inertia moment, calculating according to the motor shaft. The estimated inertia moment (Total [EstimatedInertia](#)) is used to automatically calculate the parameters of the speed and position loops. Follow the instructions reported in the *Inertia estimator* Tab.

IMPORTANT

In case of vertical load or relevant disturbing forces on the load, the estimator produces wrong results. Its use is not recommended.

Access with MotionDrive:

Main menu > Drive > Tuning ... > Tab Inertia estimator

Toolbar >  > Tab Inertia estimator

1. Options selection

- *I can move the motor shaft of 10rev* must be activated if the system mechanics allows the motor to safely move for 10 revolutions. This option requires more accurate the estimation of [EstimatedInertia](#). If the motor can move for no more than a quarter of revolution, it's anyway possible to proceed with the estimation without selecting this option. If, instead, it's absolutely not possible to move the motor, the estimation can't be executed.
- *Direction of tuning movement* is used to select the direction of the movement of the motor during the estimation.
- *Load presets* automatically sets the oscilloscope for a correct estimation evaluation.
- [TuningEndOption](#) and [TuningEndDeceleration](#) define the operation that are executed when the *End* button (command 100 of the [System Manager](#)) is pressed or at the end of the tuning movement.

2. Movement limits selection

If necessary set the movement limits according to what's reported in [Chapter 19, Motion limits](#) and insert the [InertiaEstimatorVelocity](#) and [EstimatorTorque](#) values that will be used during the estimation. In most cases it is not necessary to modify the default values of these two parameters.

3. Estimation movement

By pressing the *Start* button the estimation procedure starts, and automatically stops when the progress bar disappears. Then, check that there are no anomalies reported in the *Drive*

information field. If the *Load presets* button has been pressed, the oscilloscope automatically shows the trend of some variables that are important to evaluate the estimation quality.

4. Advised procedure to estimate the inertia moment

- If possible, select the *Extended movement* option. Select the estimation direction and push *Load presets*.
- Set the motor in order to run the requested motion. Take all the necessary precautions and configure precisely the drive limits ([Chapter 19, Motion limits](#)).




Figure 20.7. Example of speed and position progress obtained through the selected option *Extended movement* (*EncoderIncrements* is 8000 inc/rev).

- Press *Start*.
- When the movement is finished, control the informations that are reported in the *Drive information* field.
- Unselect the *Extended movement* option.
- Position the shaft so that it is possible to run the requested motion and check if the shaft reaches the machine position limits.
- Press *Start*.
- When the movement is finished, control the informations that are reported in the *Drive information* field.
- Check if the result of the estimate Total *EstimatedInertia*, is approximately coherent with the applied load.
- Run for some times the tuning command by starting from the point f and check if the estimation does not sensibly change. Variations of 10-20% can be tolerated.

ADVICE

In case of heavy friction, increase *EstimatorTorque* up to the nominal value.

5. Inertia moment estimation verification

To verify the estimation, use the oscilloscope. If the *Load presets* button has been pushed, the oscilloscope is automatically set for this aim.

During the first phase of the estimation, while the torque step is applied, the velocity should be a linear ramp (with the *Extended movement* option unselected).

ADVICE

In general, if there are some vibrations during their first phase of the estimation, try to repeat decreasing the value of **EstimatorTorque**.

In order to limit the velocity and the position reached during the estimation, the **InertiaEstimatorVelocity** value can be decreased.

In case of transmission with chains, backlash or plays, reduce the value of **EstimatorTorque** in order to maintain as linear as possible the velocity ramp, during the first step of the estimation.

- During the first phase of the estimation, the more the velocity ramp is linear the better the estimation is (see the following figure).




Figure 20.8. Example of a correct estimate of the inertia moment.

- If there are vibrations during the first phase of the estimation, but the velocity profile is quite a linear ramp, specially in the final part of the ramp, the estimation can be considered reliable (see the following figure). Consider however, during the tuning, a possible presence of mechanical elasticities of the load (see [Section 25.8, Tuning problems](#)).




Figure 20.9. Example of a correct estimation of the inertia moment with vibrations.

- If there are some heavy vibrations during their first phase of the estimation, it's probable that the mechanical transmission is too elastic (see the following figure). In this case the estimation is not reliable and it is necessary to make the correct operations during the tuning (see [Section 25.8, Tuning problems](#)).




Figure 20.10. Example of a not valid estimation, with not rigid mechanical transmission.

- During the first phase of the estimation, when there is backlash in the transmission, the velocity will rise rapidly and then decrease, and may even reverse direction when the transmission engages. If this velocity "bounce" lasts for the entire first phase, then the estimation is not reliable (see the following figure). In any case it's necessary to consider the presence of this behaviour during the tuning (see [Section 25.8, Tuning problems](#)).




Figure 20.11. Example of a not valid estimation due to backlashes in the transmission.

6. Verification of the tuning configuration, calculated by the inertia moment estimator

The second phase of the estimation is a quick stop of the motor, that uses the loop parameters that have been recalculated according to the measured value of Total *Estimated Inertia*. evaluating this phase, we can get the following conclusions:

- If the stop has a behaviour similar to the one that's reported in [Figure 20.8](#), so without vibrations, without noise and with a little and immediatly damped overshoot, then the velocity loop tuning is finished without problems.
- Otherwise, if the stop presents a behaviour similar to the one that's reported in [Figure 20.9](#), so with little and immediatly damped vibrations, the system is however stable and it's better to improve its stability (see the points [3. System stabilisation](#) and [4. Filters](#) of the *Detailed Tuning Guide*).
- At last, if the stop presents a behaviour similar to the one that's reported in [Figure 20.10](#), so with wide and persistent vibrations, the system is unstable and it has to be stabilized (see the points [3. System stabilisation](#) and [4. Filters](#) of the *Detailed Tuning Guide*).

Chapter 21

Saving, restoring or cloning the drive configuration.

21.1. Drive configuration

By *configuring the drive* it is meant to configure all the parameters of the vocabulary. The drives of the series *iBMD* provide some commands to manage in an organic way (not only according to a single parameter) the current configuration. The configuration management of the drive is summarized in the following image.




Figure 21.1. Commands for the configuration management of the drive.

Command	System Manager	Description
Save/Export parameters file	MotionDrive reserved	Saving the current configuration on parameter files
Import parameters file	MotionDrive reserved	Updating the current configuration with all the data in a parameter file (mode Offline)
Download parameters file	MotionDrive reserved	Updating the current configuration with all the data contained in a parameter file (mode Online)
Save all parameters	2001	Saving the current configuration in the drive permanent memory
Restore default parameters	2200	Updating the current configuration and the permanent memory with the default values
Reset to defaults	2201	Updating the current configuration with the default values
Reload all parameters	2300	Updating the current configuration with all the data in the permanent memory
Reload value of loops parameters and tuning configuration	2301	Updating the loops parameters and the TuningConfigurations with the values in the permanent memory


Command	System Manager	Description
Hard reset	5000	It's equivalent, for all parameters, to switching off and restarting the drive
Soft reset	5001	It's equivalent, for all parameters, except for the Non-resettable parameters , to switching off and restarting the drive


21.2. Saving/Exporting parameters file

To export the drive parameters on a file, in order to save them in an archive or download them in other drives, please follow this procedure. Access with MotionDrive:

Main menu > Drive > Save/Export parameters...


Toolbar > 

Choose the directory and the name of the destination file in the window Export parameters and press .




Some problems that may occur while exporting the parameters

1. If there is an error in reading one or more parameters, the user is informed through a notice, as the one shown in the following window, that contains the list of the errors.



In this case it is better:

- i. to update MotionDrive and the configuration files ([Section 26.1, MotionDrive updating](#))
 - ii. to update the firmware with the latest available version ([Section 26.3, Firmware updating](#))
 - iii. to interpret the error details ([Section 8.4, Errors in reading / writing of the parameters](#))
2. If case of downloading in a drive a parameter file generated with a firmware that's older than the actually installed one, the user is informed through a notice, as the one shown in the following window, that contains the list of the missing parameters.



In this case it is sufficient to:


- i. confirm and proceed with the downloading of the parameter file, even if it is incomplete
- ii. save a new parameter file, that will be in this way generated compatible with the firmware that's actually installed and includes the parameters that have just been downloaded.


21.3. Downloading parameters file

To update the drive parameters with a previously created parameters file, please use the following procedure. Access with MotionDrive:

Main menu > Drive > Download parameters file...

Toolbar > 

Choose in the window Download parameters file the parameters file to download in the drive and press .




NOTE

The parameters downloaded in the drive are not automatically saved in the internal permanent memory.

Some problems that may occur while downloading the parameters

1. If the following window appears, it means that this function is not available because of the firmware version that's installed in the drive. In this case it is necessary to update the firmware ([Section 26.3, Firmware updating](#)).





21.4. Importing parameters file

To change the parameters file during the **Offline** mode, please follow this procedure. Access with MotionDrive:

Main menu > Drive > Import parameters file...

Toolbar > 

Choose in the window Import parameters file, the directory and the file name to import and press .



NOTE

Any changes in the imported parameters file are not automatically saved in the file. To save changes in the parameters file in Offline mode, use the **Save/Export parameters file** command.

21.5. Compare parameters file

The MotionDrive environment provides an instrument to compare 2 parameters files. This method can be even used to verify the differences between the currently configured parameters and the default configuration. Access with MotionDrive:

Main Menu > Drive > Compare parameters ...





Figure 21.2. Compare of 2 parameters

Here follow the steps to execute the compare function:

1. Insert in the *File1* field the reference parameters file (.xml).
2. Insert in the *File2* field the parameters file (.xml) that you want to compare.
3. If a difference appears in the window, click on it to read its details in the text area on the bottom.
4. If you modify a file, click on the *Refresh* button to update the comparing.
5. To export the differences, click on the *Export* button and select the exportation mode:



- a. *Full Text Exportation*: to export in a ".txt" file the list of data of every parameter that results different or not present (in one of the two files) after the comparing.
- b. *Parameters to config*: in order to export in a ".txt" file the list of the data, referring to the file that's inserted in the *File2* field, that are necessary to write the parameters in the drive through a NON Bonfiglioli master: Modbus addresses CAN, Parameters name and Priority¹.

¹The priority value is used to determine the writing order of the parameters. A parameter with a lower priority value must be written before, while a parameter with a higher priority value must be written after. The parameters with the same priority value can be written in any order.

IMPORTANT

The files that have been obtained with the export operation ARE NOT PARAMETERS FILES (therefore they cannot be directly downloaded in the drive through MotionDrive), but only simple text files, that contain the list of the differences between the 2 parameters files. The purpose of those files is, as well as to list the differences, to provide the data that are necessary to write in the drive, through a NON Bonfiglioli master, the parameters that result different after the comparing.

NOTE

If you want to compare a parameter file with the actual drive parameterization, it's sufficient to load the first one and to use the "Read Online" function for the second one. This function creates a temporary file that will be used to compare operation and that will be automatically deleted on the Compare window closing action.




Figure 21.3. Compare of a parameter file with the current drive parameters.

21.6. Parameters cloning

For *cloning* it is meant the copy of only the configuration parameters from a drive to another one. It will be not executed any firmware update.

NOTICE

The cloning procedure is guaranteed only if the two drives have the same firmware version. If the drives are not aligned, you have to update the drives with the desired firmware version.

To clone the parameters of a iBMD series drive there are two procedures, depending on the instrument that you want to use:

Parameters cloning with MotionDrive

1. Connect to the drive that has to be cloned and export the parameter file (see [Section 21.2, Saving/Exporting parameters file](#)).
2. Connect to the drive that has to be configured and import the saved parameters file (see [Section 21.3, Downloading parameters file](#)).

Cloning of the parameters with Master

In this case, in order to clone the parameterization of a system in another one, the Compare procedure has to be used (see [Section 21.5, Compare parameters file](#)). In order to do this it's necessary:


1. Save the actual parameters file from the drive to be cloned (see [Section 21.2, Saving/Exporting parameters file](#)).
2. Restore the default values in the drive to be cloned (see [Section 21.7, Permanent memory](#) or else with the command 2200 of the [System Manager](#)).
3. Save the parameter file with the default values and insert it in the *File 1* field (or use the "Read Online" function).
4. Load the parameter file, related to the point 1, in the *File 2* field.
5. Export in a text file the results of the comparing by using the option *Parameters to config*.
6. Restore the default parameters in the drive to be configured (see [Section 21.7, Permanent memory](#) or else with the command 2200 of the [System Manager](#)).
7. Use the data contained in the exported file to write in the Master the instructions to write the parameters that has to be modified.
8. Proceed with the parameters writing in the drive through Master.

21.7. Permanent memory

Management of the current configuration with the permanent memory. Access with MotionDrive:

Main menu > Drive > Permanent memory...

Toolbar > 



To save the current configuration in the drive permanent memory, press

Save parameters in permanent memory

(available also in Drive setup) or use the command 2001 of [System Manager](#).

To update the current configuration and the permanent memory with the default values,

Restore default parameters

press or use the command 2200 of [System Manager](#).

To update the current configuration with the data in the permanent memory, press

Reload all parameters

or use the command 2300 of [System Manager](#).

To update only the loops configuration with the data in the permanent memory, press

Reload loops parameters

or use the command 2301 of [System Manager](#).

IMPORTANT

It is not necessary to reboot the drive for the new parameters resulted from Reload and Restore commands of the permanent memory to take effect.

21.8. Resetting

The drives of the iBMD series provide different reset levels. Access with MotionDrive from **Main menu > Drive**.

Command	System Manager	Reset-Cause	Description
Hard reset	5000	2	It's equivalent, for all parameters, to switching off and restarting the drive
Soft reset	5001	6	Except for the Non-resettable parameters and the Non-resettable on the reset parameters , it is the same as a turn off and on again of the drive
NMT reset	-	5	Except for the Non-resettable parameters and the Non-resettable on the reset parameters , it is the same as a turn off and on again of the drive. It can be run only in the CAN drive version and only with the NMT command (see Node control services).
Reset to defaults	2201	-	Updating the current configuration with the default values. The Reset-Cause does not change.

Non-resettable parameters

The *not resettable parameters* do not change when in the drive it is used a [Soft reset](#), [NMT reset](#) or [Reset to defaults](#) command. They are:

- [PositionActualValue](#).
- [HomingStatus](#).

WARNING

If the feedback sensor is incremental and if during the firmware reset the motor moves more than a half of revolution, the drive does NOT keep in memory these parameters.

 WARNING

If the feedback sensor is absolute and if during the firmware reset the encoder position is between its range limits, then these parameters are always kept in memory.

 WARNING

in case the **FeedbackSensorAbsMode** or **FeedbackSensor-Code** parameters value is modified, these parameters are reset.

Non-resettable on the reset parameters

The *Non-resettable on the reset parameters* are not modified if the drive receives a **Soft reset** or a **NMT reset** command. They are:

- **EncoderIncrements**.
- **Polarity**.

 WARNING

In case the sensor is incremental (or the **FeedbackSensorAbsMode** parameter make it work in this way), the modification of one of these parameters causes the reset of the **HomingStatus** parameter and of the executed homing procedure.

Enabled parameters after reset

The *enabled parameters after reset*, once written and saved in the drive permanent memory, take effect only after the **Hard reset**, **Soft reset**, **NMT reset** command or after the drive switching off and restarting. They are:

- **CANopenPortSwitchSetup**;
- **CANopenPortSetupNodeID**;
- **CANopenPortSetupBaudRate**;
- **AuxiliaryPortSetupBaudRate**;
- node number and baud rate set by dip switch (see [Section 7.4, Dip switches](#)) in the drive version CAN;
- **Configured station alias** in the drive version ETC.

Chapter 22

Creating a motion

Using the drives of the *iBMD* series, the motor motion can be commanded through:

- [Master](#) with CANopen or EtherCAT port that supports the CoE protocol ("[CANopen over EtherCAT](#)")
- PLC integrated in the drive
- digital inputs and outputs + drive analog input

The drive makes it possible to carry out motions by controlling the torque, the speed and the motor position according to the operating mode set in the parameter [ModesOfOperation](#). In the following chart you can find the features of the available operating modes. To learn how to command and control the motor motion, or how to enable, disable and stop the motor, or how to change the [ModesOfOperation](#), please follow the instructions in the next paragraphs of this chapter.

Type of motion	ModesOfOperationDisplay	Paragraph	Standard CiA-402	Re-al-time	Digital I/O	Analog input	Enable automatic
Position	<i>Profile Position Mode</i>	Section 22.9, Profile Position Mode	YES	-	-	-	-
	<i>Interpolated Position Mode</i>	Section 22.10, Interpolated Position Mode	YES	YES	-	-	-
	<i>Cyclic Synchronous Position Mode</i>	Section 22.11, Cyclic Synchronous Position Mode	YES	YES	-	-	-

Type of motion	ModesOfOperationDisplay	Paragraph	Standard CiA-402	Re-al-time	Digital I/O	Analog input	Enable automatic
Velocity	Profile Velocity Mode (CiA402)	Section 22.14, Profile Velocity Mode (CiA402)	YES	-	-	-	-
	Profile Velocity Mode (CUSTOM)	Section 22.15, Profile Velocity Mode (CUSTOM)	-	-	-	-	-
	Profile Velocity AI Mode	Section 22.16, Profile Velocity AI Mode	-	-	-	YES	YES
	Cyclic Synchronous Velocity Mode	Section 22.12, Cyclic Synchronous Velocity Mode	YES	YES	-	-	-
Torque	Torque Mode	Section 22.17, Torque Mode	YES	-	-	-	-
	Torque AI Mode	Section 22.18, Torque AI Mode	-	-	-	YES	YES
	Cyclic Synchronous Torque Mode	Section 22.13, Cyclic Synchronous Torque Mode	YES	YES	-	-	-
Other	Homing Mode	Section 22.19, Homing Mode	YES	-	-	-	-

Table 22.1. Features of the operating modes and modes of generation of the references.

IMPORTANT

To command the drive by using any **Master**, it's necessary to know and use the CiA402 State Machine, which characteristics are reported in [Section 8.5, CiA402 state machine](#).

22.1. Enabling by using the master

To enable the drive it's necessary to set the CiA402 State Machine to one of these 2 states:

- [Operation enable](#)
- *Switched On* (only if [SwitchedOnOptionCode](#) value is 1)

To enable the motor movement, set the CiA402 State Machine to the [Operation enable](#) state (see [Section 8.5, CiA402 state machine](#)). In the [Operation enable](#) state the changing of the operative mode is allowed both using the on-the-fly mode change (please see [Section 22.5, On-the-fly operative mode change](#)) and through the parameter [ModesOfOperation](#).

Access with MotionDrive:

Main menu > Drive > Drive enable

Toolbar > 

IMPORTANT

To enable the drive, the [EnableInputStatus](#) parameter must be equal to 1.

22.2. Disabling by using the master

To disable the drive it is necessary to execute one of the following two operations:

- if the [SwitchedOnOptionCode](#) parameter value is 0, set the CiA402 State Machine to the *Switched On* state (see [Section 8.5, CiA402 state machine](#))
- set the CiA402 State Machine to the *Switch On Disabled* state (see [Section 8.5, CiA402 state machine](#)). Through this operation it is possible to disable also the motor motion.

Access with MotionDrive:

Main menu > Drive > Drive disable

Toolbar > 

To only disable the motor movement without disabling the drive is only possible if the [SwitchedOnOptionCode](#) parameter value is 1. In this case it's sufficient to set the CiA402 State Machine to the *Switched On* state (see [Section 8.5, CiA402 state machine](#)).

⚠ ATTENTION

If the drive is in **Operation enable** and the motor is in motion, the disabling operations causes the motor stop with maximum deceleration by setting **RequestedSpeed** to zero. Before starting a disabling operation, it is recommended to stop the motor motion by using the procedures described in [Section 22.3, Carrying out a stop by using the master](#).

22.3. Carrying out a stop by using the master

To stop the motor when the drive is in the **Operation enable** state and with any **ModesOfOperation** enabled, it is possible to run a stop command. The two stop commands implemented in the drive follow the specifications of **CiA-402** and they are:

- *Halt*: stop command which carries out a braking ramp with a **ProfileDeceleration** deceleration. The stop ramp starts from the **RequestedPosition** and **RequestedSpeed**, without nullify **PositionFollowingError** and **SpeedFollowingError**;
- *Quick stop*: stop command which carries out a braking ramp parametrized according to the **QuickStopConfiguration** parameter. The braking ramp starts from the **VelocityActualValue** value, setting to zero **SpeedFollowingError** at the beginning of the ramp.

ADVICE

Use the command **Halt** for a normal stop and the command **Quick stop** for an emergency braking.

The stop execution can be commanded through the **Controlword** and the state of the CiA402 State Machine can be checked with the **Statusword** (see [Section 8.5, CiA402 state machine](#)).

Access with MotionDrive to parametrize the stops:

Main menu > Drive > Drive setup ... > Control mode

Toolbar >  **> Control mode**

Quick stop:

Quick stop deceleration: inc/s² Quick stop configuration:

Profile deceleration:

inc/s²

22.4. Change the operative mode with CiA-402 standard parameters

This type of operative mode change follows the [CiA-402](#) specifications. To execute the operative mode change it's necessary to write the [ModesOfOperation](#) parameter; by reading the [ModesOfOperationDisplay](#) it's possible to check the active operative mode.

NOTICE

In the **Operation enable** state it's possible to change [ModesOfOperation](#) only if the bit 4 of the [Controlword](#) is set to 0 (see [Section 8.5, CiA402 state machine](#)). The operative mode change, with this method, must be done with the motor stopped, and it's user's responsibility to be sure of this condition.

Motor and drive | Brake | Polarity | Digital I/O | Analog input | Captures | Limits and windows settings | Control mode | Loops settings | Homing | Errors

Mode of operation:

Input reference: Operating mode:

In the frame *Mode of operation* choose the source of the reference in the pull-down menu *Input reference* and the operating mode in the pull-down menu *Operating mode*.

NOTE

The change of [ModesOfOperation](#) is not allowed in the states Not Ready to Switch On, Quick Stop Active and Fault Reaction Active.

22.5. On-the-fly operative mode change

NOTE

The change [ModesOfOperation](#) in **Operation enable** is currently available only writing the parameters of additional bus Modbus.

This kind of mode change is also called makes possible to move from any operative mode to another one without stopping the motor and keeping the drive in **Operation enable**. The operating modes allowing the change are:

- *Profile Position Mode*;
- *Homing Mode*;
- *Interpolated Position Mode*;
- *Profile Velocity Mode (CUSTOM)*.

The management of the on-the-fly mode change can be parametrized and commanded by using the following parameters.

Parameter	Description
ApplyModeOperationCommand	Desired operating mode
ApplyModeOperationStatus	Status of the operating mode change
ApplyModeOperationParameters and following ones	Group of 7 parameters to set the mode change. The meaning of each of these parameters changes when ApplyModeOperationCommand changes, as shown in Table 22.2 .

N. par.	<i>Profile Position Mode</i>	<i>Homing Mode</i>	<i>Interpolated Position Mode</i>	<i>Profile Velocity Mode (CUSTOM)</i>
1	TargetPosition	HomingMethod	IpPosFirstParameter	TargetVelocity
2	ProfileVelocity	SpeedForSwitch	IpPosSecondParameter	-
3	EndVelocity	SpeedForZero	-	EndVelocity
4	ProfileAcceceleration	HomingAcceleration	IpPosSubModeSelect	ProfileAcceceleration
5	ProfileDeceleration	IndexPulseDeadZone	-	ProfileDeceleration
6	EndIncrements	HomeOffset	-	-
7	StartVelocity	-	-	StartVelocity

Table 22.2. Meaning of the [ApplyModeOperationParameters](#) parameters.

NOTE

The writing of this group of parameters follows the same writing restrictions as the single parameters in their original addresses.

To start a change of the on-the-fly operating mode the drive must be in [Operation enable](#). Run this operations sequence:

1. Configure the change of the operating mode by properly setting [ApplyModeOperationParameters](#).
2. Write the code of the new operating mode in [ApplyModeOperationCommand](#).
3. Verify the result of the change by reading the parameter [ApplyModeOperationStatus](#).

For some values of [ApplyModeOperationCommand](#), there can be some peculiarities. Here follow them:

- **Profile Position Mode**

With the functionality on-the-fly mode change, the *Profile Position Mode* runs positions **absolute** in mode **Single set-point**. For details on the operating mode please see [Section 22.9, Profile Position Mode](#).

22.6. How to control a motion in position

In the drives of the series *iBMD* some functionalities (common to all position modes) have been implemented and through these it is possible to check if the motion is run in conformity with the parameterization made by the user.

Position

To check the motor position, read the parameter [PositionActualValue](#).


Position reached target

If in [ModesOfOperationDisplay](#) a position mode is set, to check if the motor reached its final position it is sufficient to check if the bit *Target reached* della [Statusword](#) is equal to 1. Such bit is set when the difference between [PositionActualValue](#) and the requested position is below [PositionWindow](#) (in absolute value) for a time at least equal to [PositionWindowTime](#). The bit is reset when the difference gets over the window.

Access with MotionDrive:

Main menu > Drive > Drive setup ... > Limits and windows setting

Toolbar >  > Limits and windows setting



Position window	
Value:	<input type="text" value="0"/> position
Time:	<input type="text" value="10"/> ms


Error of position tracking

If in [ModesOfOperationDisplay](#) a position mode is set, it is possible to check the [PositionFollowingError](#) during the motor motion. Properly configuring the [FollowingErrorWindow](#) and [FollowingErrorWindowWarn](#) parameters it's possible to activate the [Position following error](#) (Fault and Warning respectively), if the [PositionFollowingError](#) exceeds the window for a time greater or equal to [FollowingErrorTimeOut](#). Furthermore, in some operating modes, when [PositionFollowingError](#) exceeds the Fault threshold for a time at least equal to the time out, also the *Following error* bit of [Statusword](#) is set. The bit is reset when [PositionFollowingError](#) is lower, in absolute value, than the Fault window. For any further information on the error notice please see [Chapter 24, Fault and Warning](#).

Access with MotionDrive:

Main menu > Drive > Drive setup ... > Limits and windows setting

Toolbar >  > Limits and windows setting



Following error					
Fault threshold:	<input type="text" value="512000"/> inc	Warning threshold:	<input type="text" value="512000"/> inc	Time:	<input type="text" value="0"/> ms

22.7. Control of a speed motion

In the iBMD series drives have been implemented some functionalities (common to all the velocity modes) that permit to control if the movement is executed according to the user parametrization.

Speed

To check the motor speed you can use the only-reading-parameter [VelocityActualValue](#).

Speed target reached

If in the [ModesOfOperationDisplay](#) a speed mode is set, it is sufficient to check if the bit *Target reached* of the [Statusword](#) is equal to 1 to check if the drive reached the final speed. This bit is set when the difference between the motor speed and the speed target is lower (in absolute value) to [VelocityWindow](#) for a time period at least equal to [VelocityWindowTime](#). The bit is reset when the difference gets over the window.

Access with MotionDrive:

Main menu > Drive > Drive setup ... > Limits and windows setting

Toolbar >  > Limits and windows setting



Velocity window

Value:	<input type="text" value="0"/>	velocity
Time:	<input type="text" value="0"/>	ms


Stopped motor

If in the [ModesOfOperationDisplay](#) a speed mode is set, to check if the motor is stopped it is sufficient to check if the bit *Speed* of the [Statusword](#) is equal to 1. This bit is set when the motor speed is lower (in absolute speed) to [VelocityThreshold](#) for a period of time at least equal to [VelocityThresholdTime](#). The bit is reset as soon as the difference is higher than the threshold.

Access with MotionDrive:

Main menu > Drive > Drive setup ... > Limits and windows setting

Toolbar >  > Limits and windows setting



Velocity threshold

Value:	<input type="text" value="0"/>	velocity
Time:	<input type="text" value="0"/>	ms

22.8. Control of a torque motion

In the drives of the series *iBMD* some functionalities (common to all torque modes) have been implemented and through these it is possible to check if the motion is run in conformity with the parameterization made by the user.



The speed limit is not enabled with the torque modes. With an incorrectly high torque reference, the motor can reach a wrongly high speed.

Torque

To check the torque created by the motor, read the [ActualTorque](#) parameter or the [ActualFilteredTorque](#) parameter.

Torque target reached

If in the [ModesOfOperationDisplay](#) only one torque mode is set, to check if the motor reached the requested torque it is sufficient to check that the bit *Target reached* of the [Statusword](#) is equal to 1. This bit is set when the difference between [RequestedTorqueCurrent](#) and [ActualTorqueCurrent](#) is lower (in absolute value) than the 5% of [MotorStallCurrent](#) for a time period of at least 1ms. The bit is reset when the difference gets over the window.

22.9. Profile Position Mode

The *Profile Position Mode* is used to run a motion in position, absolute or relative, where the positioning profile is created by the drive. This operating mode follows the specifications of the [CiA-402](#).

To use this mode you need first of all to set the [ModesOfOperation](#) with the value 1 (*Profile Position Mode*), the [MotionProfileType](#) and the options that set the behaviour of the profiler with [PositioningOptionCode](#). Finally you can proceed with the writing of the parameters defining how the position profile must be run:

[TargetPosition](#);
[EndIncrements](#);
[ProfileVelocity](#);
[StartVelocity](#);
[EndVelocity](#);
[ProfileAcceleration](#);
[ProfileDeceleration](#).

NOTICE

If the value of [ProfileVelocity](#) is lower than [StartVelocity](#) or [EndVelocity](#), its value is internally set at the highest value of the two.

Figure 22.1 You can find an example of profile and the meaning of the parameters defining it.




Figure 22.1. Example of position profile with linear ramps.

After having parametrized the drive and set it in the [Operation enable](#) state, you can run the commands to start the positionings and to check the state. To command a positioning you

have to write the **Controlword** and read the **Statusword** following the procedures described in the **CiA-402**. Particularly, through this operating mode it is possible to run a positioning by commanding the following bits in the **Controlword**:

- bit *New set-point*: bit that, on the rising edge, it enables the application of the new position set-point, provided that it is allowed by the bit *Set-point acknowledge* of the Statusword;
- bit *Change set immediately*: through this bit it is possible to choose the mode of positioning between *Single set-point* (if the bit is set to 0) and *Set of set-point* (if the bit is set to 1). In the Set of set-point mode (see **Figure 22.3**) you can find only a buffer of data, the one for the data used during the positioning. In the Single set-point mode (see **Figure 22.2**) the positioning acts as described in the bit *Change immediately option* in the parameter **PositioningOptionCode**. The bit must be set with the transition of the bit *New set-point*;
- bit *Absolute / Relative*: through this bit it is possible to choose the mode to read the parameter **TargetPosition**: for absolute positionings if the bit is set to 0, for relative positionings if the bit is set to 1. The bit must be set with the transition of the bit *New set-point*.




Figure 22.2. Timing chart Profile Position Mode in Single set point mode.




Figure 22.3. Timing chart Profile Position Mode in Set of set points mode.

NOTE

After having reached the requested position at the end of the profile, the bit is set to Target reached of the **Statusword** (see **Position reached target**).

In the Statusword there are three bits showing the status of the positioning:

- bit *Target reached* showing the status of [Position reached target](#);
- bit *Set-point acknowledge* showing if a new set point of positioning can be accepted (bit equal to 0) or not (bit equal to 1);
- bit *Following error* showing the status of [Error of position tracking](#).

NOTE

If a new positioning is started in the Single set-point mode, the ongoing one is aborted and the new one is started without motor stopping.

22.10. Interpolated Position Mode

IMPORTANT

To command the drive by this operating mode it is necessary to have a [Master](#) supporting at least a [Real-time](#) protocol on CANopen or EtherCAT bus.

The *Interpolated Position Mode* is an operative mode that allows to control the motor in [Real-time](#) by using a CANopen or EtherCAT master. This operative mode respects the [CiA-402](#) specifications.

To work, this mode requires the cyclic sending from the master within a defined time (which will be later called T_{SYNC} , synchronization time) of the following parameters (the synchronization techniques are described in the chapter of the communication interfaces):

- [IpPosFirstParameter](#): position reached when the T_{SYNC} expires. This datum is necessary in all kinds of interpolation implemented in the drive.
- [IpPosSecondParameter](#): speed reached when the T_{SYNC} expires. This datum is not used in the linear interpolation.

The writing of the [IpPosFirstParameter](#) and [IpPosSecondParameter](#) parameters does not use the SDOs, but the PDOs combined with some techniques used for the synchronization with the other nodes linked to the bus. In [Figure 22.4](#) an example of linear interpolation with the [Hard sync](#) synchronization technique is reported. This technique is used in the EtherCAT field bus through the [Sync Signal](#) synchronization signal (SYNC).




Figure 22.4. Linear interpolation with synchronization made through Sync Signal synchronization signal (SYNC)

NOTICE

The parameters are so contained in the PDO RX (see the communication interface related chapters) and determine the construction of the movement profile. To avoid this drawback, Bonfiglioli has implemented in the drives of the iBMD series a monitoring and management functionality for the corrupted or missing PDO RX (see Section 10.3.2, Missing or corrupted PDO RX management).

The kind of interpolation can be set through the `IpPosSubModeSelect` parameter and the following methods are available:

- **Linear interpolation**

The drive runs the interpolation of the position only, by linking with a straight line the set-point of the previous position, reached at the beginning of the new period of T_{SYNC} , with the position set point sent by the master in the `IpPosFirstParameter` parameter. The `FeedForwardSpeed` is calculated by the drive and is constant during the whole T_{SYNC} period. In Figure 22.5 you can find an example of linear interpolation.




Figure 22.5. Example of linear interpolation

- **Linear interpolation with FeedForwardSpeed**

The drive runs the interpolation only of the position by linking with a straight line the set-point of a previous position, with the position set point sent by the master in the `IpPosFirstParameter` parameter. The necessary `FeedForwardSpeed` to command the control loops is obtained from the set-point of the speed sent by the master in the `IpPosSecondParameter` parameter and is constant during the whole T_{SYNC} period. This kind of interpolation allows a better motion fluidity compared to the simple linear interpolation.

- **Cubic interpolation**

The drive runs the interpolation of both the position and the velocity by linking with segments of curve line, cubic for the position and quadratic for the velocity, the initial values (`IpPosFirstParameter` and `VelocityOffset` values received by the master with the previous T_{SYNC} period) with the end values (`IpPosFirstParameter` and `VelocityOffset` values received by the master through `IpPosFirstParameter` and `IpPosSecondParameter`). The movement fluidity of this kind of interpolation respect to the other ones is better, as you can observe by comparing [Figure 22.6](#) with [Figure 22.5](#). In fact considering that these two pictures have been created by using the same parameters (except of course the interpolation type selector `IpPosSubModeSelect`) and with a T_{SYNC} of medium duration, it is evident how the [Figure 22.6](#) curves have a trend with less abrupt movements.




Figure 22.6. Example of cubic interpolation

NOTICE

In the linear interpolation with or without feed-forward (values 0 and -10 in the `IpPosSubModeSelect` parameter) the set T_{SYNC} period must be greater than `MotionLoopPeriod`.

In the cubic interpolation (value -1 in the `IpPosSubModeSelect` parameter) the set T_{SYNC} period must be 4 times greater than `MotionLoopPeriod` parameter.

ADVICE

The cubic interpolation use is advantageous only if the T_{SYNC} time has a middle-long duration (about over 4 ms) while, for interpolations that have short T_{SYNC} times (about up to 4ms), these advantages are not, so it's better to use the linear interpolation.

To command the drive with the interpolated mode it is necessary:

1. to set the **ModesOfOperation** with the value 7 (*Interpolated Position Mode*);
2. to configure the communication parameters of the bus field (PDO configuration and mapping, setting of the synchronization system, ...);
3. to set the **IpPosSubModeSelect**;
4. to enable in the master the management that allows, at regular intervals, the sending of the set-points via PDO in the **IpPosDataRecord** and the synchronism management;
5. to take the drive in the **Operation enable** state;
6. enable the position interpolator by setting the *Enable ip mode* bit (see [Table 8.14](#) of the **Controlword** and check that the *Ip mode active* bit is set (see [Table 8.12](#) of the **Statusword**);
7. at this point it is possible to command the drive.

⚠ ATTENTION

If the **Enable ip mode** bit of the **Controlword** is reset, the motion is stopped and the motor stops with maximum deceleration by resetting **RequestedSpeed** to zero.

22.11. Cyclic Synchronous Position Mode

IMPORTANT

To command the drive by this operating mode it is necessary to have a **Master** supporting at least a **Real-time** protocol on CANopen or EtherCAT bus.

The *Cyclic Synchronous Position Mode* is an operative mode that allows to control the motor in **Real-time** by using a CANopen or EtherCAT master. This operative mode respects the **CiA-402** specifications.


To work, this mode requires to the master the cyclic sending, within a defined time (which will be later called T_{SYNC} , synchronization time) of the **TargetPosition** parameter (the synchronization techniques are described in the chapter of the communication interfaces):

In case of cubic interpolated mode use, even the **VelocityOffset** parameter will be necessary.

There are other parameters that are not required by the drive to generate the movement (they are not necessary), but can be useful to improve it. These parameters are:

- **PositionOffset**: position that will be added to the **TargetPosition**.
- **VelocityOffset**:
 - in case of cubic interpolation, this parameter is necessary because it is the velocity that the drive needs to make the interpolation calculations.
 - in case of non cubic interpolation: if the **CyclicSynchronousSubMode** indicates that the **KVff** internal calculation is disabled, it will be used as **KVff**
 - In all the other cases it is not used
- **TorqueOffset**: it is used as **KAff** if the **CyclicSynchronousSubMode** parameter indicates that the **KAff** internal calculation is disabled, otherwise it's not used.

The writing of the [TargetPosition](#) parameter does not use the SDO, but the PDO combined with some techniques that allow the synchronization with the other nodes that are connected to the bus. In [Figure 22.4](#) it is reported an example of linear interpolation with the [Hard sync](#) synchronization technique, used in the EtherCAT field bus with the [Sync Signal](#) synchronization signal (SYNC).

 NOTICE

The parameters are so contained in the PDO RX (see the communication interface related chapters) and determine the construction of the movement profile. When a CANopen Master is used, if a PDO RX is lost it's automatically re-sent, while in case of an EtherCAT Master this functionality is not provided.

To avoid this drawback, Bonfiglioli has implemented in the drives of the iBMD series a monitoring and management functionality for the corrupted or missing PDO RX (see [Section 10.3.2, Missing or corrupted PDO RX management](#)).

The kind of interpolation can be set through the [CyclicSynchronousSubMode](#) parameter and the following methods are available:

- **No interpolation**


The drive executes the movement without interpolating the position target, that will be directly applied on the T_{SYNC} signal. The [FeedForwardSpeed](#) and the [FeedForwardAcceleration](#) can be set by the master or internally calculated by the drive (see [Table 27.16](#) for the available combinations).

- **Linear interpolation**

The drive runs the interpolation only of the position by linking with a straight line the set-point of a previous position, with the position set point sent by the master in the [TargetPosition](#) parameter. The [FeedForwardSpeed](#) and the [FeedForwardAcceleration](#) can be set by the master or internally calculated by the drive (see [Table 27.16](#)). In [Figure 22.5](#) an example of linear interpolation can be found.

- **Cubic interpolation**

The drive executes the interpolation both of the position and of the velocity, linking with a curved lines, cubic for the position and quadratics for the velocity, the initial values (values of [TargetPosition](#) and [VelocityOffset](#) received from the master with the previous T_{SYNC} period) with the final ones (values of [TargetPosition](#) and [VelocityOffset](#) received by the master). This interpolation type, as you can see comparing [Figure 22.6](#) with [Figure 22.5](#), allows a movement improved fluidity respect to all the other interpolation modes. In fact, bearing in mind that the two figures have been created by using the same parameters (except for the [CyclicSynchronousSubMode](#) interpolation type selector, of course) and by using a T_{SYNC} with medium duration, it's evident how the curves in [Figure 22.6](#) have a trend with less abrupt deviations. The [FeedForwardAcceleration](#) can be set by the master or internally calculated by the drive (see [Table 27.16](#)).

 NOTICE

In case of no interpolation or linear interpolation (different values from -147 and -148 in the [CyclicSynchronousSubMode](#) parameter) with or without feed-forward, the set T_{SYNC} period must be greater than [MotionLoopPeriod](#).

In the cubic interpolation (values -147 and -148 in the [CyclicSynchronousSubMode](#) parameter) the set T_{SYNC} period must be greater than 4 times the [MotionLoopPeriod](#) parameter.

ADVICE

The cubic interpolation use is advantageous only if the T_{SYNC} time has a middle-long duration (about over 4 ms) while, for interpolations that have short T_{SYNC} times (about up to 4ms), these advantages are not, so it's better to use the linear interpolation.

To command the drive with this mode it is necessary:

1. to configure the communication parameters of the bus field (PDO configuration and mapping, setting of the synchronization system, ...):
2. to activate in the master the management that allows, at regular intervals, to send the set-points through PDO and the synchronism management; the number and the type of the data (set-point) that have to be sent, depends on the [CyclicSynchronousSubMode](#) that has been set;
3. to set the [CyclicSynchronousSubMode](#);
4. to set the [ModesOfOperation](#) with the value 8 (*Cyclic Synchronous Position Mode*);
5. to take the drive in the [Operation enable](#) state;
6. at this point it is possible to command the drive.

 **ATTENTION**

By selecting a value of [CyclicSynchronousSubMode](#) that assigns to the master the [KVff](#) and [KAff](#) calculation, it will be obtained a smoother motor motion. Pay attention that is a master duty to ensure that these data are sent, because the drive does not verify their receiving. If this last configuration is selected and the master doesn't anyway send the necessary feed forward values, the motion profile may be not the desired one.

22.12. Cyclic Synchronous Velocity Mode

IMPORTANT

To command the drive by this operating mode it is necessary to have a [Master](#) supporting at least a [Real-time](#) protocol on CANopen or EtherCAT bus.

The *Cyclic Synchronous Velocity Mode* is an operative mode that allows the motor control in [Real-time](#) by using a CANopen or EtherCAT master. This operative mode respects the [CiA-402](#) specifications.

To work, this mode requires to the master the cyclic sending, within a defined time (which will be later called T_{SYNC} , synchronization time) of the [TargetVelocity](#) parameter (the synchronization techniques are described in the chapter of the communication interfaces):

There are other parameters that are not required by the drive to generate the movement (they are not necessary), but can be useful to improve it. These parameters are:

- [VelocityOffset](#): velocity that will be added to [TargetVelocity](#).
- [TorqueOffset](#): it is used as [KAff](#) if the [CyclicSynchronousSubMode](#) parameter indicates that the [KAff](#) internal calculation is disabled, otherwise it's not used.

The writing of the [TargetVelocity](#) parameter does not use the SDO, but the PDO combined with some techniques that allow the synchronization with the other nodes that are connected to the bus. In [Figure 22.4](#) it is reported an example of linear interpolation with the [Hard sync](#) synchronization technique, used in the EtherCAT field bus with the [Sync Signal](#) synchronization signal (SYNC).

 NOTICE

The parameters are so contained in the PDO RX (see the communication interface related chapters) and determine the construction of the movement profile. When a CANopen Master is used, if a PDO RX is lost it's automatically re-sent, while in case of an EtherCAT Master this functionality is not provided.

To avoid this drawback, Bonfiglioli has implemented in the drives of the iBMD series a monitoring and management functionality for the corrupted or missing PDO RX (see [Section 10.3.2, Missing or corrupted PDO RX management](#)).


The kind of interpolation can be set through the [CyclicSynchronousSubMode](#) parameter and the following methods are available:

- **No interpolation**

The drive executes the movement without interpolate the velocity target, that will be directly applied on the T_{SYNC} signal arrival. The [FeedForwardAcceleration](#) can be set by the master or internally calculated by the drive (see [Table 27.16](#) for the available combinations).

- **Linear interpolation**

The drive executes the interpolation of the velocity only, by linking with a straight line the previous velocity set-point with the set-point that has been sent to the master in the [TargetVelocity](#) parameter. The [FeedForwardAcceleration](#) can be set by the master or internally calculated by the drive (see [Table 27.16](#)). In [Figure 22.5](#) you can find an example of linear interpolation.

 NOTICE

The T_{SYNC} period that has been set must be greater than [MotionLoopPeriod](#).

To command the drive with this mode it is necessary:

1. to configure the communication parameters of the bus field (PDO configuration and mapping, setting of the synchronization system, ...);
2. to activate in the master the management that allows, at regular intervals, to send the set-points through PDO and the synchronism management; the number and the type of the data (set-point) that have to be sent, depends on the [CyclicSynchronousSubMode](#) that has been set;
3. to set the [CyclicSynchronousSubMode](#);
4. to set the [ModesOfOperation](#) with the value 9 (*Cyclic Synchronous Velocity Mode*);
5. to take the drive in the [Operation enable](#) state;
6. at this point it is possible to command the drive.

 ATTENTION

By selecting a value of [CyclicSynchronousSubMode](#) that assigns to the master the [KAff](#) calculation, it will be obtained a smoother motor motion. Pay attention that is a master duty to ensure that these data are sent, because the drive does not verify their receiving. If this last configuration is selected and the master doesn't anyway send the necessary feed forward values, the motion profile may be not the desired one.

22.13. Cyclic Synchronous Torque Mode

IMPORTANT

To command the drive by this operating mode it is necessary to have a **Master** supporting at least a **Real-time** protocol on CANopen or EtherCAT bus.

The *Cyclic Synchronous Torque Mode* is an operative mode that allows the motor control in **Real-time** by using a CANopen or EtherCAT master. This operative mode respects the **CiA-402** specifications.

To work, this mode requires to the master the cyclic sending, within a defined time (which will be later called T_{SYNC} , synchronization time) of the **TargetTorque** parameter (the synchronization techniques are described in the chapter of the communication interfaces):

There are other parameters that are not required by the drive to generate the movement (they are not necessary), but can be useful to improve it. These parameters are:

- **TorqueOffset**: torque that will be added to the **TargetTorque**.

The writing of the **TargetTorque** parameter does not use the SDO, but the PDO combined with some techniques that allow the synchronization with the other nodes that are connected to the bus. In **Figure 22.4** it is reported an example of linear interpolation with the **Hard sync** synchronization technique, used in the EtherCAT field bus with the **Sync Signal** synchronization signal (SYNC).

NOTICE

The parameters are so contained in the PDO RX (see the communication interface related chapters) and determine the construction of the movement profile. When a CANopen Master is used, if a PDO RX is lost it's automatically re-sent, while in case of an EtherCAT Master this functionality is not provided.

To avoid this drawback, Bonfiglioli has implemented in the drives of the *iBMD* series a monitoring and management functionality for the corrupted or missing PDO RX (see **Section 10.3.2, Missing or corrupted PDO RX management**).

The kind of interpolation can be set through the **CyclicSynchronousSubMode** parameter and the following methods are available:

- **No interpolation**
The drive executes the movement without interpolating the torque target, that will be directly applied on the T_{SYNC} signal.
- **Linear interpolation**
The drive runs the interpolation only of the torque by linking with a straight line the set-point of a previous position, reached at the beginning of the new period of T_{SYNC} , with the torque set point sent to the master in the **TargetTorque** parameter. In **Figure 22.5** you can find an example of linear interpolation.

NOTICE

The T_{SYNC} period that has been set must be greater than **MotionLoopPeriod**.

To command the drive with the interpolated mode it is necessary:

1. to configure the communication parameters of the bus field (PDO configuration and mapping, setting of the synchronization system, ...):

2. to activate in the master the management that allows, at regular intervals, to send the set-points through PDO and the synchronism management; the number and the type of the data (set-point) that have to be sent, depends on the [CyclicSynchronousSubMode](#) that has been set;
3. to set the [CyclicSynchronousSubMode](#);
4. to set the [ModesOfOperation](#) with the value 10 (*Cyclic Synchronous Torque Mode*);
5. to take the drive in the [Operation enable](#) state;
6. at this point it is possible to command the drive.

22.14. Profile Velocity Mode (CiA402)

The *Profile Velocity Mode (CiA402)* is used to carry out a speed motion, in which the speed profile is created by the drive. This operating mode follows the specifications of the [CiA-402](#). To use this mode you need to set the [ModesOfOperation](#) with the value 3 (*Profile Velocity Mode (CiA402)*). Then you can proceed to write the parameters defining how to run the speed profile:

- [MotionProfileType](#);
- [StartVelocity](#);
- [EndVelocity](#);
- [ProfileAcceleration](#);
- [ProfileDeceleration](#);
- [TargetVelocity](#).

In [Figure 22.7](#) you can find an example showing how it is possible to change the [TargetVelocity](#) and the other profile parameters in any moment. In the first phase the motor is accelerated until it reaches the V1 speed; later it is accelerated again to reach the V2 speed but it does not reach it because it gets a new request for reaching the V3 speed. At last the motor slows down until it stops since the V4 speed is equal to 0. You can notice that the acceleration and deceleration ramps are broken, near the value of zero, respectively from [StartVelocity](#) and from [EndVelocity](#).




Figure 22.7. Speed profile with linear ramps.

After the drive is parametrized and set to the [Operation enable](#) mode, the motor will start moving as soon as a [TargetVelocity](#) is written with an absolute value higher than [EndVelocity](#) and [StartVelocity](#).

In the Statusword there are two bits showing the motion status:

- bit *Target reached*: bit showing the status of the **Speed target reached**;
- bit *Speed*: bit showing if the drive has the **Stopped motor**.

NOTICE

If with the motor in motion in mode **Profile Velocity Mode (CiA402)** the **TargetVelocity** is written in an absolute value which is lower than **EndVelocity** or **StartVelocity**, the motor slows down with a deceleration equal to **ProfileDeceleration** until it reaches the **EndVelocity** and then it stops.

ATTENTION

If with the motor in motion in **Profile Velocity Mode (CiA402)** mode, the **EndVelocity** or the **StartVelocity** are written in an absolute value which is higher than **TargetVelocity**, the motor stops with maximum deceleration resetting **RequestedSpeed** to zero.

22.15. Profile Velocity Mode (CUSTOM)

The *Profile Velocity Mode (CUSTOM)* is used to run a motion in speed whose position is controlled, in which the speed profile is created from the drive. This operating mode works like the *Profile Velocity Mode (CiA402)* with the only difference that the position control is enabled. In **Figure 22.8** you can notice a difference in the behaviour of the motor speed between the two operating modes, when a brake torque is applied at the instant t_1 .




Figure 22.8. Comparison between a motion in Profile Velocity Mode (CiA402) and in Profile Velocity Mode (CUSTOM).

In the previous picture you can notice that starting from the instant t_2 , the two operating modes behave in a different way:

- **Profile Velocity Mode (CiA402)**
The drive compensates for the brake torque and returns to the speed **TargetVelocity**.
- **Profile Velocity Mode (CUSTOM)**
The drive returns to the speed **TargetVelocity** after regaining the lost position. This means that a speed overshoot is created in the time interval t_2 - t_3 , so that the A area is equal to the B area (A area = lost position = regained position = B area). At the instant t_3 , when the lost position is fully regained, the drive returns to the speed **TargetVelocity**.


NOTE

With the **Profile Velocity Mode (CUSTOM)** the control of the **Error of position tracking** is enabled.

To use this operating mode it is sufficient to write -113 in [ModesOfOperation](#) and, so, to follow the instructions described in [Section 22.14, Profile Velocity Mode \(CiA402\)](#).

22.16. Profile Velocity AI Mode

The *Profile Velocity AI Mode* is used to run a motion in speed, in which the speed profile is created from the drive as it happens for the *Profile Velocity Mode (CiA402)*, but in this case the requested speed is not set through the [TargetVelocity](#) parameter but it is obtained from [AI0FilteredVoltage](#). The conversion of the values from their voltage to the requested speed occurs according to what is reported in [Section 17.3, Conversion](#).



IMPORTANT

For the *Profile Velocity AI Mode* you can apply all the considerations related to the *Profile Velocity Mode (CiA402)* and its parameters, as explained in [Section 22.14, Profile Velocity Mode \(CiA402\)](#), except from what was stated for the [TargetVelocity](#) parameter.

To enable the *Profile Velocity AI Mode* you must write the -111 value in the [ModesOfOperation](#) parameter. The *Profile Velocity AI Mode* has the automatic [Enable](#) functionality.

ADVICE

The filter that's applied on the analog input may limit the dynamic of the velocity reference and of the profiler ramps. To have a velocity reference that varies quickly you have to remove the filter and to increase the profiler ramps ([ProfileAcceleration](#) and [ProfileDeceleration](#)).

22.17. Torque Mode

The *Torque Mode* is used to check the motor with a torque reference. To use this mode it's necessary to set the [ModesOfOperation](#) with the value 4 (*Torque Mode*) and then set the drive to the [Operation enable](#) state as described in the [Section 8.5, CiA402 state machine](#). Later you can run the motion by writing the torque reference [TargetTorque](#).

The parameters that define how the torque referred movement has to be executed are:

- [TargetTorque](#);
- [TorqueSlope](#);
- [TorqueProfileType](#);


After the drive is parametrized and set to the [Operation enable](#) mode, a torque with module and direction consistent with the value in the [TargetTorque](#) parameter is applied on the motor.

In the Statusword there is a bit that shows the motion status:

- bit *Target reached*: bit showing the status of the [Torque target reached](#);

22.18. Torque AI Mode

The *Torque AI Mode* is used to run a motion in torque created from the drive as it happens for the *Torque Mode*, but in this case the requested torque is not set through the [Target Torque](#) parameter but it is obtained from [AIOFilteredVoltage](#). The conversion of the values from the voltage to the requested torque occurs according to what is reported in [Section 17.3, Conversion](#).



IMPORTANT

For the *Torque AI Mode* you can apply all the considerations related to the *Torque Mode* and its parameters, as explained in [Section 22.17, Torque Mode](#), except from what was stated for the [TargetTorque](#) parameter.

To enable the *Torque AI Mode* you must write the -101 value in the [ModesOfOperation](#) parameter. The *Torque AI Mode* has the automatic [Enable](#) functionality.

ADVICE

The filter that's applied on the analog input may limit the dynamic of the torque reference. To have a torque reference that varies quickly you have to remove the filter.

22.19. Homing Mode

The *Homing Mode* is used to bring the motor on a known position, using some external references as the [Positive limit switch \(FC +\)](#), the [Negative limit switch \(FC -\)](#), the mechanical stop, the [Home](#) switch and the [Index](#) of the feedback sensor. This operating mode can be also used to run the preset of [PositionActualValue](#) without running any motion. The *Homing Mode* meets the specifications of the [CiA-402](#).

NOTICE

Regardless of which feedback sensor type is on the *iBMD*, the homing procedures are always the same, it only change the position reference subsistence conditions. For further information see [Non-resettable parameters](#).

ADVICE

To configure the digital inputs like **Positive limit switch (FC +)**, **Negative limit switch (FC -)** or **Home**, see [Chapter 16, Digital inputs and outputs](#).

⚠ WARNING

If the **Polarity** is of **Reverse** type, the roles of **Positive limit switch (FC +)** and **Negative limit switch (FC -)** are reversed: **Positive limit switch (FC +)** behaves like **Negative limit switch (FC -)** and **Negative limit switch (FC -)** behaves like **Positive limit switch (FC +)**. This is true both in the text of this manual and in the **MotionDrive**.

⚠ NOTICE

If you change the **Polarity** it will be necessary to re-execute the homing procedure.

⚠ WARNING

If a **HomingMethod** (see also [Table 22.3](#)) with **mechanical stop** is selected (e.g. mode -1), remember to set the torque limit (see [Section 19.3, Torque limit](#)).

The following positions related to the *Homing Mode* are defined.

- **End position:** physical position of the motor at the end of the homing procedure, when the motor is stopped after the deceleration ramp
- **Home position:** physical position of the motor where the final phase of the homing procedure is noticed
- **Zero position:** physical position of the motor where **PositionActualValue** is equal to 0 inc.
- **HomeOffset:** difference between Zero position and Home position.

In the following picture can be found an example of homing motion with searching of the **Home** switch and the **Index** of the feedback sensor. When the motion starts, **Home** switch is not engaged and the motor is moved in the positive direction at the **SpeedForSwitch** speed. With the engagement of the **Home** switch, the motion is reversed and taken to the **SpeedForZero** speed. After the disengagement of the switch, the motor is stopped on the first **Index** found on the feedback sensor.




Figure 22.9. Example of timing chart of a homing profile (*HomingMethod* = 7).

At the end of the homing procedure, a preset of the position is carried out. **PositionActualValue** gets the value according to the following formula:

$$\text{PositionActualValue} = \text{End position} - \text{Home position} - \text{HomeOffset}$$




Figure 22.10. Example of position trend of a homing profile (*HomingMethod* = 7).

To use this operating mode, you must set the **ModesOfOperation** with the value 6 (*Homing Mode*). Then you proceed writing the parameters that define how the profile and the homing procedure must be run:

- **HomingMethod**, see the following table;
- **HomeOffset**;
- **SpeedForSwitch**;
- **SpeedForZero**;
- **StartVelocity**;
- **EndVelocity**;
- **HomingAcceleration**;
- **IndexPulseDeadZone**.

Val.	Procedure description
1	The motor is moved in the negative direction with <i>SpeedForSwitch</i> velocity. With the engagement of the Negative limit switch (FC -) , the motion is reversed and taken to the speed <i>SpeedForZero</i> . After the disengagement of the limit switch, the motor is stopped on the first detected Index pulse.
2	The motor is moved in the positive direction with <i>SpeedForSwitch</i> velocity. With the engagement of the Positive limit switch (FC +) , the motion is reversed and taken to the speed <i>SpeedForZero</i> . After the disengagement of the limit switch, the motor is stopped on the first detected Index pulse.
7	You can find the following sub-cases: <ul style="list-style-type: none"> a. At the start of the motion Home switch is not engaged, the motor is moved in the positive direction with <i>SpeedForSwitch</i> velocity. With the engagement of the Home switch, the motion is reversed and taken to the speed <i>SpeedForZero</i>. After the disengagement of the switch, the motor is stopped on the first detected Index pulse. b. At the start of the motion Home switch is engaged, the motor is moved in the negative direction with <i>SpeedForZero</i> velocity. After the disengagement of the Home switch, the motor is stopped on the first detected Index pulse. c. At the start of the motion Home switch is not engaged, the motor is moved in the positive direction with <i>SpeedForSwitch</i> velocity. With the engagement of the Positive limit switch (FC +), the motor motion is reversed. With the engagement of the Home switch, the motion is taken to the speed <i>SpeedForZero</i>. After the disengagement of the switch, the motor is stopped on the first detected Index pulse.
8	You can find the following sub-cases: <ul style="list-style-type: none"> a. At the start of the motion Home switch is not engaged, the motor is moved in the positive direction with <i>SpeedForSwitch</i> velocity. After the engagement of the Home switch, the motion is taken to the speed <i>SpeedForZero</i>. The motor is stopped on the first detected Index pulse. b. At the start of the motion Home switch is engaged, the motor is moved in the negative direction with <i>SpeedForZero</i> velocity. After the disengagement of the Home switch, the motion is reversed. After a new engagement of the switch, the motor is stopped on the first detected Index pulse. c. At the start of the motion Home switch is not engaged, the motor is moved in the positive direction with <i>SpeedForSwitch</i> velocity. With the engagement of the Positive limit switch (FC +), the motor motion is reversed. With the engagement of the Home switch, the motion is taken to the speed <i>SpeedForZero</i>. With the disengagement of the switch, the motion is reversed again. After a new engagement of the Home, the motor is stopped on the first detected Index pulse.
9	You can find the following sub-cases: <ul style="list-style-type: none"> a. At the start of the motion Home switch is not engaged, the motor is moved in the positive direction with <i>SpeedForSwitch</i> velocity. With the engagement of the Home switch, the motion is taken to the speed <i>SpeedForZero</i>, with the disengagement of the switch the motion is reversed. After a new engagement of the Home, the motor is stopped on the first detected Index pulse. b. At the start of the motion Home switch is engaged, the motor is moved in the positive direction with <i>SpeedForZero</i> velocity. With the disengagement of the Home switch, the motion is reversed. After a new engagement of the switch, the motor is stopped on the first detected Index pulse. c. At the start of the motion Home switch is not engaged, the motor is moved in the positive direction with <i>SpeedForSwitch</i> velocity. With the engagement of the Positive limit switch (FC +), the motor motion is reversed. With the engagement of the Home switch, the motion is taken to the speed <i>SpeedForZero</i>. The motor is stopped on the first detected Index pulse.
10	You can find the following sub-cases: <ul style="list-style-type: none"> a. At the start of the motion Home switch is not engaged, the motor is moved in the positive direction with <i>SpeedForSwitch</i> velocity. With the engagement of the Home switch, the motion is taken to the speed <i>SpeedForZero</i>. After the disengagement of the switch, the motor is stopped on the first detected Index pulse. b. At the start of the motion Home switch is engaged, the motor is moved in the positive direction with <i>SpeedForZero</i> velocity. After the disengagement of the Home switch, the motor is stopped on the first detected Index pulse. c. At the start of the motion Home switch is not engaged, the motor is moved in the positive direction with <i>SpeedForSwitch</i> velocity. With the engagement of the Positive limit switch (FC +), the motor motion is reversed. With the engagement of the Home switch, the motion is reversed and taken to the speed <i>SpeedForZero</i>. After the disengagement of the switch, the motor is stopped on the first detected Index pulse.

Val.	Procedure description
11	Symmetrical to the 7. Differences: reversed speed signs; in the sub-case c) reversed motion on the Negative limit switch (FC -) .
12	Symmetrical to the 8. Differences: reversed speed signs; in the sub-case c) reversed motion on the Negative limit switch (FC -) .
13	Symmetrical to the 9. Differences: reversed speed signs; in the sub-case c) reversed motion on the Negative limit switch (FC -) .
14	Symmetrical to the 10. Differences: reversed speed signs; in the sub-case c) reversed motion on the Negative limit switch (FC -) .
17	Same as 1. Differences: without search for Index pulse, motion stopped on the correct edge of the limit switch.
18	Same as 2. Differences: without search for Index pulse, motion stopped on the correct edge of the limit switch.
23	Same as 7. Differences: without search for Index pulse, motion stopped on the correct edge of the Home switch.
26	Same as 10. Differences: without search for Index pulse, motion stopped on the correct edge of the Home switch.
27	Symmetrical to the 7. Differences: reversed speed signs; in the sub-case c) reversed motion on the Negative limit switch (FC -) ; without search for Index pulse, motion stopped on the correct edge of the Home switch.
30	Symmetrical to the 10. Differences: reversed speed signs; in the sub-case c) reversed motion on the Negative limit switch (FC -) ; without search for Index pulse, motion stopped on the correct edge of the Home switch.
35	The motor does not move and the drive takes the current position as Home position .
-1	The motor is moved in the negative direction with SpeedForSwitch velocity. When the mechanical stop is reached, the movement is inverted and taken to the SpeedForZero velocity. The motor is stopped on the first detected Index pulse.
-2	The motor is moved in the positive direction with SpeedForSwitch velocity. When the mechanical stop is reached, the movement is inverted and taken to the SpeedForZero velocity. The motor is stopped on the first detected Index pulse.
-7	Same as 7. Differences: with the engagement of a limit switch the procedure is stopped and you get an error message (bit Homing error = 1).
-8	Same as 8. Differences: with the engagement of a limit switch the procedure is stopped and you get an error message (bit Homing error = 1).
-9	Same as 9. Differences: with the engagement of a limit switch the procedure is stopped and you get an error message (bit Homing error = 1).
-10	Same as 10. Differences: with the engagement of a limit switch the procedure is stopped and you get an error message (bit Homing error = 1).
-11	Symmetrical to the 7. Differences: reversed speed signs; with the engagement of a limit switch the procedure is stopped and you get an error message (bit Homing error = 1).
-12	Symmetrical to the 8. Differences: reversed speed signs; with the engagement of a limit switch the procedure is stopped and you get an error message (bit Homing error = 1).
-13	Symmetrical to the 9. Differences: reversed speed signs; with the engagement of a limit switch the procedure is stopped and you get an error message (bit Homing error = 1).
-14	Symmetrical to the 10. Differences: reversed speed signs; with the engagement of a limit switch the procedure is stopped and you get an error message (bit Homing error = 1).
-17	Same as -1. Differences: after the mechanical stop is reached and the direction is inverted, the motor is distanced from the mechanical stop with a minimum pulse number set on HomingPosDisengagement (minimum disengagement position).
-18	Same as -2. Differences: after the mechanical stop is reached and the direction is inverted, the motor is distanced from the mechanical stop with a minimum pulse number set on HomingPosDisengagement (minimum disengagement position).
-23	Same as 7. Differences: without search for Index pulse, motion stopped on the correct edge of the Home switch; with the engagement of a limit switch the procedure is stopped and you get an error message (bit Homing error = 1).

Val.	Procedure description
-26	Same as 10. Differences: without search for Index pulse, motion stopped on the correct edge of the Home switch; with the engagement of a limit switch the procedure is stopped and you get an error message (bit <i>Homing error</i> = 1).
-27	Symmetrical to the 7. Differences: reversed speed signs; without search for Index pulse, motion stopped on the correct edge of the Home switch; with the engagement of a limit switch the procedure is stopped and you get an error message (bit <i>Homing error</i> = 1).
-30	Symmetrical to the 10. Differences: reversed speed signs; without search for Index pulse, motion stopped on the correct edge of the Home switch; with the engagement of a limit switch the procedure is stopped and you get an error message (bit <i>Homing error</i> = 1).
-35	Same as 35. Differences: the drive takes RequestedPosition as Home position .

Table 22.3. Available Homing procedures (*HomingMethod*).




WARNING

If the **Polarity** is of Reverse type, the roles of **Positive limit switch (FC +)** and **Negative limit switch (FC -)** are reversed: **Positive limit switch (FC +)** behaves like **Negative limit switch (FC -)** and **Negative limit switch (FC -)** behaves like **Positive limit switch (FC +)**. This is true both in the text of this manual and in the MotionDrive.



WARNING

If a **HomingMethod** (see also **Table 22.3**) with mechanical stop is selected (e.g. mode -1), remember to set the torque limit (see **Section 19.3, Torque limit**).



Legenda:

- ┆ : axis position at the beginning of the homing movement
- : axis position at the end of the homing movement

Figure 22.11. Available Homing CiA-402 procedures.

Access with MotionDrive:

Main menu > Drive > Drive setup ... > Homing

Toolbar >  > Homing

NOTE

On the digital input with functionalities of **Home** a filtering at 10ms is run: the input status is considered as valid if it remains unchanged for at least 10 ms.

IMPORTANT

When a homing method which uses the **Index** pulse is selected, it's not permitted to use the capture peripheral A to execute other captures and in the capture peripheral B it is not possible to configure the **Index** pulse as trigger source.

After having parametrized the drive and taken it to the **Operation enable** state, you can start the homing procedure by setting the bit *Homing operation start* of the **Controlword**. On the **Statusword** you can see the status of the bits procedure.

- bit *Target reached*: it shows if the procedure is ended;
- bit *Homing attained*: it shows if the homing procedure was correctly concluded;
- bit *Homing error*: it shows that there has been an error during the procedure running.

For further details on these bits, please refer to [Table 8.12](#).

22.20. *Tuning Mode*

This operating mode is used only for the drive configuration and calibration. It is temporarily enabled by the drive when some commands of the [SysMngCommand](#) are requested.

Chapter 23

Oscilloscope and monitoring

23.1. Parameters monitoring

To monitor the parameters it is possible to follow three methods:

1. Object dictionary for non repetitive instant monitoring ([Section 27.2, Reading and writing a parameter](#))
2. Show variables ([Figure 3.1](#)) for repetitive instant monitoring
3. MotionDrive oscilloscope for longer monitoring in precise time intervals ([Section 23.2, Monitoring by oscilloscope](#)).

Parameter	Show variables	Oscilloscope
PowerTemperature	YES	-
LogicTemperature	YES	-
MotorTemperature	YES	-
FeedbackSensorTemperature	YES	-
DCBusVoltage(+HV)	YES	YES
ActualMotorCurrent	YES	YES
ActualFieldCurrent	YES	-
ActualTorqueCurrent	YES	YES
RMSMotorCurrent	YES	YES

Parameter	Show variables	Oscilloscope
RequestedField	-	YES
ActualField	-	YES
RequestedTorque	YES	YES
ActualTorque	-	YES
ActualFilteredTorque	YES	-
ActualCurrentU	-	YES
ActualCurrentV	-	YES
ActualCurrentW	-	YES
I2TValue	YES	YES
RequestedSpeed	-	YES
VelocityActualValue	-	YES
SpeedFollowingError	-	YES
FeedForwardSpeed	-	YES
FeedForwardAcceleration	-	YES
RequestedPosition	-	YES
PositionActualValue	-	YES
PositionFollowingError	YES	YES
AI0Voltage	-	YES
AI0FilteredVoltage	YES	YES
AuxiliaryEncoderPosition	YES	-
AuxiliaryEncoderSpeed	YES	YES
Motor electric angle	-	YES
Feedback electric angle	-	YES
Feedback incremental counter	-	YES
Feedback hall status	-	YES
Feedback cosine	-	YES
Feedback sine	-	YES

23.2. Monitoring by oscilloscope

Through the MotionDrive oscilloscope it is possible to acquire up to four channels at the same time. Any of the four channels, conventionally given to the vertical axis Y, and the temporal channel, conventionally given to the horizontal axis X, can be set through the related box in the tab Channels.

NOTE


When the Function Generator and Tuning tabs are enabled, MotionDrive can only run the functions that are at disposal by the Oscilloscope, Oscilloscope screen and Trigger windows. To enable the other functionalities again it is necessary to close the oscilloscope and reopen it by using only the following paths.

Access:

Main menu > Drive > Oscilloscope ... > Channels

Toolbar >  > Channels

To start a capture see [Section 23.3, Setting the oscilloscope Trigger](#), while hereafter you can find the settings related to the oscilloscope channels.



In the previous box you can find:


- A. selecting the parameter to capture
- B. indicator warning when the track gets over the lowest Screen limit; to let the track get back within bounds, change the scale or the offset
- C. indicator warning when the channel gets over the highest Screen limit; to let the track get back within bounds, change the scale or the offset
- D. buttons used to modify the offset
- E. buttons used to centre the track in the Screen
- F. field used to read and write the offset
- G. button used to update the offset after having written it in the field F
- H. selecting the display mode of the track:
 - *Disable o Hide* they hide the track
 - *Inverted* it inverts the track sign
 - *Normal* normal track display
 - *Zero* resets the track points
- I. selecting the channel scale (see also the options in [Scale and autoscale options](#))
- J. track colour (to modify it, see [Tracks preferences](#))
- K. option used to enable the channel capture

23.3. Setting the oscilloscope Trigger

Access:



To set the event of *trigger*, which starts the data capture, refer to the Trigger window.



In the Trigger window there are:

- A. selecting the channel the trigger is associated to
- B. mode selection:
 - *Auto*: data capture without waiting for the trigger
 - *Normal*: data capture waiting for the trigger.

ADVICE

If during the Normal mode no capture starts, enable the display of the trigger level (F), capture through the Auto mode, check on the screen the channel progress the trigger is associated to (A), set correctly the value (D) and the trigger edge (H) and try to capture again (I).

- C. selecting the sampling time; if the sampling time increases, the capture interval proportionally increases
- D. setting the trigger value
- E. setting the points percentage you want to capture before the trigger event, as to the total number of the single track points. For example, if the Pre-trigger is equal to 50%, the trigger event will take place at half track
- F. enabling the display at the trigger level
- G. option used to run a single capture
- H. selecting the trigger edge
- I. button used to enable the data capture
- J. button used to delete the captured data
- K. button used to stop the capture in progress; the data will not be displayed in the Screen
- L. button used to close the trigger window



- M. reading the oscilloscope status; in case of error the Screen data will not be validated
- N. reading the percentage of the progress of the oscilloscope status.

23.4. Saving or uploading an oscilloscope capture

Open the tab Channel. Access:


Main menu > Drive > Oscilloscope ... > Channels


Toolbar >  > Channels


To upload a capture saved in a file in the oscilloscope, push the button  and then the button , then select the file to upload.

IMPORTANT

The saved data are independent from the parameters and from the resolutions that are set in the drive. On consequence the oscilloscope will show the data in the charts according to the parameters that has been inserted (for example, a position profile will depend on the revolution resolution that has been set).

To save the capture in a file, push the button . When you save the file you can also add a short description of the capture to save.

To save the captured tracks in the Screen in order to compare them with any new captures, open the window Oscilloscope Memory by pushing the button .



In the window Oscilloscope memory you can find:

- A. button used to save the track in the Screen

- B. button used to delete the track saved in the Screen
- C. option used to see the chart of only the captured track and modify its features
- D. option used to see the chart of only the saved track and modify its features
- E. option used to see the chart both of the captured track and the saved track and modify their features


23.5. Processing the captured tracks by the oscilloscope

Open the tab Channel. Access:

Main menu > Drive > Oscilloscope ... > Channels


Toolbar >  > Channels

Autoscale

To set the Screen tracks automatically, according to the settings selected in [Scale and autoscale options](#), push the button .

Measures

To measure the Screen tracks use the box Cursors.





In the box Cursors you can find:

- A. field used to read and write the cursors values
- B. option used to enable the cursors
- C. button used to confirm the digital values in the fields A
- D. selecting the functionalities associated to the mouse:
 - *None*: no operation
 - *Track*: displaying the coordinates pointed with the mouse, by pushing the mouse left button in the Screen
 - *Zoom*: zooming a Screen portion

- *Pan XY*: tracks movement along the axes X and Y by moving the mouse pointer on the screen and pushing the left button
 - *Pan X*: tracks movement along the axis X by moving the mouse pointer on the screen and pushing the left button
 - *Pan Y*: tracks movement along the axis Y by moving the mouse pointer on the screen and pushing the left button
 - *Cursor X1*: enabling and positioning the cursor X1 with the mouse on the Screen
 - *Cursor X2*: enabling and positioning the cursor X2 with the mouse on the Screen
 - *Trigger*: positioning the trigger with the mouse on the Screen, only if the option Show trigger is enabled (see the point F in [Section 23.3, Setting the oscilloscope Trigger](#))
 - *Cursor Y1*: enabling and positioning the cursor Y1 with the mouse on the Screen
 - *Cursor Y2*: enabling and positioning the cursor Y2 with the mouse on the Screen
- E. selecting the channel the cursors Y1 and Y2 refer to

Scale and autoscale options


To modify the features of the scale and autoscale change open the window Oscilloscope options by pushing the button .



In the window Oscilloscope options you can find:


- A. option of command Autoscale forcing to zero the channels offset
- B. option of command Autoscale modifying the offset in order to maximize the scale
- C. option of scale change setting the average tracks value on the Screen
- D. option of scale change setting the tracks zero on the Screen
- E. option of scale change maintaining the tracks offset

Screen dimensions

To modify the dimensions of the window Oscilloscope Screen, drag the window borders with the mouse. If the window is closed push the button .

Screen preferences

To modify the Screen preferences open the window Properties - ScopeX Control, by double clicking with the mouse left button on the window Oscilloscope Screen.




In the tab *Graph*, of the window Properties - ScopeX Control, you can find:

- A. box regarding the main grid
- B. option used to display the grid
- C. box regarding the axes
- D. option used to display the axes
- E. total number of divisions of the main grid
- F. position of the axes origin expressed according to the divisions number of the main grid
- G. number of subdivisions reported on the axes, for each division of the main grid
- H. options used to display the logarithmic scales
- I. selecting the colour of the main grid
- J. selecting the axes colours

Tracks preferences

To modify the tracks preferences open the window Properties - ScopeX Control, by clicking twice with the mouse left button on the window Oscilloscope Screen.



In the tab *Elements*, of the window *Properties - ScopeX Control*, you can find:

- A. selection of the channel to modify
- B. track dimension
- C. track scale change (see the point I in [Section 23.2, Monitoring by oscilloscope](#))
- D. modification of the track offset (see the point F in [Section 23.2, Monitoring by oscilloscope](#))
- E. option used to display the name of the captured parameter on the Screen
- F. displayed name
- G. option used to display the track zero
- H. selecting the track line type
- I. option used to fill the track points with the same colour selected at the point K
- J. selecting the track points type
- K. selecting the track points colour
- L. selecting the track colour
- M. selecting the channel mode (see the point H in [Section 23.2, Monitoring by oscilloscope](#))
- N. option used to display the channel scale

Chapter 24

Fault and Warning

The drives of the series *iBMD*, when finding some anomalies during working or some errors in the parameters setting, notify the error. Errors are divided into two categories depending on their seriousness:

- **Warning**, error which notifies a non-serious condition of the drive
- **Fault**, error preventing and stopping the motor motion; the drive is often in a serious error condition.

When the drive is enabled, the Faults are divided in two types:

- **Fatal fault**, Faults immediately preventing from controlling the motor motion
- **Non fatal fault**: faults letting you temporarily control the motor motion.

Errors can be:

- **Dynamic**, if the error condition is still present in the drive (otherwise the warning automatically disappear)
- **Retentive**, if the error is stored by the drive until it is reset.

In the following table you can find the features of the [MainError](#), the bit which any error is associated to and the features of the masks defining the behaviour of the drive in case of Fault. The abbreviations WD, WR, FD, FR, FA, FE and FS have the following meaning:

- WD ([WarnDynamic](#)): main Dynamic Warnings

- WR (**WarnRetentive**): main Retentive Warnings
- FD (**FaultDynamic**): main Dynamic Faults
- FR (**FaultRetentive**): main Retentive Faults
- FA: Faults that can be set as self-restoring (the Fault Reset command is automatically run)
- FE: Faults that can be deactivated
- FS: Faults that can generate the **Safety profile**.
- FF: errors of Fatal Fault type.

Bit	Error	MainError				FaultMask			FF
		WD	WR	FD	FR	FA	FE	FS	
0	DC bus over voltage	YES	YES	YES	YES	-	-	-	YES
1	Thermal management	YES	YES	YES	YES	-	-	-	-
2	Reserved	-	-	-	-	-	-	-	-
3	DC bus under voltage	YES	YES	YES	YES	YES	YES	-	YES
4	Power or motor short circuit	-	-	YES	YES	-	-	-	YES
5	Parameters soft error	YES	-	-	-	-	-	-	-
6	Parameters serious error	YES	-	YES	YES	-	-	-	-
7	Real time mode error	-	-	YES	YES	-	YES	YES	-
8	CAN communication error	YES	YES	YES	YES	-	YES	YES	-
	EtherCAT communication error	YES	YES	YES	YES	-	YES	YES	-
9	Reserved	-	-	-	-	-	-	-	-
10	Power or motor over current	YES	YES	YES	YES	-	-	-	YES
11	Reserved	-	-	-	-	-	-	-	-
12	Position following error	YES	YES	YES	YES	-	YES	-	-
13	Last command requested failed	YES	YES	YES	YES	-	-	-	-
14	/STO Management Error	-	-	YES	YES	-	-	-	YES
15	User Fault	-	-	YES	YES	-	YES	-	-
16	I2T limit reached	YES	YES	YES	YES	-	YES	-	-
17	I2T Warning threshold reached	YES	YES	-	-	-	-	-	-
18 - 19	Reserved	-	-	-	-	-	-	-	-
20	Limit reached	YES	-	-	-	-	-	-	-
21	Possible no tuning of regulator	YES	YES	-	-	-	-	-	-
22	Drive is in disable state, since the enable input is or has been in not active state	YES	YES	-	-	-	-	-	-
23	Feedback sensor error	-	-	YES	YES	-	-	-	YES
24	Digital IO configuration error	-	YES	YES	YES	-	-	-	-
25	Logic voltage error	YES	YES	YES	YES	-	YES	-	-
26	Motion parameter limited	YES	-	-	-	-	-	-	-
27	Digital output overtemperature or overload	YES	YES	-	-	-	-	-	-
28	Over Speed	-	-	YES	YES	-	-	-	YES
29 - 30	Reserved	-	-	-	-	-	-	-	-
31	Internal Error	-	-	YES	YES	-	-	-	-




Table 24.1. Features of the MainError.

NOTE

To choose the self-restoring Faults, use the **FaultMaskAutoErase** parameter.
 To choose the Faults to enable/disable, use the **FaultMaskEnable** parameter.
 To choose the Faults generating the **Safety profile**, use the **FaultMaskSafetyPrfExecute** parameter.


24.1. Management of the errors with MotionDrive

In the tab Main of MotionDrive, in the frame *Drive error* you can find two indicators showing the status of the Warnings and of the Faults. The colours have the following meaning:

- [0 - 0]  indicator switched off, no error
- [0 - 1]  orange light, Warning presence
- [1 - 1]  red light, Fault presence.

Next to the indicators you can find the number of the found errors. The number on the left shows the number of the errors of dynamic type, the number on the right shows the number of errors of retentive type, both for Faults and for Warnings. To see the details of the errors, open the window Show errors:

Main menu > Drive > Show errors ...

Tab Main > 




Figure 24.1. Window Show errors.



In the window Show errors, every error is placed next to an indicator, the colour of which has the following meaning:

-  green indicator, no error

- yellow light, Warning
- orange light, Warning becoming Fault if you try to enable the drive
- red light, Fault.

The errors are written in [Section 24.6, Errors description](#).

NOTE

To reset the errors push the button . To stop the updating of the errors shown in the page, push the button .

24.2. Monitoring the errors on the status leds

The iBMD drives show the status of the errors through the L1 and L2 leds ([Section 7.3, Leds](#)) that can take the following colours:

- green led, no error found, showing the enabling status of the drive (see [Table 8.10](#))
- orange led, only Warnings and no Faults are present.
- red led, Faults presence.

In case of more errors, the leds only show the error that in the following chart has the lowest visualization order (that corresponds to a higher priority).

IMPORTANT

In the boot and firmware start up phases of the iBMD the below description of the leds is no more valid. Please refer to [Chapter 26, Software updating](#)

Error	L1	L2	Order
CAN communication error	1 FL	ON	11
EtherCAT communication error			
Real time mode error	1 FL	BLK	12
Position following error	1 FL	1 FL	13
Limit reached	1 FL	2 FL	14
I2T limit reached	1 FL	3 FL	15
I2T Warning threshold reached	1 FL	3 FL	16
Parameters soft error	2 FL	BLK	17
Possible no tuning of regulator	2 FL	1 FL	18
Motion parameter limited	2 FL	2 FL	19
User Fault	2 FL	ON	21
Over Speed	3 FL	1 FL	23
Internal Error	3 FL	ON	24
/STO Management Error	BLK	ON	6
Feedback sensor error	BLK	BLK	7
Last command requested failed	BLK	1 FL	8

Error	L1	L2	Order
Parameters serious error	BLK	2 FL	9
Digital IO configuration error	BLK	3 FL	10
Digital output overtemperature or overload	BLK	3 FL	20
Drive is in disable state, since the enable input is or has been in not active state	BLK	ON	22
DC bus over voltage	ON	BLK	0
Power or motor short circuit	ON	ON	1
Power or motor over current	ON	ON	2
Thermal management	ON	1 FL	3
DC bus under voltage	ON	2 FL	4
Logic voltage error	ON	3 FL	5

Table 24.2. Status of the L1 and L2 leds for drives iBMD in case of error.

NOTE

The leds activation depends on some parameters. The value of the **FaultRetentive** parameter, if different from 0, determines the activation of the red colour leds. If there are no Faults, but Warnings only, then the orange leds depend by the most significant bit between the ones that are different from 0 in the **WarnDynamic** and **WarnRetentive** parameters (this bit is determined by executing the OR logic operation between the two parameters).

24.3. Reaction to the Warnings

When an error of Warning type occurs, the drive runs the following operations:

1. the bits of the parameters **WarnDynamic**, **WarnRetentive** and of any other parameter showing the details are set
2. In the CAN versions if a communication error is present and if a Warning of the **CAN communication error**, **CANOpenEmcyService** and/or **CANOpenEmcyProcess** parameters is active, then bit0 and bit4 of **ErrorRegister** are set.
3. with the CAN versions if a communication error is detected then the messages of EMCY are sent to the CANopen network (see [Section 9.2, Emergency object \(EMCY\)](#))
4. if no Faults are active (**FaultRetentive** is equal to 0), the leds show the Warning according to the order in [Table 24.2](#)
5. the state of the CiA402 State Machine is not modified (see [Section 8.5, CiA402 state machine](#)).

NOTE

When the error condition that generated the Warning is no longer noticed, the corresponding bits in the dynamic Warning parameters are reset.


In [Table 24.1](#) you can find the errors of Warning type.

If all the causes that have activated the bit4 of **ErrorRegister** are removed, then the bit resets and, if it was the only present alarm, then even the bit0 resets.

24.4. Reaction to the Faults

When an error of Fault type occurs, the drive executes the following operations:


1. the bits of the parameters [FaultDynamic](#) and [FaultRetentive](#) and of any other parameter showing the details are set
2. The bit (or the bits) that's related to the error type and the bit 0 of the [ErrorRegister](#) are set.
3. with the versions CAN the messages of EMCY are sent to the network CANopen
4. viene visualizzato dai led il Fault secondo l'ordine riportato in [Table 24.2](#)
5. the CiA402 State Machine goes to the *Fault Reaction Active* state (see [Section 8.5, CiA402 state machine](#))
6. One of the following operations is executed on the motor:
 - If the fault is a Fatal Fault, then the motor is immediately disabled (see Faults with FF property in the [Table 24.1](#));
 - If the fault is NOT a Fatal Fault and has not been deactivated, even if it is self restoring, (see Faults with FA and FE properties in the [Table 24.1](#)) then the drive executes a ramp stop and the motor disabling according to the [FaultReactionOptionCode](#) parameter setting;
 - If the fault is NOT a Fatal Fault and requires the [Safety profile](#) (see Faults with FS properties in [Table 24.1](#)), that can be set through the [SafetyPrfCommand](#) and [FaultMaskSafetyPrfExecute](#) parameters, then the drive executes the positioning and the disabling of the motor.

 NOTICE

If contemporary more faults happen and between these there are some with different severity (and so each one provides a different reaction) it's important to know that the 3 different reactions (above described on point 6) have a different priority:

- The more serious the Fault is, the more high is the priority.

In other words the FatalFault reaction has the highest priority, then follows the Fault reaction that requires the ramp stop, while the reaction that requires the positioning in the security position has the lowest priority.

 NOTICE

If all the causes that have activated a particular bit of [ErrorRegister](#) are removed, then that bit resets; if all the alarm causes are removed, then even the generic bit0 is reset.

The settings about Faults deactivation, self-restoring and selection of the motor deceleration ramp before the disabling, can be easily managed through the "Errors" table in the Drive Setup.

Access through MotionDrive:

Main menu > Drive > Drive Setup ... > Errors

Tab Main >  > Errors

Motor and drive Brake Polarity Digital I/O Analog input Captures Limits and windows settings Control mode Loops settings Homing Errors		
Fault	Alarm enabled	Alarm autoerase
Under voltage power section	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Real time mode error	<input checked="" type="checkbox"/>	
CAN communication error	<input checked="" type="checkbox"/>	
Following error position	<input checked="" type="checkbox"/>	
User fault	<input checked="" type="checkbox"/>	
I2T limit reached	<input type="checkbox"/>	
Logic voltage error	<input checked="" type="checkbox"/>	

Fault reaction option code: Zero speed and waiting for motor stop

Zero speed and waiting for motor stop

Slow down on Profile deceleration ramp

Slow down on Quick stop deceleration ramp

- In the windows on the right it's possible to select which Faults are active (Alarm enable) and self-restoring (Alarm autoerase).
- In the drop-down menu on the bottom it's possible to select the deceleration ramp type that precedes the axis disabling, in case of the detection of one of the active Faults. Every item of this menu corresponds to a value of the [FaultReactionOptionCode](#) parameter, in particular:
 - Zero speed and waiting for motor stop = -1;
 - Slow down on Profile deceleration ramp = 1;
 - Slow down on Quick stop deceleration ramp = 2;

⚠ ATTENTION

If a FE Fault is deactivated through the [FaultMaskEnable](#) parameter (see [Table 24.1](#)), the related Warning is anyway signaled, but the Fault reaction actions will not be executed.

NOTE

If the fault requires the possibility to solve with the [Safety profile](#) (see Faults with FS property on [Table 24.1](#)), and this profile has not been activated, the drive will execute the deceleration ramp as set on the [FaultReactionOptionCode](#) parameter.




Figure 24.2. Flow diagram of the reaction to the Faults.

NOTE

When the error condition that generated the Faults is no longer noticed, the corresponding bits in the dynamic Fault parameters are reset.

In Table 24.1 you can find the errors of Fault type.

Safety profile

The safety profile is a motion of the motor carried out in the reaction to the Faults to take the motor to a safe position. As a Fault is detected, check if the drive is the [Operation enable](#) state, if the profile is enabled (see [SafetyPrfCommand](#)) and if the detected Fault allows its running (see [FaultMaskSafetyPrfExecute](#)). If all the conditions are respected the operation shown in [SafetyPrfCommand](#) is run.

24.5. Resetting the errors

NOTICE

It is up to the operator to find and to eliminate the causes that have caused the Fault condition before running a command of Fault Reset. The continuous repetition of the command of Fault Reset without removing the causes could cause some permanent damage to the drive.

To reset only the errors of retentive Warning type, write the [WarnRetentive](#) parameter; any written value is accepted.

IMPORTANT

Before resetting the errors it is necessary to remove all the causes that generated them.

To reset all errors, only if the CiA402 State Machine is in the *Fault* state (see [Section 8.5, CiA402 state machine](#)), write the Fault reset command in the [Controlword](#). The command consists of a transition from 0 to 1 of the bit 7 of the [Controlword](#) following these symbols: xxxx xxxx \bar{x} xxx xxxx (the status of the bits shown with 'x' is not important to determine the command). This command resets the errors of retentive type, only if there are some retentive Faults ([FaultRetentive](#) different from 0). The CiA402 State Machine switches to the *Switch On Disabled* state (see [Section 8.5, CiA402 state machine](#)) only if there are no other Faults ([FaultDynamic](#) value is 0).

NOTE

Power or motor short circuit and Power or motor over current do not allow the running of the command Fault Reset before at least 20 seconds after the Fault event.

24.6. Errors description

DC bus over voltage

Overvoltage for the power supply of the power section (DC bus) (Warning = 800 V; Fault = 840 V). Check the size of the power supply and the electrical connections. For any further information, see [Section 14.3, Regeneration](#). The DC bus voltage can be monitored through the [DCBusVoltage\(+HV\)](#) parameter.

Thermal management

Error related to the drive thermal management. The details can be found in the following chart and in the parameters [ThermalManageError](#).

Bit	Name	Type	Description
0	Power over temperature	W/F	Overtemperature of the power section (Warning = 105°C; Fault = 110°C). Check the environment temperature and the ventilation of the power section.
1	Control over temperature	W/F	Overtemperature of the control section (Warning = 85°C; Fault = 95°C). Check the environment temperature.

Bit	Name	Type	Description
			ture, the ventilation and the power consumption of the control section with an external amperometer. Check that the values of the current, that are reported in the Chapter 5, Technical features , are respected
2	Motor over temperature	W/F	Overtemperature of the motor (Warning = 10°C before of the Fault threshold; Fault = it depends on which motor is used). To know the Fault threshold value : from MotionDrive see MotorParameters table, from parameter see FaultTemperatureThrs . Verify the environment temperature, the ventilation, the dissipation, analyze the working cycle in relation to the motor performance and torque curves
3	Fan 1 stuck	W	Fan 1 stuck. Clean the fans and try again.
4	Fan 2 stuck	W	Fan 2 stuck. Clean the fans and try again.
5	Fan 3 stuck	W	Fan 3 stuck. Clean the fans and try again.
6	Power temp. sensor hardware failure	F	Failure of the Power Temperature Sensor of the power section. Please contact Bonfiglioli
7	Logic temp. sensor hardware failure	F	Failure of the Temperature Sensor of the control section. Please contact Bonfiglioli
8	Motor temp. sensor hardware failure	F	Failure of the Motor Temperature Sensor. Please contact Bonfiglioli
9	Feedback sensor over temperature	W/F	Feedback sensor over temperature. This error is present only if the position sensor is provided of the temperature sensor (and then the temperature measurement is supported by the hardware) Verify the environment temperature, the ventilation, the dissipation, analyze the working cycle in relation to the motor performance and torque curves.
10	Motor temperature sensor unknown - selection forced to none sensor	W	Temperature sensor unknown The firmware doesn't recognize the temperature sensor code, the system will maintain as selected the sensor that has been set by the user, but will internally manage it as it had been selected "None sensor" (MotorTemperatureSensorType = 0), so without monitoring the motor temperature. Every time that the system is turned off and on again and finds a sensor that's not provided by the firmware, this Warning will recur unless a motor without a temperature sensor, or with a supported one, is saved in EEPROM (see MotorTemperatureSensorType).
11 - 15	Reserved		

Table 24.3. Details about [ThermalManageError](#) (W = Warning, F = Fault, W/F = both).

DC bus under voltage

Undervoltage for the power supply of the power section (DC bus) (Warning = 200 V; Fault = 150 V). Check the output voltage of the secondary of the transformer and the input voltage of the converter (if are present), check the drive supply voltage and the wirings, use the oscilloscope to monitor the power section voltage and to check its trend and, if in some particular motion condition a voltage drop happens, decrease the velocities and the accelerations of the working cycle and/or substitute the power supply with another one more powerful. The DC bus voltage can be monitorized through the [DCBusVoltage\(+HV\)](#) parameter.

Power or motor short circuit

Power or motor short circuit error. Wait for 20 seconds before running the Fault Reset to allow the dissipation of the accumulated power. Check that the insulation voltage of the motor windings is compatible with the drive supply voltage. If the problem persists, please contact Bonfiglioli.

Parameters soft error

Soft error in the drive parametrization. You can find the details in the following chart and in the parameter [ParamSoftError](#) and [AI0CalibrationStatus](#).

Bit	Name	Type	Description
0	I2T Limited to max drive value	W	UserMaxI2T higher than DriveMaxI2T . Decrease UserPeakCurrent and/or I2TTime .
1	Peak current too high for motor or drive	W	UserPeakCurrent higher than MotorPeakCurrent and/or MaxPeakCurrent . Decrease UserPeakCurrent .
2 - 4	Reserved		
5	Loops configuration selected is not supported	W	LoopConfiguration not supported by the current firmware. Update the firmware or change configuration.
6	Software position limits incompatibility	W	PositionLimitPositive lower than PositionLimitNegative . Correct the limits
7	Capture Trigger Source equal on both Capture peripheral	W	CaptureTriggerInput_A equal to CaptureTriggerInput_B . Choose two different values.
8 - 9	Reserved		
10	Capture A: Filter or trigger on both edges not allowed on selected trigger input	W	If it has been tried to contemporary set the capture on Index and the space filter (CaptureSource0_A) or the capture on both edges. Or it has been tried to set the space filter (CaptureSource0_A) with the CiA402 mode. Or it has been tried to modify the capture trigger with capture enabled.
11	Capture B: Filter or trigger on both edges not allowed on selected trigger input	W	If it has been tried to contemporary set the capture on Index and the space filter (CaptureSource0_B) or the capture on both edges. Or it has been tried to set the space filter (CaptureSource0_B) with the CiA402 mode. Or it has been tried to modify the capture trigger with capture enabled.
12	Capture A: Selected trigger not available (previous value has been kept)	W	The last value written in CaptureTriggerInput_A has been refused since it is not supported by the current firmware. Verify that the inserted data is valid, if necessary update the firmware.
13	Capture B: Selected trigger not available (previous value has been kept)	W	The last value written in CaptureTriggerInput_B has been refused since it is not supported by the current firmware. Verify that the inserted data is valid, if necessary update the firmware.
14	Reserved		
15	Capture setup using disabled parameters' interface (look at parameter ' CaptureInterfaceMode ')	W	It has been tried to access, in reading or writing, to the not selected interface (see CaptureInterfaceMode parameter). This bit cannot auto-reset, but must be reset by the user.

Table 24.4. Details about [ParamSoftError](#) (W = Warning, F = Fault, W/F = both).

Parameters soft error is active even when [AI0CalibrationStatus](#) assumes the following values (W = Warning, F = Fault, W/F = both).

Value	Name	Type	Description
0	Analog input 0 is not calibrated	W	Analog input 0 is not correctly calibrated. Run the calibration according to what is reported in Section 17.2, Calibration or update the current configuration and the permanent memory with the default values.
1	Analog input 0 calibration not complete (only offset)	W	
2	Analog input 0 calibration not complete (only gain)	W	

Parameters serious error

Serious error in the drive parametrization. The details can be found in the following chart and in the parameters [ParamSeriousError](#). The Warning becomes a Fault if you try to enable the drive.

Bit	Name	Type	Description
0	Stall current not set	W/F	MotorStallCurrent is equal to 0. Turn the drive off and then on again. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
1	Motor peak current not set	W/F	MotorPeakCurrent is equal to 0. Turn the drive off and then on again. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
2	Motor torque constant not set	W/F	TorqueConstant(ForceConstant) is equal to 0. Turn the drive off and then on again. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
3	Motor inductance not set	W/F	MotorInductance is equal to 0. Turn the drive off and then on again. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
4	Motor resistance not set	W/F	MotorResistance is equal to 0. Turn the drive off and then on again. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
5	Motor inertia not set	W/F	MotorInertia(MotorMass) is equal to 0. Turn the drive off and then on again. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
6	Motor pole number not set	W/F	MotorPoles is equal to 0. Turn the drive off and then on again. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
7	Motor rated speed not set	W/F	MotorRatedSpeed is equal to 0. Turn the drive off and then on again. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
8	Sensor not set	W/F	FeedbackSensorCode is equal to 0. Turn the drive off and then on again. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
9	Max rated current not set	W/F	MaxRatedCurrent is equal to 0. Please contact Bonfiglioli Mechatronic Research S.p.a
10	Max peak current not set	W/F	MaxPeakCurrent is equal to 0. Please contact Bonfiglioli Mechatronic Research S.p.a
11	Current not calibrated	W/F	Please contact Bonfiglioli Mechatronic Research S.p.a
12	Voltage not calibrated	W/F	Please contact Bonfiglioli Mechatronic Research S.p.a
13	Sensor not supported	W/F	FeedbackSensorCode not supported by the current firmware. Update the firmware or change the sensor.
14	Sensor not phased	W/F	Feedback sensor phasing problems. The cause is specified by the Feedback sensor error . Reset the errors, if the problem persists please contact Bonfiglioli Mechatronic Research S.p.a.

Bit	Name	Type	Description
15	Pole pitch not set	W/F	PolePitch is equal to 0. Turn the drive off and then on again. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.

Table 24.5. Details about [ParamSeriousError](#) (W = Warning, F = Fault, W/F = both).

Real time mode error

Error of *Interpolated Position Mode*. The details can be found in the following chart and in the parameter [RealTimeModeError](#).

The following descriptive table refers to the parameters for the interpolation and to the synchronization methods. Their use is intended according to the following rules:

With *parameters for the interpolation* is meant:

- if [ModesOfOperationDisplay](#) = 7 → [IpPosFirstParameter](#) and [IpPosSecondParameter](#) (the second one is not necessary if [IpPosSubModeSelect](#) value is 0);
- if [ModesOfOperationDisplay](#) = 8 → [TargetPosition](#) and [VelocityOffset](#) (the second one is necessary only if [CyclicSynchronousSubMode](#) value is -147 or -148);
- if [ModesOfOperationDisplay](#) = 9 → [TargetVelocity](#);
- if [ModesOfOperationDisplay](#) = 10 → [TargetTorque](#);

The limits of the *parameters for the interpolation* related to alarm that corresponds to the bit5, according to the value of [ModesOfOperationDisplay](#), mean that:

- in a T_{SYNC} period the resultant position difference must be lower than 16.38 rev. The position difference is calculated according to the value that's written in the [IpPosFirstParameter](#) parameter if [ModesOfOperationDisplay](#) value is 7 or according to the value of [TargetPosition](#) if [ModesOfOperationDisplay](#) value is 8;
- the velocity must be lower than ± 3216 rad/s. The velocity set in [IpPosSecondParameter](#) if [ModesOfOperationDisplay](#) value is 7, in [VelocityOffset](#) if [ModesOfOperationDisplay](#) value is 8, in [TargetVelocity](#) if [ModesOfOperationDisplay](#) value is 9;

With *synchronization method* is meant:

- with CANopen drive, see [Section 9.3, Synchronization object \(SYNC\)](#)
- with EtherCAT drive, see [Section 10.4, Synchronization](#)

Bit	Name	Type	Description
0	CANopen not in operational state	F	The NMT state machine is not in the OPERATIONAL state (only in the versions CAN). This Fault is caused by: <ul style="list-style-type: none"> • it has been required to change the state of the NMT state machine with the NMT service; • the drive signals CAN communication error; analyse the error details.
	EtherCAT not in operational state		The EtherCAT state machine is not in the OPERATIONAL state (only in the versions ETC). This Fault is caused by: <ul style="list-style-type: none"> • it has been required to change the state to the EtherCAT state machine; • the drive signals EtherCAT communication error; analyse the error details.
1	Pdo missing	F	The parameters for the interpolation were not received via PDO, before the synchronization; correctly manage

Bit	Name	Type	Description
			the PDOs in the master according to the synchronization method.
2	Incompatibility of cubic interpolation parameter	F	Cubic interpolation parameters not coherent. Check that the data that are being sent by the master are correct.
3	Wrong cubic interpolation cycle period	F	T _{SYNC} too short. Increase the period according to the synchronization method and to the ModesOfOperationDisplay (For further details see what is reported in each single operative mode in the Chapter 22, Creating a motion).
4	Wrong interpolation cycle period	F	
5	Interpolation parameters out of range	F	Interpolation parameters out of allowed ranges. Check that the data that are being sent to the master are correct and respect the limits set in the drive.
6	Incompatibility interpolation sub mode	F	The CyclicSynchronousSubMode is not compatible with the ModesOfOperationDisplay . Check the settings according to the contents of Table 27.16 .
7 - 15	Reserved		

Table 24.6. Details about [RealTimeModeError](#) (W = Warning, F = Fault, W/F = both).

CAN communication error

NOTE

The information in this paragraph are valid only for the drives version CAN.

Main port communication error CANopen. The details can be found in the following charts and in the parameters [CANopenEmcyRegister](#).

Bit	Name	Type	Description
0	This bit is equal to 1 if at least one emergency has been sent.		
1	CAN in error passive state	W	CAN in the Error-passive state state; analyze the causes by reading the group of parameters CANopenCounters .
2	Life guard error	F	Error of <i>Life Guard</i> . See Error control services ; check the wiring.
3	Recovered from bus-off	W	Drive retrieved from the Bus-off state state; analyze the causes by reading the group of parameters CANopenCounters .
4	Sync controller error	F	Error in the SYNC controller. See Section 9.3, Synchronization object (SYNC) .
5 - 7	Reserved		
8	Peripheral initialization error	W	Error during the hardware peripheral initialization phase; check the wirings. See Section 7.2.3, Field bus (CAN) .
9 - 24	Reserved		
25	Message overrun: Node guard (RX)	W	CANopen overrun: overwritten NODEGUARD RX; manage a longer life time period with the master (see Error control services) or diminish the network load CANopen.
26	Message overrun: Node guard (TX)	W	CANopen overrun: overwritten NODEGUARD TX; manage a longer life time period with the master (see Error control services) or diminish the network load CANopen.

Bit	Name	Type	Description
27	Message overrun: SDO (RX)	W	CANopen overrun: overwritten SDO RX; diminish the network load CANopen.
28	Message overrun: SDO (TX)	W	CANopen overrun: overwritten SDO TX; diminish the network load CANopen.
29	Message overrun: EMCY	W	CANopen overrun: overwritten EMCY; diminish the network load CANopen.
30	Message overrun: SYNC	W	CANopen overrun: overwritten SYNC; manage a SYNC with the master with a longer CommunicCyclePeriod .
31	Message overrun: NMT	W	CANopen overrun: overwritten NMT.

Table 24.7. Details about *CANopenEmcyService* (W = Warning, F = Fault, W/F = both).

Bit	Name	Type	Description
0	Message overrun: PDO TX 1	W	The PDO 1 TX has been overwritten: <ul style="list-style-type: none"> if the overrun comes from a PDO sending the results to the capture peripheral, increase the inhibit time of the related peripheral (see Chapter 18, Capture Peripherals); if the overrun comes from a generic PDO, increase the inhibit time of the PDO (see Section 27.23, PDO managed by the port CANopen (10000-11999)).
1	Message overrun: PDO TX 2	W	The PDO 2 TX has been overwritten; see the description of the PDO TX 1.
2	Message overrun: PDO TX 3	W	The PDO 3 TX has been overwritten; see the description of the PDO TX 1.
3	Message overrun: PDO TX 4	W	The PDO 4 TX has been overwritten; see the description of the PDO TX 1.
4 - 7	Reserved		
8	Message overrun: PDO RX 1	W	The PDO 1 RX has been overwritten; slow the timing the PDO is sent from the producer of the PDO itself (the producer is the node sending the PDO to the network CANopen).
9	Message overrun: PDO RX 2	W	The PDO 2 RX has been overwritten; see the description of the PDO RX 1.
10	Message overrun: PDO RX 3	W	The PDO 3 RX has been overwritten; see the description of the PDO RX 1.
11	Message overrun: PDO RX 4	W	The PDO 4 RX has been overwritten; see the description of the PDO RX 1.
12 - 15	Reserved		
16	PDO RX 1 too short	W	PDO 1 RX with data field length too short: the sent data have no effect; verify that the PDOs that have been programmed in the master and in the slave are coherent.
17	PDO RX 2 too short	W	PDO 2 RX with data field length too short: the sent data have no effect; see the description of the PDO RX 1.
18	PDO RX 3 too short	W	PDO 3 RX with data field length too short: the sent data have no effect; see the description of the PDO RX 1.
19	PDO RX 4 too short	W	PDO 4 RX with data field length too short: the sent data have no effect; see the description of the PDO RX 1.
20 - 23	Reserved		
24	PDO RX 1 too long	W	PDO 1 RX with data field length too long: verify that the PDOs that have been programmed in the master and in the slave are coherent.

Bit	Name	Type	Description
25	PDO RX 2 too long	W	PDO 2 RX with data field length too long: see the description of the PDO RX 1
26	PDO RX 3 too long	W	PDO 3 RX with data field length too long: see the description of the PDO RX 1
27	PDO RX 4 too long	W	PDO 4 RX with data field length too long: see the description of the PDO RX 1
28 - 31	Reserved		

Table 24.8. Details about *CANopenEmcyProcess* (W = Warning, F = Fault, W/F = both).

EtherCAT communication error

NOTE

The information in this paragraph are valid only for the drive version ETC.

Main port communication error EtherCAT. The details can be found in the following chart and in the parameters [EtherCAT_Diagnostics](#).

Bit	Name	Type	Description
0	Sync Manager watchdog expired	F	The watchdog of the Sync manager (SM) of the PDO RX expired; the PDO RX has not been received; manage correctly in the master the sending of the PDO RX or read the watchdog times in the registers of the ET1100.
1	Sync 0 watchdog expired	F	The watchdog of the Sync Signal 0 expired; set and enable correctly the signal Sync Signal 0 and the watchdog times in the registers of the ET1100.
2	PLL Error	F	PDO and Sync Signal 0 are not synchronized; manage correctly in the master the sending of the PDO before the synchronization; the synchronization methods can be found in Section 10.4, Synchronization .
3	Synchronization Error	F	The PDOs RX don't arrive or however not in correspondence to the set synchronization reference (see Section 10.4, Synchronization), within a tolerance from [Sync/2] to [Sync + Sync/2] with a maximum value of [Sync + 1ms]; verify that the PDOs RX are sent by the master in correspondence to the synchronization reference.
4 - 7	Reserved		
8	Hardware failure	W	Serious error in ET1100; please contact Bonfiglioli Mechatronic Research S.p.a
9	ESI eeprom may not be updated	W	ESI eeprom not updated; update the ESI eeprom according to what's reported in Section 26.6, ESI EEPROM updating procedure on ETC drive .
10	ESI eeprom will be updated at the next power-up cycle	W	ESI eeprom not updated; in case the drive characteristics allow the ESI eeprom automatic update, when a firmware download ends then the drive is ready to execute it on next start-up.
11	ESI eeprom updating at the power-up failed	W	ESI eeprom not updated; the automatic procedure has failed due to a drive HW problem, execute the ESI eeprom manual update procedure according to what's reported in Section 26.6, ESI EEPROM updating procedure on ETC drive .
10 - 31	Reserved		

Table 24.9. Details about *EtcErrorRetentCommMsg* (W = Warning, F = Fault, W/F = both).

Power or motor over current

Too high and anomalous current in the power section or in the motor phases. The overcurrent values can be found in [OverCurrentAValue](#), [OverCurrentBValue](#) and [OverCurrentCValue](#). It generally happens when the drive is not on condition to correctly control the current due to an anomaly or a non optimal parametrisation (tuning). If the alarm stands for a short time period and it's a Warning, it means that the overcurrent has lasted for a short time, not dangerous for the drive; if the alarm is a Fault it means that the overcurrent has a value and a duration such that the drive might damage. Check the current loop tuning and decrease its dynamic response. Decrease the value of [UserPeakCurrent](#). Check that the insulation voltage of the motor windings is compatible with the drive supply voltage.

This anomaly can happen even when [ActualFieldCurrent](#) < -50%IS and very steep decelerations are executed. In these conditions the DC bus supply voltage turns out to be not sufficient to control the current, the counter-electromotive force of the motor increases the currents to values that are higher than the limit and the over current may be reported. If this condition continues, during the Warning presence, it can become a Fault. Decrease the deceleration ramps or the starting ramp velocity, increase the DC bus supply voltage.

Wait 20 seconds before to execute the Fault Reset, in order to allow the dissipation of the stored energy. If the problem persists, please contact Bonfiglioli.

Position following error

The [PositionFollowingError](#) exceeded the specified thresholds, according to what is reported in [Error of position tracking](#): check if the motor motion is compatible with the settings. The Fault can be disabled by writing the [FaultMaskEnable](#) parameter; the Warning cannot be disabled.

Last command requested failed

The last command of the [SysMngCommand](#) has concluded with an error. The details and the solutions of the error can be found in the parameter [SysMngError](#).

/STO Management Error

Error related to the /STO input management. The details are reported in this table and in the [STOError](#) parameters.

Bit	Name	Type	Description
0	/STO = 0V with drive enabled	F	It occurs in the following cases: <ul style="list-style-type: none"> The drive is in Drive enable state and the voltage on the /STO digital input fails → Disable the drive before to cut off the voltage supply to the /STO input. It has been tried to enable the drive without the /STO signal → Provide voltage to the /STO input before to give the enabling command.
1	/STO input level not in valid range	F	The voltage level that's applied on the /STO input has lasted more than 500ms in the intermediate range of values of the voltage thresholds (see Figure 6.3). Be sure that the transition between the voltage levels, from the electrical point of view, takes no more than 500ms and that the voltage values are within the correct ranges (see /STO input electric features)

Bit	Name	Type	Description
2 - 15	Reserved		

Table 24.10. Details about **STOError** (W = Warning, F = Fault, W/F = both).

User Fault

Error managed directly by the user. It can be useful when, in case of dangerous situations, the user thinks it is necessary to stop the drive working and report a Fault. The details can be found in the following chart and in the parameters **UserError**.

Bit	Name	Type	Description
0	User Fault 1	F	User fault number 1
1 - 15	Reserved		

Table 24.11. Details about **UserError** (W = Warning, F = Fault, W/F = both).

I2T limit reached

I2TValue has reached the 100%, that is the drive has reached the highest level of overload. If the Fault is active the drive is in Fault state, otherwise only the Warning is reported and the motor current reaches the value **NominalCurrent**. See what reported in [Section 25.6, Motion problems](#).

I2T Warning threshold reached

I2TValue reached the specified threshold in **I2TWarningThreshold**. The motor current is not limited. See what reported in [Section 25.6, Motion problems](#).

Limit reached

Limits reached by the motor motion (see [Chapter 19, Motion limits](#)). The details can be found in the following chart and in the parameter **LimitReachedError**.

Bit	Name	Type	Description
0	Positive software position limit reached	W	PositionActualValue higher than PositionLimitPositive .
1	Negative software position limit reached	W	PositionActualValue lower than PositionLimitNegative .
2	Positive hardware position limit reached.	W	Positive hardware position limit reached Positive limit switch (FC +) . If the position limit has not been activated by the machinery that's moved by the motor, verify that the switch has not been accidentally activated, that it's correctly powered, that the cable has not been cut, that's correctly connected with the connector CN4 's digital inputs.
3	Negative hardware position limit reached	W	Negative hardware position limit reached Negative limit switch (FC -) . If the position limit has not been activated by the machinery that's moved by the motor, verify that the switch has not been accidentally activated, that it's correctly powered, that the cable has not been cut, that's correctly connected with the connector CN4 's digital inputs.
4 - 7	Reserved		

Bit	Name	Type	Description
8	Max motor speed limit reached	W	VelocityActualValue limited by MaxMotorSpeed .
9 - 11	Reserved		
12	Torque limit reached	W	TargetTorque higher or equal to ActualTorqueLimitP in absolute value. Verify that there are not mechanical obstacles; if the limit is set through analog input (in the TorqueLimitSelector parameter has been set the value 2), verify the input value.
13	Peak current is zero	W	UserPeakCurrent is equal to 0. Set UserPeakCurrent .
14	Peak current limit reached	W	ActualMotorCurrent limited by UserPeakCurrent .
15	Reserved		

Table 24.12. Details about [LimitReachedError](#) (W = Warning, F = Fault, W/F = both).



If the **Polarity** is of Reverse type, then the roles of **Positive limit switch (FC +)** and **Negative limit switch (FC -)** are reversed: **Positive limit switch (FC +)** behaves like **Negative limit switch (FC -)** and **Negative limit switch (FC -)** behaves like **Positive limit switch (FC +)**. This is true both in the text of this manual and in the MotionDrive.

Possible no tuning of regulator

Because of the change of one or more motor parameters, of the sensor or of the power pwm, the regulation loops could not be correctly calibrated. It is advisable to check the loop calibration according to what is reported in [Chapter 20, System tuning](#), or use one of the commands in [Section 20.2, Reset the tuning](#).

Drive is in disable state, since the enable input is or has been in not active state

The digital input, to which the [Enable](#) functionality is related, is set to 0 logic state and it is required the drive enabling (take it to the [Drive enable](#) state), or, while the drive is enabled, the input which is programmed with the [Enable](#) functionality is set to 0 (is deactivated). This error report is not active in the *Profile Velocity AI Mode* and *Torque AI Mode* modes.

Feedback sensor error

An error related to a feedback position sensor malfunctioning has occurred. The details can be found in the following chart and in the parameters [FeedbackSensorError](#).

Code	Name	Type	Description
0x159	Phasing: Sensor code does not match	W	The phasing has been executed with a different sensor. If it's possible, repeat the phasing procedure, if not please contact Bonfiglioli Mechatronic Research S.p.a.
0x15A	Phasing: Polarity of quadrature signals A or B is wrong	F	The encoder A and B quadrature signals polarity is not correct. Check the encoder connections. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x15B	Phasing: Quadrature signals A or B are disconnected	F	The drive does not receive the encoder A and B quadrature signals. Check the encoder connections. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.

Code	Name	Type	Description
0x30A	Phasing: Hall sensors status is not valid	F	The drive does not receive the Hall sensor signals. Check the encoder connections. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x30B	Phasing: Validation window not respected	F	The alignment between the encoder and the motor position has failed. Check the encoder connections. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x30C	Phasing: Hall sensors sequence is wrong	F	The Hall sensor signals don't respect the right sequence. Check the encoder connections. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x359	Phasing: Sensor code does not match	W	The phasing has been executed with a different sensor. If it's possible, repeat the phasing procedure, if not please contact Bonfiglioli Mechatronic Research S.p.a.
0x35A	Phasing: Polarity of quadrature signals A or B is wrong	F	The encoder A and B quadrature signals polarity is not correct. Check the encoder connections. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x35B	Phasing: Quadrature signals A or B are disconnected	F	The drive does not receive the encoder A and B quadrature signals. Check the encoder connections. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x457	Phasing: Incremental counter initialization error	F	The alignment between the encoder and the motor position has failed. Check that, during this procedure, the motor is stopped and the encoder is correctly wired. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x459	Phasing: Sensor code does not match	W	The phasing has been executed with a different sensor. If it's possible, repeat the phasing procedure, if not please contact Bonfiglioli Mechatronic Research S.p.a.
0x45A	Phasing: Polarity of Sine or Cosine is wrong	F	The encoder Sine and Cosine quadrature signals polarity is not correct. Check the encoder connections. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x470	Position calculation error: Mismatch between Sine/Cosine and Incremental counter	W/F	Electrical problems on the reconstruction of the position from the Sine/Cosine signals. Reset the errors. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x471	Sine or Cosine value error	W/F	Electrical problems on the reconstruction of the position from the Sine/Cosine signals. Check the encoder connections. Reset the errors. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x472	Phasing: Number of Sine/Cosine is incompatible with number of motor poles	F	The feedback sensor cannot be used for the feedback of the selected motor. Select another sensor so that the pole pairs of the motor is an integer multiple of the number of sensor sinusoids/revolution.
0x473	Sine or Cosine level out of range	W	Electrical problems on the reconstruction of the position from the Sine/Cosine signals. Check the encoder connections. Reset the errors and execute the Hard Reset command (command 5000 of the System Manager). If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x474	Sine or Cosine hardware error	F	Drive internal electrical problems. Reset the errors and execute the Hard Reset command (command 5000 of the System Manager). If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.

Code	Name	Type	Description
0x501	Internal sensor error	F	Sensor internal error. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a
0x502			
0x503			
0x504			
0x505			
0x506			
0x507			
0x508			
0x509			
0x50A			
0x50B			
0x50C			
0x50D			
0x50E			
0x50F			
0x510			
0x511			
0x512			
0x51F			
0x520			
0x521			
0x522			
0x523			
0x51C			
0x51E			
0x530	Communication: Timeout receiving data	F	Communication error with the sensor. Reset the errors. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x531	Communication: Timeout sending data	F	Communication error with the sensor. Reset the errors. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x535	Communication: Out of memory	F	Communication error with the sensor. Stop the oscilloscope and try again. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x540	Communication: Checksum error	F	Communication error with the sensor. Reset the errors. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x541	Communication: Parity error	F	Communication error with the sensor. Reset the errors. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x542	Communication: Framing error	F	Communication error with the sensor. Reset the errors. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x543	Communication: Overrun error	F	Communication error with the sensor. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x557	Phasing: Incremental counter initialization error	F	The alignment between the encoder and the motor position has failed. Check that, during this procedure, the motor is stopped and the encoder is correctly wired. If

Code	Name	Type	Description
			the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x558	Phasing: Data not found (sensor serial number does not match)	W	The phasing has been executed with a different sensor. If it's possible, repeat the phasing procedure, if not please contact Bonfiglioli Mechatronic Research S.p.a.
0x559	Phasing: Sensor code does not match	W	The phasing has been executed with a different sensor. If it's possible, repeat the phasing procedure, if not please contact Bonfiglioli Mechatronic Research S.p.a.
0x55A	Phasing: Polarity of Sine or Cosine is wrong	F	The encoder Sine and Cosine quadrature signals polarity is not correct. Check the encoder connections. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x570	Position calculation error: Mismatch between analog and digital position	W/F	Electrical problems on the reconstruction of the position from analog and digital signals. Reset the errors. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x571	Sine or Cosine value error	W/F	Electrical problems on the reconstruction of the position from the Sine/Cosine signals. Check the encoder connections. Reset the errors. If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x573	Sine or Cosine level out of range	W	Electrical problems on the reconstruction of the position from the Sine/Cosine signals. Check the encoder connections. Reset the errors and execute the Hard Reset command (command 5000 of the System Manager). If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x574	Sine or Cosine hardware error	F	Drive internal electrical problems. Reset the errors and execute the Hard Reset command (command 5000 of the System Manager). If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x673	Sine or Cosine level out of range	W	Electrical problems on the reconstruction of the position from the Sine/Cosine signals. Check the resolver connections. Reset the errors and execute the Hard Reset command (command 5000 of the System Manager). If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.
0x674	Sine or Cosine hardware error	F	Drive internal electrical problems. Reset the errors and execute the Hard Reset command (command 5000 of the System Manager). If the problem persists, please contact Bonfiglioli Mechatronic Research S.p.a.

Table 24.13. Details about [FeedbackSensorError](#) (W = Warning, F = Fault, W/F = both).

Digital IO configuration error

The configuration of the functionalities associated to the digital I/O is not correct. The details can be found in the following chart and in the parameters [DigitalIoConfigError](#). The Warning becomes a Fault if you try to enable the drive.

Bit	Name	Type	Description
4-0	Code of the first hardware resource involved in the error	-	1 = I/O 0 2 = I/O 1 3 = I/O 2
9-5	Code of the second hardware resource involved in the error	-	4 = I/O 3 5 = In 4 6 = In 5 7 = In 6

Bit	Name	Type	Description
			8 = In 7 9 = In 8 10 = In 9 11 = Out 4 12 = Out 5 13 = Out 6
16-10	1 = Exclusive function assigned to both resources	W/F	Functionality to be assigned to a hardware resource has been assigned to two resources; reprogram the functionalities;
	2 = Step function assigned to this resource without Direction		Step functionality assigned without having assigned the Dir one; assign the lacking functionality;
	3 = Dir function assigned to this resource without Step		Dir functionality assigned without having assigned the Step one; assign the lacking functionalities;
	4 = Index function assigned to this resource without FA nor FB		Quadrature Input Index (Idx) functionality assigned without having assigned the Quadrature Input ChA (Ch A) and Quadrature Input ChB (Ch B) ones; assign the lacking functionalities;
	5 = FB function assigned to this resource without FA		Quadrature Input ChB (Ch B) functionality assigned without having assigned the Quadrature Input ChA (Ch A) one; assign the lacking functionality;
	6 = FA function assigned to this resource without FB		Quadrature Input ChA (Ch A) functionality assigned without having assigned the Quadrature Input ChB (Ch B) one; assign the lacking functionality;
	7 = Settings in permanent memory not compatible with firmware (default value restored)		The I/Os setting in the permanent memory is not compatible with the firmware in the drive, so the default values have been automatically restored; Reconfigure the I/Os with the functionalities that are allowed by the actual firmware or restore the firmware that allowed the use of the functionalities that are no more at disposal.

Table 24.14. Details about [DigitalIoConfigError](#) (W = Warning, F = Fault, W/F = both).

Logic voltage error

Error of the power supply voltage of the control section. For any further information, see [Section 14.2, Supply voltages](#). The details can be found in the following chart and in the parameters [LogicVoltageError](#).

Bit	Name	Type	Description
0	Logic voltage too low for brake	W/F	The supply voltage of the control section is too low to correctly ensure the brake. Under the "Error threshold for the brake" (see Chapter 5, Technical features) the drive enters in the Warning status. If the voltage remains under this threshold, the Fault activates. Increase the supply voltage or stabilize it.
1 - 15	Reserved		

Table 24.15. Details about [LogicVoltageError](#) (W = Warning, F = Fault, W/F = both).

Motion parameter limited

One or more motion parameters are set above their own limits. The details can be found in the following chart and in the parameter [MotionParamLimitedError](#).

Bit	Name	Type	Description
0	Target velocity limited	W	With the <i>Profile Velocity Mode (CiA402)</i> (CiA402 and CUSTOM) operative modes, TargetVelocity is greater or equal to MaxMotorSpeed or to MaxProfileVelocity . Decrease TargetVelocity . With the <i>Profile Velocity AI Mode</i> mode, the conversion from AI0FilteredVoltage to the required velocity, produces a velocity value that's greater or equal to MaxMotorSpeed or to MaxProfileVelocity . If the Warning is unexpected, check if the conversion procedure accords to the contents of Section 17.3, Conversion .
1	Profile velocity limited	W	ProfileVelocity is higher or equal to MaxMotorSpeed or to MaxProfileVelocity . Decrease ProfileVelocity .
2	Start velocity limited	W	StartVelocity is higher or equal to MaxMotorSpeed or to MaxProfileVelocity . Decrease StartVelocity .
3	End velocity limited	W	EndVelocity is higher or equal to MaxMotorSpeed or to MaxProfileVelocity . Decrease EndVelocity .
4	Speed during search for switch limited	W	SpeedForSwitch is higher or equal to MaxMotorSpeed or to MaxProfileVelocity . Decrease SpeedForSwitch .
5	Speed during search for zero limited	W	SpeedForZero is higher or equal to MaxMotorSpeed or to MaxProfileVelocity . Decrease SpeedForZero .
6	Velocity of the safety profile limited	W	SafetyPrfVelocity is higher or equal to MaxMotorSpeed or to MaxProfileVelocity . Decrease SafetyPrfVelocity .
7	Reserved		
8	Profile acceleration limited	W	ProfileAcceleration is higher or equal to MaxAcceleration . Decrease ProfileAcceleration .
9	Profile deceleration limited	W	ProfileDeceleration is higher or equal to MaxDeceleration . Decrease ProfileDeceleration .
10	Homing acceleration limited	W	HomingAcceleration is higher or equal to MaxAcceleration or to MaxDeceleration . Decrease HomingAcceleration .
11	Quick stop deceleration limited	W	QuickStopDeceleration is higher or equal to MaxDeceleration . Decrease QuickStopDeceleration .
12	Deceleration of MC_Stop/ MC_Emc function block limited	W	SafetyPrfAcceleration is higher or equal to MaxAcceleration . Decrease SafetyPrfAcceleration .
13	Acceleration of the safety profile limited	W	SafetyPrfAcceleration is higher or equal to MaxAcceleration . Decrease SafetyPrfAcceleration .
14	Deceleration of the safety profile limited	W	SafetyPrfDeceleration is higher or equal to MaxDeceleration . Decrease SafetyPrfDeceleration .
15	Reserved		

Table 24.16. Details about [MotionParamLimitedError](#) (W = Warning, F = Fault, W/F = both).

Digital output overtemperature or overload

Overcharge or overtemperature have been detected on the drive internal management circuit of the digital output. All digital outputs are switched off. Check the connected wirings and loads.

Over Speed

Maximum velocity limit exceeded. The threshold value is $\text{MaxMotorSpeed} * 1.2$, therefore it's 20% over the maximum velocity that the motor can reach. If [VelocityActualValue](#) con-

tinuously remains over this threshold for 10ms, the system enters in Fault state because the movement is no more under control.

Internal Error

A firmware internal error has occurred. The details can be found in the following chart and in the parameters [InternalError](#). Please contact Bonfiglioli

Bit	Name	Type	Description
0	Internal Software Reset	F	A firmware internal error has occurred. Report to Bonfiglioli the codes in the SwResetCode and SwResetInfo parameters.

Table 24.17. Details about [InternalError](#) (W = Warning, F = Fault, W/F = both).

/STO Error

An error on the /STO has occurred. The details are reported in the [STOError](#) parameters.

Chapter 25

Troubleshooting

ADVICE

In case of problems run the [Save/Export parameters file](#) command with MotionDrive, so that you can record on a file the full drive situation. The saved file is useful to run in a second moment or remotely the problem analysis.

25.1. Generic problems

Problem	Solution
The leds are switched off.	<ul style="list-style-type: none">• Verify that the drive is correctly supplied, in particular the control section; see what's reported in Section 14.2, Supply voltages;• check the wiring.
The leds are on but the drive does not communicate.	<ul style="list-style-type: none">• See what reported in Section 25.5, Communication problems.
Interpreting the drive status on the basis of the leds status	<ul style="list-style-type: none">• See what reported in Section 7.3, Leds.
Find the status of the Digital I/O	<ul style="list-style-type: none">• Read the parameters DigitalInputs and PhysicalOutputs;• open the tab Main of MotionDrive• see what reported in Chapter 16, Digital inputs and outputs.

Problem	Solution
Value the motion performances	<ul style="list-style-type: none"> • See the available parameters in Show variables (Figure 3.1) for one first evaluation; • use the MotionDrive oscilloscope to estimate the performances of the motion parameters (Section 23.2, Monitoring by oscilloscope).
Monitor some drive parameters (temperature, currents, speed, etc...)	<ul style="list-style-type: none"> • See what reported in Chapter 23, Oscilloscope and monitoring; • see what reported in Section 27.12, Drive status (1800-1999).
Load dynamic braking	<ul style="list-style-type: none"> • Do not use the internal brake of the iBMD drives; • run the braking according to what is reported in Section 22.3, Carrying out a stop by using the master; • consider what is reported in Section 14.3, Regeneration.
Delay the brake	<ul style="list-style-type: none"> • The brake is managed automatically by the drive and it cannot be enabled with Drive enable; • with Drive disable the brake can be delayed as described in Section 15.6, Brake. Pay attention, in this case the load can move in an unforeseen way.
The internal brake does not keep the motor steady	<ul style="list-style-type: none"> • If the load applies a higher torque on the brake torque, it is necessary to apply more efficient braking systems; • the internal brake is damaged; it could be necessary to repeat the brake run-in. Please contact Bonfiglioli Mechatronic Research S.p.a.
Use the capture units.	<ul style="list-style-type: none"> • See what reported in Chapter 18, Capture Peripherals.

25.2. Electric and connection problems


Problem	Solution
Which is the reference voltage (0V) of the digital inputs and outputs	<ul style="list-style-type: none"> • The voltages of the digital inputs and outputs refer to Ground Control supply of CN5 (PIN B).

25.3. Problems with Fault and Warning

Problem	Solution
The drive is in Fault: how to proceed	<ul style="list-style-type: none"> • Interpret the present Fault precisely (FaultDynamic, Section 24.1, Management of the errors with MotionDrive or Section 24.2, Monitoring the errors on the status leds); • analyse the Fault type and its possible causes (Section 24.6, Errors description); • eliminate the causes that have caused the Fault and run the reset (Section 24.5, Resetting the errors).
It is not possible to eliminate the Faults	<ul style="list-style-type: none"> • Ready carefully what is reported in Section 24.5, Resetting the errors.
How to remove the Fault causes	<ul style="list-style-type: none"> • Analyse the occurred Faults by using what is reported in Section 24.6, Errors description.
How to stop the motor in case of Fault	<ul style="list-style-type: none"> • In case of Fault, the drive runs what is reported in Section 24.4, Reaction to the Faults. In some cases it is not possible to check the motor stop or to run a Safety profile.
Difference between a dynamic and a retentive Fault	<ul style="list-style-type: none"> • Dynamic error: the error condition is still in the drive; • retention error: the error is memorized by the drive, until it is reset.

Problem	Solution
The drive goes in Fault when it is enabled	<ul style="list-style-type: none"> Analyse the Fault that's present after the enabling.
Enabling the drive while some Warnings are active	<ul style="list-style-type: none"> In general the drive can be enabled also with active Warnings; pay attention: some Warnings become Faults if you try to enable the drive; it is advisable to eliminate any present Warning.
Difference between Parameters serious error and Parameters soft error	<ul style="list-style-type: none"> The serious error is a more serious Warning and it becomes a Fault if you try to enable the drive. The soft error does not compromise the drive integrity, that is the drive protects itself. In any case you need to analyse the error type accurately.

25.4. Problems with parameters and configuration

Problem	Solution
How parametrizing the drive	<ul style="list-style-type: none"> Use the parameters vocabulary (Section 27.2, Reading and writing a parameter); use Drive Setup of MotionDrive (Toolbar > ); download a parameters file (Section 21.3, Downloading parameters file).
Restoring a known configuration	<ul style="list-style-type: none"> Run the command Restore default parameters (command 2200 of the System Manager): updating the current configuration and the permanent memory with the default values; run the command Reset to default (command 2201 of the System Manager): updating the current configuration with the default values; run the command Reload all parameters (command 2300 of the System Manager): updating the current configuration with the data in the permanent memory; run the command Hard reset (command 5000 of the System Manager): it means, for all parameters, to switch on and off the drive; run the command Soft reset (command 5001 of the System Manager): it means, for all parameters, except from the position ones, to switch on and off the drive.
The parameters are not kept	<ul style="list-style-type: none"> Run the command Save all parameters (command 2001 of the System Manager): saving the current configuration in the drive permanent memory; check if the parameters are not written in the internal PLC programme; try to cancel the programme; check if the parameters are not written by the network master; disconnect the field buses; check if there are no parametrization or System Manager errors at the firmware start.
How to manage the drive parametrization	<ul style="list-style-type: none"> See what reported in Chapter 21, Saving, restoring or cloning the drive configuration..
Modifying a parameters file	<ul style="list-style-type: none"> Open a MotionDrive session and connect OFFLINE choosing the parameters file to modify (Section 12.2, Offline mode); at the end of the modifications, save the modified parameters file.
Moving the parameters configuration between one drive and another	<ul style="list-style-type: none"> Use the parameters file (Section 21.2, Saving/Exporting parameters file) only between drives with the same ProductCode and HardwareProductCode.
In the tab Motor and drive you cannot find the motor you want to use	<ul style="list-style-type: none"> If the motor doesn't appear in the combo box Motor, the motor database has to be updated (Section 26.2, Updating the motors database); in the <i>iBMD</i> drives the motor cannot be changed.
In the tab Motor and drive you cannot find the FeedbackSensorCode you want to use	<ul style="list-style-type: none"> if you cannot find the sensor in the list of the FeedbackSensorCode, check the available sensors with the installed firmware and if necessary update the firmware (Section 26.3, Firmware updating); if the sensor is not supported by any available firmware for the drive, contact Bonfiglioli Mechatronic Research S.p.a;

Problem	Solution
	<ul style="list-style-type: none"> in the iBMD drives, FeedbackSensorCode cannot be changed.
The parameters to configure the capture units are not writable	<ul style="list-style-type: none"> the configuration parameters are not writable if the capture units are enabled. Check the status of the capture units through the parameter CaptureUnitCommand_A (CaptureUnitCommand_B).

25.5. Communication problems

Problem	Solution
The drive does not communicate via Modbus	<ul style="list-style-type: none"> Connect the drive and see the connection settings according to what reported in Section 8.3, Communicate with master Modbus RS232 (auxiliary communication port); check if the drive is on: the L1 and L2 leds (Figure 7.10) must not be off.
The drive does not communicate via CANopen	<ul style="list-style-type: none"> Connect the drive and see the connection settings according to what reported in Section 8.1, Communicate with master CANopen; check if the drive is on: the L1 and L2 leds (Figure 7.10) must not be off; check if the led LA is on and the CAN communication error is not enabled; if necessary remove the error.
The drive does not communicate via EtherCAT	<ul style="list-style-type: none"> Connect the drive and see the connection settings according to what reported in Section 8.2, Communicate with master EtherCAT; check if the drive is on: the L1 and L2 leds (Figure 7.10) must not be off; check the presence of the link in the communication ports connected to the network EtherCAT: the related leds L/A 0 and L/A 1 must not be off (Figure 7.10); check if the led ERR is not on and the EtherCAT communication error is not enabled; if necessary remove the error.
Updating request of the MotionDrive Configuration files	<ul style="list-style-type: none"> Updating according to what is reported in Section 26.5, Updating the Configuration File.
Reading/Writing parameters	<ul style="list-style-type: none"> See Section 8.4, Errors in reading / writing of the parameters.
Firmware download procedure goes in error.	<ul style="list-style-type: none"> Verify that the communication with the drive is active, verify the messages that are reported in the FirmwareStatus and SysMngError parameters and follow the suggested instructions.

25.6. Motion problems

Problem	Solution
How to enable the drive	<ul style="list-style-type: none"> See what reported in Section 22.1, Enabling by using the master.
How to stop the load in safety	<ul style="list-style-type: none"> See what reported in Section 22.3, Carrying out a stop by using the master.
How to measure the drive load level	<ul style="list-style-type: none"> Monitoring the regular drive temperatures with the parameters of the group TemperatureStatus; monitoring the working of TargetTorque; monitoring the working of RMSMotorCurrent, after having set RMSMotorCurrent-Filter equal to the value of the drive working time cycle.
The motor does not run the requested motion and the drive signals I2T limit reached or I2T	<ul style="list-style-type: none"> Check the working of I2TValue and check the problem in the following line.

Problem	Solution
Warning threshold reached	
The drive signals I2T limit reached or I2T Warning threshold reached	<ul style="list-style-type: none"> Monitoring the value of I2TValue and ActualMotorCurrent to find any anomalies; check the mechanics working to avoid any anomalous absorptions of Actual-Torque; decrease the requested performances and increase the dwell times during which the motor works at low current in order to download I2TValue; decrease the acceleration ramps and the requested speeds to decrease the Target-Torque; increase UserMaxI2T till the value of DriveMaxI2T (Section 14.6, <i>I2T</i>).
The motor does not run the requested motion or the requested motion has been interrupted	<ul style="list-style-type: none"> Check for any possible stop command (see Section 22.3, <i>Carrying out a stop by using the master</i>); check if the drive is in Fault (see Chapter 24, <i>Fault and Warning</i>); check for any possible disabling command (see Section 22.2, <i>Disabling by using the master</i>); check if the Limit reached is not enabled; check if the drive has not run an on-the-fly mode change; in this case the drive is used to insert the new set points according to the new selected operating mode (see Section 22.5, <i>On-the-fly operative mode change</i>); if you work in <i>Interpolated Position Mode</i> check if the bit <i>Enable ip mode</i> of the Controlword has not been reset; if you work in <i>Profile Velocity Mode (CiA402)</i> or <i>Profile Velocity Mode (CUSTOM)</i>, check if the absolute value of TargetVelocity is higher than EndVelocity and StartVelocity.
the PositionFollowingError doesn't resets during a positioning, while the velocity is constant	<ul style="list-style-type: none"> Verificare che l'asse sia tarato correttamente (vedere Chapter 20, <i>System tuning</i>) e aumentare la dinamica dei loop per far rientrare più velocemente PositionFollowingError; Check that the torque/velocity or position limits are not reached (see Chapter 19, <i>Motion limits</i>); If the <i>Interpolated Position Mode</i> is used with IpPosSubModeSelect = -10: check that at every variation of RequestedPosition, the FeedForwardSpeed takes the correspondent value (see Figure 22.5 and Figure 22.6); check that the value of the KVff parameter is 1000;

25.7. Problems with the oscilloscope

Problem	Solution
How to do a trial capture	<ul style="list-style-type: none"> Choose at least one parameter to capture from the channels list (point A in Section 23.2, <i>Monitoring by oscilloscope</i>); check if the channel (point K) is enabled and if the display mode is Normal (point H); select Trigger mode Auto (point B in Section 23.3, <i>Setting the oscilloscope Trigger</i>), Sampling time lower than 1ms (point C) and the option Single trigger mode (point G); press Run (point I) and wait for some seconds for the upload to be finished; press Autoscale in the tab Channel.
The oscilloscope does not capture any data	<ul style="list-style-type: none"> No channel has been selected in the tab Channel; select at least one parameter to capture and check if the channel is enabled (point K in Section 23.2, <i>Monitoring by oscilloscope</i>); the trigger has been stopped; the oscilloscope status is Trigger stopped; press Run; check if the trigger is correctly set; if necessary try with Trigger mode Auto (point B in Section 23.3, <i>Setting the oscilloscope Trigger</i>).
The oscilloscope loads the data repeatedly	<ul style="list-style-type: none"> Select the option Single trigger mode (point G in Section 23.3, <i>Setting the oscilloscope Trigger</i>).
There is no trigger event	<ul style="list-style-type: none"> Check if the parameter the trigger is associated to can cause the event: try with Trigger mode Auto (point B in Section 23.3, <i>Setting the oscilloscope Trigger</i>);

Problem	Solution
	<ul style="list-style-type: none"> • check if the trigger is associated to the wanted channel (point A); • check if Trigger value and Trigger edge are the wanted ones; enable the option Show trigger for confirmation (point F).
<p>The progress of the oscilloscope status bar is too slow or has stopped (point N in Section 23.3, Setting the oscilloscope Trigger)</p>	<ul style="list-style-type: none"> • The Sampling time (point C) is too high (> 10ms) and a large time window will be captured; try to decrease the Sampling time; • the communication does not allow higher uploading speeds: wait for the procedure end or analyse any possible communication problems.
<p>The captured time interval is not sufficient or the available track is concentrated in a limited portion of captured data</p>	<ul style="list-style-type: none"> • Modifying the Sampling time: increasing it to increase the time window to capture; decrease it to concentrate the samples in a lower time interval; • zooming to enlarge the tracks (point D in Measures).
<p>The first part of the profiles is not captured</p>	<ul style="list-style-type: none"> • Select correctly the pre-trigger to capture one part of the profiles before the trigger event (point E in Section 23.3, Setting the oscilloscope Trigger).
<p>The tracks are not sufficiently resolute</p>	<ul style="list-style-type: none"> • Disable the useless channels (deselect the option at the point K in Section 23.2, Monitoring by oscilloscope); • decrease the Sampling time.
<p>There are no traces in the Screen</p>	<ul style="list-style-type: none"> • Run a capture; • press Autoscale in the tab Channel; • modify scale and channels offset (Section 23.2, Monitoring by oscilloscope); • centre the tracks in the Screen (point E in Section 23.2, Monitoring by oscilloscope); • select Normal in the display mode (point H).
<p>How to measure the captured profiles</p>	<ul style="list-style-type: none"> • Run a capture; • insert the scales in the screen (point N in Tracks preferences); • see what reported in Measures.
<p>How to compare the next captures</p>	<ul style="list-style-type: none"> • Save in the Screen the first set of tracks (Section 23.4, Saving or uploading an oscilloscope capture); • run the second capture for the comparison.
<p>How to running motions by the Function Generator</p>	<ul style="list-style-type: none"> • Select the desired Function Generator in the Function Generator tab; • press Load presets; • in order to avoid unwanted motions or collisions, take all the necessary precautions and configure precisely the drive limits (Chapter 19, Motion limits); • press Start and wait for some seconds for the upload of the oscilloscope data to end; • check any possible error in the field Drive information.
<p>The Function Generator does not start</p>	<ul style="list-style-type: none"> • read and interpret the errors in the field Drive information; • the internal PLC interferes with the Function Generator: stop the PLC; • the network master interferes with the Function Generator: disconnect the field buses not used or interrupt the parameters writings; • the drive is in Fault: press Show errors; • press End and try again.
<p>The Function Generator must be promptly stopped</p>	<ul style="list-style-type: none"> • Select properly the parameters for the End command (Tuning end option and Tuning end deceleration); • Press End.
<p>The drive must not be disabled once the Function Generator is finished.</p>	<ul style="list-style-type: none"> • Select for Tuning end option, Deceleration ramp and enable or Zero speed and enable; • never press Disable to stop the Function Generator.
<p>The units of measurement of the references are not suit-</p>	<ul style="list-style-type: none"> • Modify the MotionDrive units of measurement (Section 13.4, MotionDrive units).

Problem	Solution
able for the foreseen motion	

25.8. Tuning problems

Problem	Solution
Difficulties on the visualization of the results on the oscilloscope charts	<ul style="list-style-type: none"> See Section 25.7, Problems with the oscilloscope.
Resonances in VelocityActualValue and in ActualTorqueCurrent	<ul style="list-style-type: none"> Decrease the dynamic performances by lowering the DynamicResponse option For the drives of different type as <i>iBMD</i>, check and improve the motor and feedback sensor wirings by following carefully what is reported in Section 7.2, Electrical connections; for the drives of different type as <i>iBMD</i>, use a feedback sensor with higher resolution; decrease the value of KCp_Q and KCp_D; bearing in mind that CurrentLoopEstimatedBandwidth decreases, such as the performances which can be obtained also from the VelocityLoop; modify the filtering action of the <i>Sensor filter</i> in the <i>VelocityLoop</i> (VFilterSensorFrequency); reduce the <i>VelocityLoop</i> band by decreasing KVp.
Resonances found at the end of the estimate of the inertia moment (Section 20.9, Inertia estimator) or when the motor is stopped or at the presence of pure inertial load (with low friction) coupled with less rigid joints or mechanical backlashes.	<ul style="list-style-type: none"> Stabilize the system as reported in 3. System stabilisation and 4. Filters of the <i>Detailed Tuning Guide</i>; see the solutions in the next line.
Resonances in VelocityActualValue using mechanical transmissions with considerable backlashes and tolerances (mechanical transmission at limited performances)	<ul style="list-style-type: none"> Make the load more solid through the mechanical transmission; improve the mechanical transmission: reduce backlashes, check the chains and the drive belts tension, check the joints, pulleys and gear wheels closure, use transmission components with no backlash, etc... tighten the mechanical structure and the machine chassis; decrease PositionLoopEstimatedBandwidth by decreasing KPP; reduce VelocityLoopEstimatedBandwidth by proportionally reducing KVp and KVi; if the resonances have a low speed, decrease PositionStandStill and VelocityStandStill in case of position control, increase the value of PositionErrorDeadBand.
Resonances in VelocityActualValue	<ul style="list-style-type: none"> Repeat the tuning and follow the instructions that are reported in Section 20.5, Detailed tuning guide
Resonances at low speeds or at stopped motor	<ul style="list-style-type: none"> Decrease the PositionStandStill and VelocityStandStill bars.
EstimatedInertia higher than 8-10Jm	<ul style="list-style-type: none"> If PositionLoopEstimatedBandwidth is not at least the half of VelocityLoopEstimatedBandwidth, decrease KPP and PositionStandStill; use motors with higher inertia moment and mechanical transmissions with no backlash and with high stiffness coupling among the components increase the reduction ratio of the mechanical transmission in order to reduce the load inertia moment on the part of the motor

Problem	Solution
	<ul style="list-style-type: none">• reduce the accelerations and decelerations in accordance with the available torque in order to avoid oscillations at the ramp end• decrease <i>KVi</i> by 20-50 units• modify the outgoing filters of the speed regulator.

Chapter 26

Software updating

In the *iBMD* drives, during the functioning of the boot software and of the firmware startup, the leds don't work as the standard functioning (started firmware, referring to the [Table 7.6](#)). In the following table the various leds statuses are reported with a short description.

Every cell that indicates the leds configuration contains their colour and blink type, separated by a comma.

The codes for the colours are made of one letter:

- *G*: green;
- *O*: orange;
- *R* red;
- *x* unimportant (in case of led off);

The blinking codes are the same that are reported in [Section 7.3, Leds](#).

Description	FirmwareStatus	L1	L2	L3	L4	L5	L6
Boot startup	-	x, OFF	x, OFF	O, ON	O, ON	x, OFF	x, OFF
Firmware startup	-	x, OFF	x, OFF	G, ON	G, ON	x, OFF	x, OFF
Firmware download phases	-	O, 1 FL	O, 1 FL	O, ON	O, ON	O, 1 FL	O, 1 FL
		O, BLK	O, BLK	O, ON	O, ON	O, BLK	O, BLK
		O, ON	O, ON	O, ON	O, ON	O, ON	O, ON
		O, FLK	O, FLK	O, ON	O, ON	O, FLK	O, FLK

Description	FirmwareStatus	L1	L2	L3	L4	L5	L6
		G, BLK R, ON	G, BLK R, ON	O, ON R, ON	O, ON R, ON	G, BLK R, ON	G, BLK R, ON
Firmware exception error	20						
Error during the Firmware download or corrupted Firmware flash memory	13, ≥ 100	R, ON	x, OFF	R, ON	R, ON	R, BLK	R, BLK
CPLD programming aborted due to an error	19	R, ON	x, OFF	R, ON	R, ON	R, BLK	R, BLK
One or more incompatibility between boot, hw and fw	13, 16, 17, 18	G, BLK	x, OFF	R, ON	R, ON	R, BLK	R, BLK

Table 26.1. Description of the leds during the boot and the firmware startup.

26.1. MotionDrive updating

To update MotionDrive you only need to install the updated version of the programme by choosing one of the procedures proposed in [Section 3.2, Installation](#).

26.2. Updating the motors database

The motors database is a file that's released by Bonfiglioli Mechatronic Research S.p.a and contains the data of the standard motors for the iBMD drive series. The motor database is used by MotionDrive to recognize the motor type that's wired to the drive with which you are connected and it's important to keep it updated.

To update the motor database of MotionDrive it's sufficient to the MotionDrive program (see [Section 3.2, Installation](#))

26.3. Firmware updating


IMPORTANT


The firmware updating does not cancel any data saved in the permanent memory.

To update the firmware, connect the drive with MotionDrive and open the Download firmware window. Access with MotionDrive:

Main menu > Drive > Download firmware ...

Toolbar > 



In the Download firmware window, choose the desired firmware and press . If the firmware is not present in the proposed list it's sufficient to install the updated version of MotionDrive by selecting one of the procedures that are proposed [Section 3.2, Installation](#).

ADVICE

If at the end of the download, the firmware does not start up, check what reported in the window and in the [FirmwareStatus](#) parameter.

26.4. Updating the boot

NOTICE

If during the boot updating the control section runs out of power, the drive cannot be used anymore and must be sent back to Bonfiglioli Mechatronic Research S.p.a. During the updating, supply power to the drive with an uninterruptible power supply (UPS).

To update the boot, connect to the drive with MotionDrive and open the Download firmware window.


IMPORTANT


Update the boot software only if really necessary.

Access with MotionDrive:

Main menu > Drive > Download firmware ...

Toolbar > 



Activate the Show all option in the download firmware window, select the desired boot and push . If the boot is not present in the proposed list it's sufficient to install the updated version of MotionDrive by selecting one of the procedures that are proposed [Section 3.2, Installation](#).

NOTE

After downloading the boot it is necessary to download the firmware again. The data saved in the permanent memory are not cancelled.

26.5. Updating the Configuration File

The Configuration files are files xml used by MotionDrive to communicate with the drive. To update the Configuration files you only need to install the updated version of the MotionDrive by selecting one of the procedures that are proposed in [Section 3.2, Installation](#).

26.6. ESI EEPROM updating procedure on ETC drive

26.6.1. ESI EEPROM updating from MotionDrive through debug serial port


The procedure is commanded/executed by MotionDrive that connects to the drive through the debug serial port.

The EtherCAT master (e.g. TwinCAT Beckhoff) must be connected to the drive through the EtherCAT port, it is assumed to have already installed on the PC the EtherCAT master development environment and to have a project that describes all the peripherals in the EtherCAT network.


The sequence is the following:

1. start the EtherCAT master development environment and connect to the drive

- take the EtherCAT status of the drive to BOOTSTRAP



- start MotionDrive and connect to the drive through the debug serial port
- on MotionDrive select the "Show Error" button and push the "Update esi eeprom" button




- at the end of the operation check that the "ESI eeprom may not be updated" Warning is no more present
- execute a power-up cycle on the drive (in case there are more than one drive to update, this operation can be executed only once at the end of the sequence)

26.6.2. ESI EEPROM updating from MotionDrive through gateway CoDeSys


The procedure is commanded/executed by MotionDrive that connects to the drive through the Ethernet port to a EtherCAT CoDeSys master..

The EtherCAT CoDeSys master must be connected to the drive through the EtherCAT port. The sequence is the following:

1. start MotionDrive and connect to the drive through the CoDeSys master



2. on MotionDrive select the "Show Error" button and push the "Update esi eeprom" button



3. at the end of the operation check that the "ESI eeprom may not be updated" Warning is no more present
4. execute a power-up cycle on the drive (in case there are more than one drive to update, this operation can be executed only once at the end of the sequence)

26.6.3. ESI EEPROM updating from EtherCAT master in manual mode


The procedure is commanded/executed by the EtherCAT master.

The EtherCAT master must be connected to the drive through the EtherCAT port, it is assumed to have already installed on the PC the EtherCAT master development environment and to have a project that describes all the peripherals in the EtherCAT network.

The following described procedure can be manually executed by an operator or can be inserted at the end of a firmware updating operation made by the master.

The sequence is the following:

1. start the master development environment
2. connect to the drive
3. write 1 on the 0x500 register of the ET1100 (enables the SII_EEPROM access to the DSP)



4. write the command 5400 on the [SysMngCommand](#) cell (0x5FF7.01 CoE)
5. execute the reading of the [SystemManagerStatus](#) cell (0x5FF7.02 CoE) to read the operation status, wait the end operation code, if it ends with an error read the error code on [SysMngError](#) (0x5FF7.03 CoE)
6. write 0 on the 0x500 register of the ET1100 (disables the SII_EEPROM access to the DSP)
7. execute a power-up cycle on the drive (in case there are more than one drive to update, this operation can be executed only once at the end of the sequence)

26.6.4. ESI EEPROM updating from EtherCAT master in automatic mode

The procedure permits to execute the update without an EtherCAT master.

At the end of a firmware download the message: *ESI eeprom will be updated at the next power-up cycle* will appear in the “Show error” window of the MotionDrive tool. By executing the drive turn off/turn on sequence, the ESI eeprom update is automatically executed

and at the firmware start-up it's sufficient to check that there is no error signals related to the update. If at the start-up the message: *ESI eeprom updating at the power-up failed* appears, it means that the automatic procedure has failed due to a drive HW problem.

NOTE

it's anyway possible to execute always the manual procedure for the update.

The eventual warning messages are related to the bits in the [EtcErrorRetentCommMsg](#) parameter.

Chapter 27

Parameters vocabulary

The exchange of data with the drive takes place through a list of parameters, called *Parameters vocabulary*. The parameters define and control every single function of the drive.

27.1. Agreements on the parameters description

Every drive parameter is described in this chapter by the fields in the following table:

Field	Description
-	<i>Desc</i> means that the field information can be found in the following description.
Modbus	Parameter address which is accessible through protocol Modbus. The number is expressed on a decimal basis.
CANopen	Parameter address which is accessible through CANopen protocol. The value is expressed on a hexadecimal basis in the format 0xYYYY.ZZ with the following meaning: <ul style="list-style-type: none">• YYYY: parameter index;• ZZ: parameter subindex. This field has a meaning only for drives CAN. For drives of ETC version this field refers to the address of the parameter in the vocabulary accessible through the CANopen over EtherCAT protocol.
Range	Range of values accepted for the parameter. If it is not specified it means that all values represented by the type of datum associated to the parameter are considered as valid.
Default	Parameter default value.
Type	Type of datum associated to the parameter:

Field	Description
	<ul style="list-style-type: none"> • U8: 8 bits without sign • U16: 16 bits without sign; • U32: 32 bits without sign; • S8: 8 bits with sign; • S16: 16 bits with sign; • S32: 32 bits with sign; • STR: string; • IQN: notation at fixed point at 32 bits with sign and N bits after the point; • FLT: floating point single precision.
Units	Unit of measurement of the parameter (see Section 13.1, Units of measurement of the parameters).
Acc	Type of access to the parameter: <ul style="list-style-type: none"> • RW (read/write): reading and writing; • WO (write only): only writing; • RO (read only): only reading; • CST (constant): only reading (constant parameter).
Pdo	Parameter mapping in a PDO: <ul style="list-style-type: none"> • YES: mappable parameter; • -: not mappable parameter. This field has a meaning only for drives CAN.
Mem	Type of parameter saving in the permanent memory: <ul style="list-style-type: none"> • -: parameters non savable in the permanent memory • ES: parameters savable in the permanent memory that can be restored on command with the default values; • EM: parameters savable in the permanent memory that cannot be restored on command with default values.

Table 27.1. Fields describing the parameters

27.2. Reading and writing a parameter

The dimension of every [Modbus register](#) is 1 Word (2 byte). Therefore each parameter takes a minimum of 2 bytes of memory. For example:

- if a parameter is 8 bit long (1 byte = 1/2 Word) it takes 1 word anyway, therefore if it is on 4100 Modbus address, the next parameter is on 4101;
- if a parameter is 16 bit long (2 byte = 1 Word) it takes 1 word, therefore if it is on 1201 Modbus address, the next parameter is on 1202;
- if a parameter is 32 bit long (4 byte = 2 Word) it takes 2 words, therefore if it is on 4110 Modbus address, the contained data take even the 4111 register and, in consequence, the next parameter is on 4112;

NOTE

To read and write a parameter via EtherCAT, using the SDOs expedited ([Section 10.1, Protocol CANopen over EtherCAT \(CoE\)](#)).


To read and write a parameter via CANopen, use the SDOs expedited according to the specifications [CiA-301](#).

To read and write a parameter via Modbus, send a frame by using the function codes written in [Table 11.1](#).

Access with MotionDrive:

Main menu > Drive > Object dictionary ...

Toolbar > 



To select the parameter to read or write in the Object dictionary window, you can click on the proposed list, write the name and the address or use the search by name functions in the box Filter.

ADVICE

To interpret any error messages please see [Section 8.4, Errors in reading / writing of the parameters.](#)

27.3. Uploading/downloading

To upload/download via EtherCAT, use the SDOs normal ([Section 10.1, Protocol CANopen over EtherCAT \(CoE\)](#)).

To upload/download via CANopen, use the SDOs normal according to the specifications [CiA-301](#).

Via Modbus it is not possible to run correctly an upload/download.

27.4. Initial configuration, update and board identity (0-999)

DriveInformation

Informations related to the drive.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x5FFD.00	15	15	U8	-	CST	-	-

Number of parameters in this group.

HardwareRevision

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
12	0x5FFD.01	-	-	S16	-	RO	-	-

Drive hardware revision.

BootRevision

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
15	0x5FFD.04	-	-	S16	-	RO	-	-

Boot firmware revision.

FirmwareRevision

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
18	0x5FFD.07	-	-	S16	-	RO	-	-

Firmware revision. If -1 is valid, only the boot firmware is present.

HardwareProductCode

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
21	0x5FFD.0A	-	-	U32	-	RO	-	-

Product hardware code.

OemCode

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
33	0x5FFD.0E	6873	6873	U16	-	CST	-	-

Code that identifies the constructor.

SoftwareProductCode

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
34	0x5FFD.0F	-	-	U16	-	RO	-	-

Product software code.

FirmwareStatus

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
40	0x5FFE.01	-	-	U8	-	RO	-	-

Status of the firmware.

FirmwareStatus	Message	Solution
0	CRC has not been checked yet	Wait the end of the download procedure.
1	Do not launch firmware	
10	Run	Firmware is executing.
11	Permanent memory error	Error in the permanent memory, turn off and on again the drive. If the problem persists, please contact Bonfiglioli.
12	Reserved	-
13	CRC error	The firmware is corrupted, try again the download procedure. If the problem persists, please contact Bonfiglioli.
14	Hardware is not compatible with firmware	The hardware is not compatible with firmware. Try a new download procedure with a compatible firmware or substitute the <i>iBMD</i> drive with one that has a compatible hardware. In the "Download Firmware" window, choose the desired firmware and press
15	Boot is not compatible with firmware	The Boot is not compatible with the firmware. Try a new download procedure with a compatible firmware or update the boot. The "Download Firmware" window automatically shows the firmwares and the boots that are compatible.
16	Firmware is not compatible with hardware	The firmware is not compatible with the hardware. Try a new download procedure with a compatible firmware or substitute the <i>iBMD</i> drive with one that has a compatible hardware. In the "Download Firmware" window, choose the desired firmware and press
17	Firmware is not compatible with boot	Firmware non compatible with the boot. Try a new download procedure with a compatible firmware or update the boot. The "Download Firmware" window automatically shows the firmwares and the boots that are compatible.
18	Reserved	-
19	CPLD error	Error during the internal memory programming, try to download again the firmware. If the problem persists, please contact Bonfiglioli.
20	Firmware exception error	Due to an error that cannot be reset, the firmware start has been blocked. Try to download another firmware and then restore the parameters with the default.
106	Download: generic time out	Firmware download procedure interrupted. Check the wirings (see Section 7.2, Electrical connections), the parameters of the connection (see Chapter 8, Communicating with the drive) and, then, try a new download procedure.
113	Download: memory is busy	The memory of the drive is busy because other procedures are executing on another communication channel, wait that these are ended and try another download procedure.
151	Download: file corrupted (code 5101)	The firmware file is corrupted, update the files as described in Section 26.5, Updating the Configuration File and try again the download procedure.
153	Download: file requires unsupported features (code 5103)	The firmware download requires some functionalities that are not supported by the boot. Try to download another firmware or update the boot.

FirmwareStatus	Message	Solution
154	Download: file requires unsupported features (code 5104)	
155	Download: file requires unsupported features (code 5105)	
156	Download: file requires unsupported features (code 5106)	
157	Download: file requires unsupported features (code 5107)	
158	Download: file requires unsupported features (code 5108)	
161	Download: file corrupted (code 5111)	The firmware file is corrupted, update the files as described in Section 26.5, Updating the Configuration File and try again the download procedure.
162	Download: file corrupted (code 5112)	
163	Download: file corrupted (code 5113)	
164	Download: file corrupted (code 5114)	
165	Download: file corrupted (code 5115)	
166	Download: file requires unsupported features (code 5116)	The firmware download requires some functionalities that are not supported by the boot. Try to download another firmware or update the boot.
167	Download: file requires unsupported features (code 5117)	
168	Download: file requires unsupported features (code 5118)	
169	Download: file requires unsupported features (code 5119)	
170	Download: file requires unsupported features (code 5120)	
171	Download: file requires unsupported features (code 5121)	Error during the memory programming, try to download again the firmware. If the problem persists, please contact Bonfiglioli.
172	Download: memory error (code 5122)	
173	Download: file corrupted (code 5123)	The firmware file is corrupted, update the files as described in Section 26.5, Updating the Configuration File and try again the download procedure.
174	Download: file corrupted (code 5124)	
175	Download: memory error (code 5125)	Error during the memory programming, try to download again the firmware. If the problem persists, please contact Bonfiglioli.
200	Download: memory error (code 5150)	
201	Download: memory error (code 5151)	
202	Download: memory error (code 5152)	
203	Download: memory error (code 5153)	
204	Download: memory error (code 5154)	
210	Download: memory error (code 5160)	
211	Download: memory error (code 5161)	
212	Download: memory error (code 5162)	
213	Download: memory error (code 5163)	
214	Download: memory error (code 5164)	
220	Download: memory error (code 5170)	
221	Download: memory error (code 5171)	
230	Download: memory error (code 5180)	

ManufacturerDeviceName

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
80	0x1008.00	-	-	STR	-	CST	-	-

Reading of the ManufacturerDeviceName. For further informations see [Section 29.1, OrderCode](#)

DeviceType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
100	0x1000.00	0x00020192	0x00020192	U32	-	CST	-	-

Code of the type of device and of its functionalities:

- The value in the two less important bytes (0x0192) shows that the device is a drive in compliance with the specification CANopen [CiA-402](#);
- The value in the two most important bytes (0x0002) shows that the drive can control the motor in closed chain.

ErrorRegister

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
102	0x1001.00	Desc	-	U8	-	RO	YES	-

Concisely indicates the status of the drive alarms that are described in the [Table 24.1](#). If a particular type of alarm is present the corresponding bit value is 1, otherwise its value is 0:

Bit	Description	Related alarms
0	Generic alarm (the value of this bit is 1 if at least one of the following bits value is 1, in other words if it has been detected at least one alarm. Otherwise it's equal to 0).	
1	Current fault.	Power or motor short circuit , Power or motor over current
2	Voltage fault	DC bus over voltage , DC bus under voltage , Logic voltage error
3	Temperature fault	Thermal management
4	Communication Warning or Fault	- If it is a BD/ETC: EtherCAT communication error - If it is a BD/CAN: CAN communication error , CANopenEmcyService and CANopenEmcyProcess .
5	Fault of the Device Profile (related to the CiA-402 regulations)	Parameters serious error , Position following error , I2T limit reached , Digital IO configuration error
6	Reserved	
7	Manufacturer fault	Real time mode error , Last command requested failed , /STO Management Error , User Fault , Feedback sensor error

Table 27.2. Bit coding of ErrorRegister

The value of this parameter is sent with the emergency messages (see [Section 9.2, Emergency object \(EMCY\)](#)).

ManufacturerHwVersion

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
110	0x1009.00	-	-	STR	-	CST	-	-

String in ASCII characters showing the hardware version of the drive.

ManufacturerSwVersion

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
114	0x100A.00	-	-	STR	-	CST	-	-

String in ASCII characters showing the software version of the drive.

Identity

Drive Identity.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1018.00	5	5	U8	-	CST	-	-

Number of parameter in this group.

VendorID

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
120	0x1018.01			U32	-	RO	-	-

Number code given to Bonfiglioli Mechatronic Research S.p.a as manufacturer of CANopen or EtherCAT devices.

ProductCode

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
122	0x1018.02	-	-	U32	-	RO	-	-

Product code.

RevisionNumber

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
124	0x1018.03	-	-	U32	-	RO	-	-

Revision of the product.

SerialNumber

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
126	0x1018.04	-	-	U32	-	RO	-	-

Drive serial number.

CpuInfo

Information about the CPU.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x5FFA.00	2	2	U8	-	CST	-	-

Number of parameters in this group.

SwResetCode

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
560	0x5FFA.03	-	0	U16	-	RO	-	-

Software reset: reset code. Please contact Bonfiglioli if it is different from 0.

SwResetInfo

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
561	0x5FFA.04	-	-	U32	-	RO	-	-

Software reset: RPC register value. It identifies a firmware internal problem.

CPUSiliconRevision

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
580	0x5FFA.01	-	-	U16	-	RO	-	-

CPU revision.

ResetCause

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
581	0x5FFA.02	-	-	U32	-	RW	-	-

Code of the cause that has caused the firmware reset.

ResetCause	Description
1	Reserved
2	Power-up reset (switching on the drive, command 5000 of SysMngCommand , firmware download Chapter 26, Software updating)
3	Reserved
4	Reset from watchdog
5	Reset from NMT reset CANopen
6	Reset from any other communication channel (command 5001 of SysMngCommand).

27.5. Communication port CANopen (1000-1099)

NOTE

This vocabulary section can be found only in the drive version CAN

CANopenPortStatus

Parameters for the management of the CANopen communication port status.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x5100.00	2	2	U8	-	CST	-	-

Number of parameters in this group.

CANopenPortEnable

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1000	0x5100.01	-	1	U16	-	RW	-	-

Enabling/disabling the CANopen communication port (0 = disabled port, otherwise enabled port).

CANopenPortSwitchSetup

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1001	0x5100.02	0 - 1	0	U16	-	RW	-	EM

Selector of the settings used to configure the CANopen communication port. This parameter is part of the [Enabled parameters after reset](#) group.

CANopen-PortSwitchSetup	Description
0	Configuration of the node number and baud rate from dip switch (Configuration from dip switch)
1	Configuration node number and baud rate with CANopenPortSetup .

NOTE

If the node number set with the dip switches is 0, you can use the configuration of the parameters [CANopenPortSetup](#).

CANopenPortSetup

Parameters used to configure the CANopen communication port from the permanent memory.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x5102.00	2	2	U8	-	CST	-	-

Number of parameters in this group.

CANopenPortSetupNodeID

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1002	0x5102.01	1 - 127	1	U16	-	RW	-	EM

Setting of the permanent memory of the node number of the CANopen communication port. This parameter is part of the group [Enabled parameters after reset](#).

CANopenPortSetupBaudRate

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1003	0x5102.02	Desc	1000000	U32	bit/s	RW	-	EM

Setting of the permanent memory of the baud rate of the CANopen communication port. This parameter belongs to the group [Enabled parameters after reset](#). The accepted values are:

- 20000;
- 50000;
- 100000;
- 125000;
- 250000;
- 500000;
- 1000000.

CANopenPortActual

Parameters showing the current configuration of the CANopen communication port.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x5108.00	2	2	U8	-	CST	-	-

Number of parameters in this group.

CANopenPortActualNodeID

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1005	0x5108.01	1 - 127	-	U16	-	RO	-	-

Current setting of the node number of the CANopen communication port.

CANopenPortActualBaudRate

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1006	0x5108.02	Desc	-	U32	bit/s	RO	-	-

Current setting of the baud rate of the CANopen communication port.

SYNC_CobID

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1010	0x1005.00	Desc	0x80	U32	-	RW	-	-

Identification code (COB-ID) of the SYNC message. The bit meaning is shown in [Table 27.3](#).

Bit	Description
0 - 10	Field at 11 bits for the standard ID (CAN 2.0).
11 - 28	Field at 18 bits for the extended ID, not supported. They must be set at 0.
29	Format identifier. It must be equal to 0 (standard identifier).
30	It must always be 0 because the iBMD series drives can be only <i>consumer</i> of the SYNC service (see Section 9.3, Synchronization object (SYNC)).
31	Reserved

Table 27.3. Bit coding of SYNC_CobID

CommunicCyclePeriod

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1012	0x1006.00	0 - 32000	0	U32	μs	RW	-	-

Time period T_{SYNC} during which the SYNC message is transmitted from the *producer* (see [Section 9.3, Synchronization object \(SYNC\)](#)). By setting a value equal to 0 the SYNC receiving is disabled by the drive.

NOTE

In case of interpolated mode use, pay attention to [Section 22.10, Interpolated Position Mode](#).

GuardTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1014	0x100C.00	-	0	U16	ms	RW	-	-

Period during which the master sends the requests to read the state of the *NMT state machine* to the drive. The drive will answer to every request with a message of *node guarding* showing the internal status of the communication. See [Error control services](#).

LifeTimeFactor

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1015	0x100D.00	-	0	U8	-	RW	-	-

By multiplying this parameter for the [GuardTime](#) you get the time-out value tolerated by the drive between two consecutive requests of the state of the *NMT state machine*. If this time-out elapses, the drive switches to Fault (see [Error control services](#)).

EMCY_CobID

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1016	0x1014.00	Desc	0x80+NodeID	U32	-	RW	-	-

Identification code (COB-ID) of the EMCY message. With *NodeID* it is meant the current node number of the drive, which can be read by the [CANOpenPortActualNodeID](#) parameter. The bit meaning is shown in [Table 27.4](#).

Bit	Description
0 - 10	Field at 11 bits for the standard ID (CAN 2.0).
11 - 28	Field at 18 bits for the extended ID, not supported. They must be set at 0.
29	Format identifier. It must be equal to 0 (standard identifier).
30	It must always be 0.
31	COB-ID Validation: if equal to 0 it is valid and the EMCY service is enabled.

Table 27.4. Bit coding of EMCY_CobID

NOTE

It is not possible to modify the bits 0 - 29 when the bit 31 is equal to 0 (EMCY service enabled).

CANopenCounters

Error frame counters of the CANopen communication port.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x5FFE.00	5	5	U8	-	CST	-	-

Number of parameters in this group.

CANopenStatusRegister

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1060	0x5FFE.02	Desc	-	U32	-	RO	-	-

Status register of the CANopen communication port. In the [Table 27.5](#) you can find the meaning of the single bits: for further information see also the specification [CAN 2.0](#).

Bit	Description
0	<i>Warning state</i> . Bit set when one of the two error counters (TEC or REC) is higher or equal to 96.
1	<i>Error-passive state</i> . Bit set when the communication port CANopen goes to the error-passive state (error counter TEC higher or equal to 128).
2	<i>Bus-off state</i> . Bit set with many errors on the communication port CANopen (error counter TEC higher or equal to 256). During the bus-off no message can be received or transmitted.

Bit	Description
3	Acknowledge error.
4	Stuff error.
5	Crc error.
6	Stuck at dominant error.
7	Bit error.
8	Form error.
9 - 15	Reserved
16 - 23	Transmit error counter (TEC). Error counter in transmission.
24 - 31	Receive error counter (REC). Receiving error counter.

Table 27.5. Bit coding of CANopenStatusRegister

CANopenCountTxErrFrame

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1062	0x5FFE.04	-	-	U32	-	RW	-	-

Counter of error frame in transmission found by the CANopen communication port.

CANopenCountRxErrFrame

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1064	0x5FFE.05	-	-	U32	-	RW	-	-

Counter of error frame in transmission found by the CANopen communication port.

CANopenEmcyRegister

Register of the emergencies sent by the drive in the communication port CANopen.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1080	0x5FF9.00	3	3	U8	-	RW	-	-

Number of parameters in this group. By writing this parameter all parameters associated to the subindexes 1-3 are reset.

CANopenEmcyService

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1082	0x5FF9.01	-	-	U32	-	RO	-	-

Specific details of the [CAN communication error](#) related to the emergencies created by the objects NMT, SYNC, EMCY and SDO.

CANopenEmcyProcess

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1084	0x5FF9.02	-	-	U32	-	RO	-	-

Specific details of the [CAN communication error](#) related to the emergencies created from the objects PDO.

CANopenEmcyDevice

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1086	0x5FF9.03	-	-	U32	-	RO	-	-

Emergencies created because of the [MainError](#) (excluding [CAN communication error](#)). The bit coding is shown in [Table 24.1](#).

27.6. Communication port EtherCAT (1000-1099)

NOTE

This vocabulary section can be found only in the drive versions ETC

EtherCATPortSetup

Parameters used to configure the EtherCAT communication port from the permanent memory.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x5102.00	1	1	U8	-	CST	-	-

Number of parameters in this group.

EtcConfiguredStationAlias

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1002	0x5102.01	-	-	U16	-	RO	-	-

Node number with which the slave can be identified in an EtherCAT network. The parameter reports the value that's contained in the "Configured Station Alias" register of the ET1100 chip (register with address 0x0012-0x0013). For further details see [Section 8.2, Communicate with master EtherCAT](#).

EtherCAT_PortActual

Current configuration of the EtherCAT communication port.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x5108.00	1	1	U8	-	CST	-	-

Number of parameters in this group.

EtcConfiguredStation

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1005	0x5108.01	-	-	U16	-	RO	-	-

Node number with which the master recognize the drive through the Fixed addressing (Node Address). The parameter reports the value that's contained in the "Configured Station Address" register of the ET1100 chip (register with address 0x0010-0x0011). For further details see [Section 8.2, Communicate with master EtherCAT](#).

CommunicCyclePeriod

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1012	0x1006.00	0 - 32000	0	U32	µs	RW	-	-

Synchronization time of the PDOs with the synchronization method [Soft sync](#).

NOTE

In case of interpolated mode use, pay attention to [Section 22.10, Interpolated Position Mode](#).

EtherCAT_Diagnostics

Specific details of [EtherCAT communication error](#).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x5FF6.00	15	15	U8	-	CST	-	-

Number of parameters in this group.

EtcRegDIStatus

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1020	0x5FF6.08	Desc	-	U16	-	RO	-	-

0x110:0x111 register of the ESC

EtcRegAIStatus

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1021	0x5FF6.09	Desc	-	U16	-	RO	-	-

0x130:0x131 register of the ESC

EtcResetPdoRxLostMaxConsecReset

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1084	0x5FF6.10	-	0	U16	-	RW	-	-

Counter of the total number of consecutively lost PDOs RX. It's automatically reset on the transition from SAFE-OPERATIONAL state to the OPERATIONAL state and it works only in the OPERATIONAL state.

EtcRegAIStatusCode

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1022	0x5FF6.0A	Desc	-	U16	-	RO	-	-

0x134:0x135 register of the ESC

EtcRegEEpromConfiguration

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1023	0x5FF6.0B	Desc	-	U16	-	RO	-	-

0x500:0x501 register of the ESC

EtcRegSyncOutUnit

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1024	0x5FF6.0C	Desc	-	U16	-	RO	-	-

0x980:0x981 register of the ESC

EtcRegSyncPulseLenght

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1025	0x5FF6.0D	Desc	-	U16	-	RO	-	-

0x982:983 register of the ESC

EtcRegSyncActivationStatus

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1026	0x5FF6.0E	Desc	-	U16	-	RO	-	-

0x984 register of the ESC

EtcRegSync0CycleTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1027	0x5FF6.0F	Desc	-	U32	-	RO	-	-

0x9A0:9A3 register of the ESC

EtcErrorRetentCommMsg

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1070	0x5FF6.01	Desc	-	U32	-	RO	-	-

Detail of the errors of the [EtherCAT communication error](#).

IMPORTANT

The Faults can be generated only if the drive is in the [Operation enable](#) (CiA-402) status. In any case it is possible to analyze the causes of an unexpected EtherCAT status change, by reading the [EtcRegAlStatusCode](#) parameter.

EtcPdoRxMissingTolerance

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1072	0x5FF6.02	0 - 128	1	U16	-	RW	-	-

Tolerance on the number of PDO RX that can be consecutively lost before the drive generates an error.

⚠ ATTENTION

We suggest to set a greater than 4 tolerance, because every not received and not interpreted PDO RX implies that the movement is not controlled by the Master (see [Section 10.3.2, Missing or corrupted PDO RX management](#)).

EtcPdoRxLostConsecutive

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1073	0x5FF6.03	-	0	U16	-	RW	-	-

Counter of the maximum number of consecutively lost PDOs RX (only updated on the OPERATIONAL state).

EtcPdoRxLostTotal

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1074	0x5FF6.04	-	0	U32	-	RW	-	-

Counter of the total number of consecutively lost PDOs RX (only updated on the OPERATIONAL state).

EtcPdoRxLostTotalReset

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1076	0x5FF6.05	-	0	S32	-	RW	-	-

Counter of the total number of lost PDOs RX. It's automatically reset on the transition from SAFE-OPERATIONAL state to the OPERATIONAL state and it works only in the OPERATIONAL state.

EtcDcPllResetOnOpe

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1078	0x5FF6.06	Desc	-	S32	-	RW	-	-

Difference between the detected [Sync Signal](#) number and the correctly received PDO RX messages number (the value is updated only if the drive is on OPERATIONAL state and if the synchronization mode is HardSync, see [Section 10.4, Synchronization](#)).

EtcPdoRxTotal

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1080	0x5FF6.07	Desc	0	U32	-	RW	-	-

Number of total frames that have been correctly received. The counter doesn't overflow, when the 32bit maximum value is reached the counting stops until its value is modified by a writing operation. It is possible to write any value, it will be reset on the SAFEOPERATIONAL -> OPERATIONAL transition.

27.7. Auxiliary communication port (1100-1199)

AuxiliaryPortSetup

Parameters used to configure the auxiliary communication port.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x5120.00	4	4	U8	-	CST	-	-

Number of parameters in this group.

AuxiliaryPortSetupWordOrder

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1100	0x5120.01	0 - 1	0	U16	-	RW	-	EM

Order of the words used by the drive, through the auxiliary port, to receive or send the parameters of 32 bits (the byte order of the words is big-endian, as defined by the specification of the Modbus protocol, implemented in the auxiliary port).

Auxiliary Port Setup Word Order	Description	Example
0	Word sent in little-endian format.	The value 0x12345678 is sent in the order 0x5678 0x1234.
1	Word sent in big-endian format.	The value 0x12345678 is sent in the order 0x1234 0x5678.

AuxiliaryPortSetupTimeout

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1101	0x5120.02	20 - 65000	50	U16	ms	RW	-	EM

Timeout of the auxiliary port. If the time between two consecutive characters overcomes this value, the interface cancels the ongoing receiving of the whole frame and it prepares to receive a new frame.

AuxiliaryPortSetupBaudRateImmediate

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1110	0x5120.03	19200 or 57600	57600	U32	bit/s	RW	-	-

Parameters used for the immediate exchange of the baud rate of the auxiliary port. Once received the request to change the baud rate, the drive sends the answer with the precedent baud rate and only after it configures the communication interface with the new baud rate.

AuxiliaryPortSetupBaudRate

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1112	0x5120.04	19200 o 57600	57600	U32	bit/s	RW	-	EM

Baud rate of the auxiliary port. This parameter is included in the [Enabled parameters after reset](#) group.

AuxiliaryPortError

Parameters to read the last error condition in writing or reading carried out with the auxiliary communication port.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x5124.00	2	2	U8	-	CST	-	-

Number of parameters in this group.

AuxiliaryPortErrorParam

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1120	0x5124.01	-	0	U16	-	RW	-	-

Modbus address of the parameter that generated the last error condition during the writing/reading phase with the auxiliary communication port. An access in writing causes the resetting of this parameter and of the parameter [AuxiliaryPortErrorCode](#).

AuxiliaryPortErrorCode

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1121	0x5124.02	Desc	0	U16	-	RW	-	-

Error code of the last error condition found during the writing/reading phase with the auxiliary communication port. An access in writing causes the resetting of this parameter and of the parameter [AuxiliaryPortErrorParam](#). The meaning of the codes can be found in [Table 8.9](#).

27.8. Motor, drive and I2T (1200-1299)

MotorParameters

Motor parameters.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x6410.00	15	15	U8	-	CST	-	-

Number of parameters in this group. For any further information, see [Section 15.1, Motor parametrization](#).

MotorStallCurrent

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1201	0x6410.01	-	-	U16	100 = 1A	RW	-	EM

It is the motor stall current, that corresponds to the current of the maximum motor torque, with a close to 0 velocity, without its thermal limits are exceeded.

MotorPeakCurrent

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1202	0x6410.02	-	-	U16	100 = 1A	RW	-	EM

Motor peak current.

CoggingTorque(CoggingForce)

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1203	0x6410.03	-	-	U16	Desc	RW	-	EM

Motor cogging torque. The measurement unit depends on the motor type: rotative motor [1000 = 1Nm], linear motor [1000 = 1N].

MotorInductance

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1204	0x6410.04	-	-	U16	100 = 1mH	RW	-	EM

Phase-phase motor inductance.

MotorResistance

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1205	0x6410.05	-	-	U16	mΩ	RW	-	EM

Phase-phase motor resistance.

MotorInertia(MotorMass)

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1206	0x6410.06	-	-	U16	Desc	RW	-	EM

Motor moment of inertia. The unit of measurement depends on the motor type: rotary motor [1 = 10g cm²], linear motor [1 = 10g].

TorqueConstant(ForceConstant)

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1212	0x6410.08	-	-	U16	Desc	RW	-	EM

Motor torque constant. The unit of measurement depends on the motor type: rotary motor [1000 = 1Nm/A], linear motor [10 = 1N/A].

MotorRatedSpeed

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1213	0x6410.09	-	-	U32	Desc	RW	-	EM

Motor nominal velocity. The unit of measurement depends on the motor type: rotary motor [rpm], linear motor [mm/s].

MotorPoles

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1215	0x6410.0A	-	-	U16	-	RW	-	EM

Number of motor poles.

FaultTemperatureThrs

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1216	0x6410.0B	-	-	U16	-	RW	-	EM

Motor temperature fault threshold.

For further details please see [Table 24.3](#).

MotorMotionType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1217	0x6410.0C	0 ÷ 1	-	U16	-	RW	-	EM

Motor type: 0 = rotary, 1 = linear.

PolePitch

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1218	0x6410.0D	-	-	U16	mm	RW	-	EM

Linear motor pole pitch.

MotorFaultTemperatureThrsOhm

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1219	0x6410.0E	-	-	U32	Ω	RW	-	EM

Resistance value that causes the motor temperature Fault, if the motor temperature sensor is PTC.

MotorTemperatureSensorType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1221	0x6410.0F	0-2	-	U16	-	RW	-	EM

Temperature sensor type built on the motor. For the temperature value reading, if this parameter value is 1 please refer to [MotorTemperature](#), if it is 2 refer to [MotorTemperaturePTC](#).

Code	Sensor type
0	No sensor – the temperature measurement is disabled
1	KTY84
2	PTC SWITCH

NOTE

The temperature sensor is present only since the [HardwareRevision 5](#). Drives with previous hardware versions can be configured only if [MotorTemperatureSensorType](#) = 0.

DriveParameters

Drive parameters.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x6510.00	-	4	U8	-	CST	-	-

Number of parameters in this group.

UserDriveName

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1250	0x6510.04	-	-	-	-	RW	-	EM

Drive name, given by the user. For an easier drive identification, it's possible to insert an alphanumeric string of up to 16 characters. The UserDriveName parameter must be considered as any other parameter: it's saved in the permanent memory and it's managed by the parameters file as the others parameters. UserDriveName is showed on the connection status and in the main page heading.

MaxRatedCurrent

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1253	0x6510.01	-	-	U16	100 = 1A	RO	-	-

Drive nominal current, power section.

MaxPeakCurrent

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1254	0x6510.02	-	-	U16	100 = 1A	RO	-	-

Drive peak current, power section.

MaxSupplyVoltage

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1255	0x6510.03	-	-	U16	V	RO	-	-

Maximum supply voltage, power section.

I2TParameters

Parameters of the I2T limitation.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x3405.00	-	6	U8	-	CST	-	-

Number of parameters in this group. For further details see [Section 14.6, I2T](#).

UserPeakCurrent

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1258	0x3405.06	-	Desc	U16	100 = 1A	RW	YES	ES

Peak current that can be set by the user to limit the current supply to the motor. It contributes to determine [UserMaxI2T](#). UserPeakCurrent must be different from zero and lower or equal to [MotorPeakCurrent](#) and [MaxPeakCurrent](#). Its default value is the lowest value between [MotorPeakCurrent](#) and [MaxPeakCurrent](#).

I2TTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1259	0x3405.01	-	Desc	U16	ms	RW	-	ES

Maximum time the drive can keep the motor current at the value of [PeakCurrent](#). It contributes to determine [UserMaxI2T](#). Its default value is so that [UserMaxI2T](#) is lower than [DriveMaxI2T](#), with a maximum value of 5s.

UserMaxI2T

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1260	0x3405.02	-	-	U32	A ² s	RO	-	-

Maximum value of I2T calculated depending on [PeakCurrent](#) and [I2TTime](#). Its value must be lower than [DriveMaxI2T](#).

DriveMaxI2T

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1262	0x3405.03	-	-	U32	A ² ms	RO	-	-

Maximum value of drive I2T.

I2TWarningThreshold

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1264	0x3405.04	0-100	80	U16	%	RW	-	ES

Warning threshold enabling the [I2T Warning threshold reached](#) error.

27.9. Tuning (1400-1499)

ResetWatchdogTimeout

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1400	0x3500.00	-	-	U16	-	WO	-	-

Write in this parameter the [SysMngCommand](#) value to execute the [Reset of the Watchdog of the System manager](#).

TuningConfigurations

TuningConfigurations.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x3502.00	-	4	U8	-	CST	-	-

Number of parameters in this group.

DynamicResponse

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1401	0x3502.01	-	150	U16	-	RW	YES	ES

Tuning configuration used to select the dynamic response of the motor.

DynamicResponse	Description
120	Lowest
130	Very low
140	Low
150	Medium
160	High
170	Very high
180	Highest

Stiffness

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1402	0x3502.02	-	150	U16	-	RW	YES	ES

Tuning configuration used to select the motor stiffness at low velocities. Low speeds are 30% lower than the [HighSpeed](#) parameter.

Stiffness	Description
130	Very low
140	Low
150	Medium
160	High
170	Very high

VelocityLoopFilter1

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1403	0x3502.03	-	2	U16	-	RW	YES	ES

Tuning configuration that defines the filtering action of the velocity loop. For further details see "*Tuning configuration modifications*" in the [Section 20.3, "Fast tuning guide"](#).

VelocityLoopFilter1	Description
1	User
2	Noise filter
3	Disable
51	Soft filter

VelocityLoopFilter2

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1404	0x3502.04	-	3	U16	-	RW	YES	ES

Tuning configuration selecting the second filter of the speed loop. For further details please see "*Tuning configuration modifications*" in the [Section 20.3, "Fast tuning guide"](#).

VelocityLoopFilter2	Description
1	User
2	Resonance filter

VelocityLoopFilter2	Description
3	Disable
50	Debounce filter

EstimatedLoopsBandwidth

Loops estimated bandwidths.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x3501.00	-	3	U8	-	CST	-	-

Number of parameters in this group.

CurrentLoopEstimatedBandwidth

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1407	0x3501.01	-	-	U16	Hz	RO	-	-

CurrentLoop estimated bandwidth.

VelocityLoopEstimatedBandwidth

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1408	0x3501.02	-	-	U16	Hz	RO	-	-

VelocityLoop estimated bandwidth.

PositionLoopEstimatedBandwidth

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1409	0x3501.03	-	-	U16	Hz	RO	-	-

PositionLoop Estimated Bandwidth.

TuningEndOption

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1450	0x3515.08	-	22	S16	-	RW	-	-

Operation that is executed when the End button of the MotionDrive (command 100 of the [System Manager](#)) is pushed.

TuningEndOption	Description
0	Immediately disable, the motor is stopped with maximum deceleration resetting RequestedSpeed to zero and then the drive has the <i>Switch On Disabled</i> state
10	Zero speed and disable, the motor is stopped with maximum deceleration resetting RequestedSpeed at zero and then the drive has the <i>Switch On Disabled</i> state
11	Zero speed and switched on, the motor is stopped with maximum deceleration, by resetting RequestedSpeed at zero, and then the drive has the <i>Switched On</i> state

TuningEndOption	Description
12	Zero speed and previous state, the motor is stopped with maximum deceleration resetting RequestedSpeed at zero and then the drive has the same status before the requested tuning command
20	Deceleration ramp and disable, the motor is stopped with a deceleration equal to TuningEndDeceleration and then the drive has the <i>Switch On Disabled</i> state
21	Deceleration ramp and switched on, the motor is stopped with a deceleration equal to TuningEndDeceleration and then the drive has the <i>Switched On</i> state
22	Deceleration ramp and previous state, the motor is stopped with a deceleration equal to TuningEndDeceleration and then the drive has the same status before the requested tuning command

TuningEndDeceleration

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1451	0x3515.09	Desc	Desc	U32	inc/s ²	RW	-	-

Motor deceleration value when the End button in MotionDrive is pushed (command 100 of the [System Manager](#)). The default value is 1000.0 rad/s² while the range of the accepted values goes from 0.32 to 205887.3 rad/s².

InertiaEstimator

Parameters for the inertia estimation

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x3503.00	6	6	U8	-	CST	-	-

Number of parameters in this group.

InertiaEstimatorDirection

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1460	3503.01	-	0	U16	-	RW	-	-

Rotation direction of the drive shaft using the inertia estimator (0 = positive, 192 = negative).

EstimatorTorque

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1461	3503.02	0 ÷ 32767	1000	U16	10 = 1%IS	RW	-	-

Torque requested to the motor using the inertia estimator.

InertiaEstimatorVelocity

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1462	3503.03	-	Desc	U32	inc/s	RW	-	-

Velocity requested to the motor using the inertia estimator. The default value is 100.0 rad/s.

EstimatedDampingFactor

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1464	3503.04	-	Desc	U16	0,0001 A s	RW	-	EM

Estimated value between the viscous friction and [TorqueConstant\(ForceConstant\)](#).

EstimatedInertia

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1466	0x3503.05	-	10	U16	10 = 1Jm	RW	-	EM

Total inertia moment, calculated compared to the motor shaft. EstimatedInertia must take into consideration the moments of motor inertia, brake mechanical transmission and load.

InertiaReductionFactor

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1467	0x3503.06	0 ÷ 1000	1000	U16	Desc	RW	-	EM

Reduction factor of [EstimatedInertia](#) (0 = maximum reduction, 1000 = no reduction). The result of the reduction is used to calculate the regulation loops gains.

RLEstimator

Parameters for the phase resistance and the motor inductance

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x3504.00	12	12	U8	-	CST	-	-

Number of parameters in this group.

IMPORTANT

The [EstimatedPhaseResistance](#), [EstimatedLDNominalP](#), [EstimatedLDNominalN](#), [EstimatedLDPeakP](#), [EstimatedLDPeakN](#), [EstimatedLQNominalP](#), [EstimatedLQNominalN](#), [EstimatedLQPeakP](#), [EstimatedLQPeakN](#) parameters cannot be downloaded through the parameters file because they are specific for every axis. On the contrary, the parameters file download reset them to the default value.

EstimatedPhaseResistance

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1470	0x3504.01	-	-	U16	mΩ	RO	-	EM

Phase resistance estimated with RLEstimator(see [Section 20.7, RL estimator](#)).

MotorPhaseResistance

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1471	0x3504.02	-	-	U16	mΩ	RO	-	EM

Theoretical phase resistance obtained with the motor nameplate data ([MotorResistance](#)).

MotorSynchronousInductance

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1473	0x3504.04	-	-	U16	100 = 1mH	RO	-	EM

Theoretical synchronous inductance obtained with the motor nameplate data ([MotorInductance](#)).

EstimatedLDNominalP

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1474	0x3504.05	-	-	U16	100 = 1mH	RO	-	EM

Synchronous inductance, estimated with RLEstimator and positive [ActualFieldCurrent](#) equal to [NominalCurrent](#).

EstimatedLDNominalN

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1475	0x3504.06	-	-	U16	100 = 1mH	RO	-	EM

Synchronous inductance, estimated with RLEstimator and negative [ActualFieldCurrent](#) equal to [NominalCurrent](#).

EstimatedLDPeakP

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1476	0x3504.07	-	-	U16	100 = 1mH	RO	-	EM

Synchronous inductance, estimated with RLEstimator and positive [ActualFieldCurrent](#) equal to [PeakCurrent](#).

EstimatedLDPeakN

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1477	0x3504.08	-	-	U16	100 = 1mH	RO	-	EM

Synchronous inductance, estimated with RLEstimator and negative [ActualFieldCurrent](#) equal to [PeakCurrent](#).

EstimatedLQNominalP

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1478	0x3504.09	-	-	U16	100 = 1mH	RO	-	EM

Synchronous inductance, estimated with RLEstimator and positive [ActualTorqueCurrent](#) equal to [NominalCurrent](#).

EstimatedLQNominalN

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1479	0x3504.0A	-	-	U16	100 = 1mH	RO	-	EM

Synchronous inductance, estimated with RLEstimator and negative [ActualTorqueCurrent](#) equal to [NominalCurrent](#).

EstimatedLQPeakP

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1480	0x3504.0B	-	-	U16	100 = 1mH	RO	-	EM

Synchronous inductance, estimated with RLEstimator and positive [ActualTorqueCurrent](#) equal to [PeakCurrent](#).

EstimatedLQPeakN

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1481	0x3504.0C	-	-	U16	100 = 1mH	RO	-	EM

Synchronous inductance, estimated with RLEstimator and positive [ActualTorqueCurrent](#) equal to [PeakCurrent](#).

EstimatedResonanceFrequency

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1483	0x3505.01	-	-	U16	Hz	RW	-	EM

Estimated value of the mechanical resonance frequency.

VelocityStandStill

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1490	0x3523.00	-	-	U16	-	RW	-	ES

Regulation of the gains of the speed regulator for low speeds (it modifies both [KVp_LS](#) and [KVi_LS](#)).

27.10. Loop (1500-1599)

ResetSpeedIntegrator

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1516	0x60F9.22	-	-	U16	-	WO	-	-

By writing any value in this parameter, the integrative memory of the velocity regulator is reset to 0.

LoopConfiguration

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1529	0x3522.00	0 ÷ 2	2	U16	-	RW	-	ES

Loops configuration.

LoopConfiguration	Description
0	Gains not set
1	Basic configuration (available with every FirmwareRevision).
2	Smith configuration (available since FirmwareRevision ≥ 14).

VelocityLoop




Figure 27.1. Flow chart of the speed regulator.

Velocity loop.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x60F9.00	-	33	U8	-	CST	-	-

Number of parameters in this group. The VelocityLoop is composed by the following blocks:

- input speed limiter
- PID regulator with more degrees of freedom made up by five components: acceleration feed forward, derivative with weight and filter, integral with persistence limit (AWU), proportional with weight, damping.
- three filters in the regulator output
- one filter on the sensor of the feedback position
- limiter of the output torque.

EnableVelocityStandStill

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1500	0x60F9.17	-	-	U16	-	RW	YES	ES

Enabling of the **VelocityStandStill**: (0 = disabled, 1 = enabled).

LowSpeed

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1501	0x60F9.09	-	-	U32	inc/s	RW	YES	ES

Speed threshold to use only the Stand still parameters.

HighSpeed

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1505	0x60F9.08	-	-	U32	inc/s	RW	YES	ES

Out of this speed threshold the Stand still parameters do not have any effect.

KVp_LS

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1509	0x60F9.04	-	-	U16	-	RW	YES	ES

Proportional gain of the speed regulator for low speeds.

KVi_LS

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1511	0x60F9.05	-	-	U16	-	RW	YES	ES

Integral gain of the speed regulator for low speeds.

ActualKVp

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1513	0x60F9.0C	-	-	U16	-	RO	YES	-

Proportional gain currently used by the speed regulator.

ActualKVi

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1515	0x60F9.0D	-	-	U16	-	RO	YES	-

Integral gain currently used by the speed regulator.

KVp

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1517	0x60F9.01	-	-	U16	-	RW	YES	ES

Proportional gain of the speed regulator.

KVi

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1519	0x60F9.03	-	-	U16	-	RW	YES	ES

Integral gain of the speed regulator.

KVdFilterFrequency

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1524	0x60F9.10	-	-	U16	-	RW	YES	ES

Typical filter frequency on the derivative component of the speed regulator. By increasing this parameter, the filtering action decreases.

KVd

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1525	0x60F9.11	-	-	U16	-	RW	YES	ES

Derivative gain of the speed regulator.

WVd

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1526	0x60F9.12	-	-	U16	1000 = 1	RW	YES	ES

Weighting coefficient of the speed reference in the calculation of the derivative component.

WVp

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1527	0x60F9.13	-	-	U16	1000 = 1	RW	YES	ES

Weighting coefficient of the speed reference in the calculation of the proportional component.

KVc

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1528	0x60F9.14	-	-	U16	-	RW	YES	ES

Damping gain of the speed regulator.

VFilter1Frequency

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1540	0x60F9.0E	-	-	U16	Hz	RW	YES	ES

Typical frequency of the first filter on the output of the speed regulator.

VFilter1Type

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1541	0x60F9.0F	-	-	U16	-	RW	YES	ES

Type of the first filter on the output of the speed regulator.

VFilterType1	Description
0	All-stop filter
1	Low-pass filter of the first order
2	Low-pass filter of the second order
3	Band-eliminating filter
65535	All-pass filter

VFilter1QFactor

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1542	0x60F9.18	-	-	U16	10 = 1	RW	YES	ES

Quality Q factor of the first filter on the output of the speed regulator.

VFilter2Frequency

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1543	0x60F9.19	-	-	U16	Hz	RW	YES	ES

Typical frequency of the second filter on the output of the speed regulator.

VFilter2Type

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1544	0x60F9.1A	-	-	U16	-	RW	YES	ES

Type of the second filter on the output of the speed regulator.

VFilterType2	Description
0	All-stop filter
1	Low-pass filter of the first order
2	Low-pass filter of the second order
3	Band-eliminating filter
65535	All-pass filter

VFilter2QFactor

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1545	0x60F9.1B	-	-	U16	10 = 1	RW	YES	ES

Quality Q factor of the second filter on the output of the speed regulator.

VFilter3Frequency

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1546	0x60F9.1C	-	-	U16	Hz	RW	YES	ES

Typical frequency of the third filter on the output of the speed regulator.

VFilter3Type

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1547	0x60F9.1D	-	-	U16	-	RW	YES	ES

Type of the third filter on the output of the speed regulator.

VFilterType3	Description
0	All-stop filter
1	Low-pass filter of the first order
2	Low-pass filter of the second order
3	Band-eliminating filter
65535	All-pass filter

VFilter3QFactor

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1548	0x60F9.1E	-	-	U16	10 = 1	RW	YES	ES

Quality Q factor of the third filter on the output of the speed regulator.

DegaussTypeFilter

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1557	0x3520.06	Desc	2	U16	-	RW	-	ES

Selector that allows to activate/deactivate the field weakening functionality, by acting on the filter type on the homonymous regulator output and that is not part of any loop in the Loop settings page. The values that can be inserted are listed in the following table:

DegaussTypeFilter	Description
0	Disable weakening - All-stop filter
1	Enable weakening - Low-pass filter of the first order
2	Enable weakening - Low-pass filter of the second order
3	Enable weakening - Band-eliminating filter
65535	Enable weakening - All-pass filter

VFilterSensorFrequency

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1570	0x60F9.1F	-	-	U16	Hz	RW	YES	ES

Typical frequency of the filter on the feedback position sensor.

VFilterSensorType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1571	0x60F9.20	-	-	U16	-	RW	YES	ES

Filter type on the sensor of the feedback position.

VFilterTypeSensor	Description
0	All-stop filter
1	Low-pass filter of the first order
2	Low-pass filter of the second order
3	Band-eliminating filter
65535	All-pass filter

VFilterSensorQFactor

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1572	0x60F9.21	-	-	U16	10 = 1	RW	YES	ES

Quality Q factor of the filter on the feedback position sensor.

KAff

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1590	0x60F9.16	-	-	U16	1000 = 1	RW	YES	ES

Acceleration feed forward gain.

PositionLoop




Figure 27.2. Flow chart of the position regulator.

Position loop.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x60FB.00	-	6	U8	-	CST	-	-

Number of parameters in this group. The position regulator is of P type, made up of two components, proportional and speed feed forward. Just at its input there is the resetting block of the [PositionFollowingError](#) when it is included in the [PositionErrorDeadBand](#) (EDB) located near the zero.

KPp

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1560	0x60FB.01	-	-	U16	-	RW	YES	ES

Proportional gain of the position regulator.

KVff

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1561	0x60FB.02	-	-	U16	1000 = 1	RW	YES	ES

Velocity feed forward gain.

PositionStandStill

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1562	0x60FB.03	-	-	U16	-	RW	YES	ES

Proportional gain of the position regulator for low velocities.

EnablePositionStandStill

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1563	0x60FB.04	-	-	U16	-	RW	YES	ES

Enabling of the [PositionStandStill](#): (0 = disabled, 1 = enabled).

ActualKPp

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1564	0x60FB.05	-	-	U16	-	RO	YES	-

Proportional gain currently used by the position regulator.

ClosePositionLoop

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1565	0x60FB.06	-	1	U16	-	RW	YES	ES

It enables the internal closure of the drive of the position loop.

PositionErrorDeadBand

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1565	0x4281.01	-	0	U16	inc	RW	-	ES

Half width of the dead band of the [PositionFollowingError](#).

CurrentLoop




Figure 27.3. Flow chart of the logical part of the CurrentLoop. Number of parameters in this group.

Current loop.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x60F6.00	10	10	U8	-	CST	-	-

Number of parameters in this group. The current regulator is of PI type, made up of the two components, proportional and integral with persistence limit of the integral part (Anti Wind Up). For the regulator you can use two different gain torques: one for the torque component and one for the field component.

KCp_Q

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1580	0x60F6.01	-	-	U16	-	RW	YES	ES

Proportional gain of the torque current regulator.

KCi_Q

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1581	0x60F6.02	-	-	U16	-	RW	YES	ES

Integral gain of the torque current regulator.

KCp_D

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1582	0x60F6.03	-	-	U16	-	RW	YES	ES

Proportional gain of the field current regulator.

KCi_D

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1583	0x60F6.04	-	-	U16	-	RW	YES	ES

Integral gain of the field current regulator.

KC_FilterFrequency

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1584	0x60F6.06	-	-	U16	Hz	RW	YES	ES

Typical frequency of the filter on the output of the current regulators.

KC_FilterType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1585	0x60F6.07	-	-	U16	-	RW	YES	ES

Type of the filter on the output of the current regulator.

KC_FilterFrequency	Description
0	All-stop filter
1	Low-pass filter of the first order
2	Low-pass filter of the second order
3	Band-eliminating filter
65535	All-pass filter

KC_FilterQFactor

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1586	0x60F6.08	-	-	U16	10 = 1	RW	YES	ES

Quality factor of the filter on the current regulators output.

KC_QReduction

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1587	0x60F6.09	0 ÷ 1000	-	U16	Desc	RW	YES	ES

Gains reduction factor to compensate the Lq saturation (0 = no reduction, 1000 = maximum reduction).

EnableLoopCompensation

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1588	0x60F6.05	-	-	U16	-	RW	YES	ES

Each bit of this parameter enables the related functionality. The functionalities are listed in the following table.

Bit	Name	Description
0	EMF Compensation	enable the counterelectromotive force compensation.
1	crossDQ	Cross coupling contributions compensation of the current regulators.
2	Reserved	-
3	Predictive current measurement	enable the predictive current measurement.
4	KC_QReduction	enable the gains reduction to compensate the Lq saturation.

AngleObserverBandwidth

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1589	0x60F6.0A	-	-	U16	Hz	RW	YES	ES

Natural frequency of the observer that estimates the rotor position.

LoopType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1595	0x3080.00	0 ÷ 1	0	U16	-	RW	-	-

Loops control mode (0 = Servo mode, 1 = Micro step).

27.11. Power Pwm (1600-1699)

PowerPwmParameters

Power pwm parameters.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x3521.00	-	7	U8	-	CST	-	-

Number of parameters in this group. For further details see [Section 14.5, Power PWM](#).

PwmBridgeFrequency

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1600	0x3521.01	1500-30000	5000	U16	Hz	RO	-	ES

Three-phase bridge modulation frequency.

PwmModulationMethod

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1601	0x3521.02	2	2	U16	-	RO	-	ES

Modulation type of the three-phase bridge; 2 = asymmetrical.

PwmMotionLoopDivider

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1602	0x3521.03	-	1	U16	-	RO	-	ES

Reduction factor of the loop motion period compared to the current loop period.

PwmMotionLoopCode

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1603	0x3521.07	-	0	U16	-	WO	-	-

Unique code to set the frequency of the three-phase bridge and of the loop period. Writable only when the motor is disabled.

PwmMotion-LoopCode	PwmBridge-Frequency	PwmModulationMethod	PwmMotion-LoopDivider	Motion-LoopPeriod	Current-LoopPeriod
0	5000	2	1	100	100

MotionLoopPeriod

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1610	0x3521.04	-	100	U16	μs	RO	-	-

Motion loop period.

CurrentLoopPeriod

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1611	0x3521.05	-	100	U16	μs	RO	-	-

Current loop period.

27.12. Drive status (1800-1999)

TemperatureStatus

Temperature status.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x3300.00	-	5	U8	-	CST	-	-

Number of parameters in this group.

PowerTemperature

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1800	0x3300.01	-	-	S16	10 = 1°C	RO	YES	-

Power section actual temperature.

LogicTemperature

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1801	0x3300.02	-	-	S16	10 = 1°C	RO	YES	-

Control section actual temperature.

MotorTemperature

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1802	0x3300.03	-	-	S16	10 = 1°C	RO	YES	-

Actual motor temperature (if the selected sensor is KTY, see [MotorTemperatureSensorType](#)).

FeedbackSensorTemperature

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1803	0x3300.04	-	-	S16	1 = 1°C	RO	YES	-

Feedback sensor temperature. This parameter returns the temperature only if it is installed an Absolute encoder Hiperface position sensor (see [Section 15.4, Absolute feedback position sensor](#)). With the other sensor types this cell returns 0.

MotorTemperaturePTC

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1804	0x3300.05	-	-	S32	Ω	RO	YES	-

Resistor value for the motor temperature when the selected sensor is PTC (see [MotorTemperatureSensorType](#)).

DCBusVoltage(+HV)

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1840	0x3310.01	-	-	U16	10 = 1V	RO	YES	-

DC bus voltage feeding the drive power section.

I2TValue

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1880	0x3405.05	-	-	U16	%	RO	YES	-

Actual value of I2T.

CurrentStatus

Current status.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x3320.00	-	9	U8	-	CST	-	-

Number of parameters in this group.

ActualMotorCurrent

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1881	0x3320.01	-	-	U16	100 = 1A	RO	YES	-

Motor actual current.

ActualFieldCurrent

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1883	0x3320.02	-	-	U16	100 = 1A	RO	YES	-

Motor actual field current (Id).

ActualTorqueCurrent

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1884	0x3320.03	-	-	U16	100 = 1A	RO	YES	-

Motor actual torque current (Iq).

OverCurrentAValue

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1885	0x3320.05	-	-	U16	100 = 1A	RO	YES	-

Motor A phase current in [Power](#) or [motor over current](#) conditions.

OverCurrentBValue

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1886	0x3320.06	-	-	U16	100 = 1A	RO	YES	-

Motor B phase current in [Power](#) or [motor over current](#) conditions.

OverCurrentCValue

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1887	0x3320.07	-	-	U16	100 = 1A	RO	YES	-

Motor C phase current in [Power or motor over current](#) conditions.

RMSMotorCurrent

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1888	0x3320.08	-	-	U16	100 = 1A	RO	YES	-

Motor RMS current.

RMSMotorCurrentFilter

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1889	0x3320.09	-	100	U16	100 = 1s	RW	-	ES

Filtering time to get the [RMSMotorCurrent](#). RMSMotorCurrentFilter must be different from 0. Too low values of RMSMotorCurrentFilter can generate swinging in [RMSMotorCurrent](#). Too high values of RMSMotorCurrentFilter slow down the convergence of [RMSMotorCurrent](#). Writing in the parameter RMSMotorCurrentFilter, the time value of machine cycle the drive belongs to, it is possible to get a stable and convergent [RMSMotorCurrent](#) in ten machine cycles.

AIOAcquiringStatus

Acquiring through the analog input 0.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x3330.00	-	2	U8	-	CST	-	-

Number of parameters in this group. For further details see [Section 17.1, Capture](#).

AIOVoltage

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1930	0x3330.01	-	-	S16	mV	RO	YES	-

Actual value of the not filtered analog input 0. The updating time of this parameter is [CurrentLoopPeriod](#).

AIOFilteredVoltage

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
1931	0x3330.02	-	-	S16	mV	RO	YES	-

Actual value of the filtered analog input 0. The updating time of this parameter is [MotionLoopPeriod](#).

27.13. Fault and Warning (2000-2199)

FaultMask

Masks representing the Faults features. The relation between the masks bits and the Faults is shown in [Table 24.1](#).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x3000.00	3	3	U8	-	CST	-	-

Number of parameters in this group. For further details see [Section 24.4, Reaction to the Faults](#)

FaultMaskAutoErase


Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2000	0x3000.01	Desc	0	U32	-	RW	-	ES

Auto-restoring Fault mask the Fault Reset command is automatically run for. The Fault Reset runs when the Fault cause has been removed and there are no more retentive Faults. In [Table 24.1](#) you can find the errors that can become auto-restoring through this parameter.

FaultMaskEnable

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2002	0x3000.02	Desc	Desc	U32	-	RW	-	ES

Error mask the Fault signal has been enabled for. In [Table 24.1](#) you can find the Faults that can be enabled/disabled through this parameter. All Fatal Faults, all bits for future uses and the Faults [Real time mode error](#), [CAN communication error](#), [EtherCAT communication error](#), [Position following error](#), [User Fault](#), [I2T limit reached](#) and [Logic voltage error](#) are enabled by default.



NOTICE

If the Fault signal is disabled, the related bits in the Fault registers will always be 0 and the drive will consequently not reach the Fault state because of that error cause.

FaultMaskSafetyPrfExecute

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2004	0x3000.03	Desc	0x180	U32	-	RW	-	ES

Fault mask generating the [Safety profile](#). In [Table 24.1](#) you can find the Faults that can generate the [Safety profile](#).

FaultReactionOptionCode

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2049	0x605E.00	Desc	-1	S16	-	RW	-	ES

Action run in case of Non fatal Fault and with disabled [Safety profile](#). For further information see [Section 24.4, Reaction to the Faults](#).

FaultReactionOptionCode	Action
-1	The motor is stopped with maximum deceleration by resetting RequestedSpeed and then the drive reaches the <i>Fault</i> state.
1	The motor is stopped with deceleration equal to ProfileDeceleration and then the drive reaches the <i>Fault</i> state.
2	The motor is stopped with deceleration equal to QuickStopDeceleration and then the drive reaches the <i>Fault</i> state.

SafetyPrfConfiguration

Parameters to configure the [Safety profile](#).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x300C.00	4	4	U8	-	CST	-	-

Number of parameters in this group.

SafetyPrfTargetPosition

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2050	0x300C.01	-	0	S32	inc	RW	-	ES

Absolute position target to reach when the safety profile is run.

SafetyPrfVelocity

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2052	0x300C.02	Desc	Desc	U32	inc/s	RW	-	ES

Running speed of the safety profile. The default value and the adjustable maximum value are respectively 3.0 rad/s and 3216.9 rad/s. It cannot be set with a zero value.

SafetyPrfAcceleration

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2054	0x300C.03	Desc	Desc	U32	inc/s ²	RW	-	ES

Acceleration of the safety profile. The default value is 125.0 rad/s² while the range of the accepted values goes from 0.32 to 205887.3 rad/s².

SafetyPrfDeceleration

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2056	0x300C.04	Desc	Desc	U32	inc/s ²	RW	-	ES

Deceleration of the safety profile. The default value is 125.0 rad/s² while the range of the accepted values goes from 0.32 to 205887.3 rad/s².

SafetyPrfCommand

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2065	0x3010.01	Desc	0	U16	-	RW	-	-

Command to enable/disable the safety profile. For further information see [Section 24.4, Reaction to the Faults](#).

SafetyPrfCommand	Description
0	Safety profile not enabled.
1	Safety profile enabled and configured with the same parameters of the <i>Profile Position Mode</i> .
2	Safety profile enabled and configured with the parameters defined in SafetyPrfConfiguration . The speed of the profile beginning and end are not valid.

ADVICE

It is advisable to choose 2 for SafetyPrfCommand to have more flexibility and less restrictions.

MainError

Drive main errors. The bit encoding is shown in [Table 24.1](#).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x3014.00	4	4	U8	-	CST	-	-

Number of parameters in this group.

WarnRetentive

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2070	0x3014.01	Desc	0	U32	-	RW	-	-

Main retentive warnings.

WarnDynamic

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2072	0x3014.02	Desc	0	U32	-	RO	-	-

Main dynamic warnings.

FaultRetentive

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2074	0x3014.03	Desc	0	U32	-	RO	YES	-

Main retentive faults.

FaultDynamic

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2076	0x3014.04	Desc	0	U32	-	RO	YES	-

Main dynamic faults.

ErrorCode

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2078	0x603F.00	Desc	0	U16	-	RO	YES	-

Register that reports the error code of the last detected error. The possible codes are reported in the [Table 9.3](#) for the CAN versions and in the [Table 10.3](#) for the ETC versions. The parameter is reset on the Fault Reset command (see [Table 8.13](#)).

RealTimeModeError

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2080	0x3018.00	Desc	0	U16	-	RO	-	-

Specific details of the [Real time mode error](#).

LimitReachedError

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2081	0x3019.00	Desc	0	U16	-	RO	-	-

Specific details of the [Limit reached](#).

ParamSoftError

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2082	0x301A.00	Desc	0	U16	-	RO	-	-

Specific details of the [Parameters soft error](#).

MotionParamLimitedError

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2083	0x301B.00	Desc	0	U16	-	RO	-	-

Specific details of the [Motion parameter limited](#).

ThermalManageError

Specific details of the [Thermal management](#).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x302C.00	4	4	U8	-	CST	-	-

Number of parameters in this group.

ThermalManageWarnRetentive

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2100	0x302C.01	Desc	0	U16	-	RO	-	-

Details of the retentive Warnings of the [Thermal management](#).

ThermalManageWarnDynamic

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2101	0x302C.02	Desc	0	U16	-	RO	-	-

Details of the dynamic Warnings of the [Thermal management](#).

ThermalManageFaultRetentive

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2102	0x302C.03	Desc	0	U16	-	RO	-	-

Details of the retentive Faults of the [Thermal management](#).

ThermalManageFaultDynamic

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2103	0x302C.04	Desc	0	U16	-	RO	-	-

Details of the dynamic Faults of the [Thermal management](#).

ParamSeriousError

Specific details of the [Parameters serious error](#).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x302D.00	4	4	U8	-	CST	-	-

Number of parameters in this group.

ParamSeriousWarnDynamic

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2106	0x302D.02	Desc	0	U16	-	RO	-	-

Details

of the dynamic Warnings of the [Parameters serious error](#).

ParamSeriousFaultRetentive

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2107	0x302D.03	Desc	0	U16	-	RO	-	-

Details of the retentive Faults of the [Parameters serious error](#).

ParamSeriousFaultDynamic

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2108	0x302D.04	Desc	0	U16	-	RO	-	-

Details of the dynamic Faults of the [Parameters serious error](#).

DigitalIoConfigError

Specific details of the [Digital IO configuration error](#).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x302E.00	4	4	U8	-	CST	-	-

Number of parameters in this group.

DigitalIoConfigWarnRetentive

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2110	0x302E.01	Desc	0	U16	-	RO	-	-

Details of the retentive Warnings of the [Digital IO configuration error](#).

DigitalIoConfigFaultRetentive

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2112	0x302E.03	Desc	0	U16	-	RO	-	-

Details of the retentive Faults of the [Digital IO configuration error](#).

DigitalIoConfigFaultDynamic

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2113	0x302E.04	Desc	0	U16	-	RO	-	-

Details of the dynamic Faults of the [Digital IO configuration error](#).

UserError

Specific details of the [User Fault](#).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x302F.00	4	4	U8	-	CST	-	-

Number of parameters in this group.

UserFaultDynamic

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2115	0x302F.04	Desc	0	U16	-	RW	-	-

Details of the dynamic Faults of the [User Fault](#).

LogicVoltageError

Specific details of the [Logic voltage error](#).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x3030.00	4	4	U8	-	CST	-	-

Number of parameters in this group.

LogicVoltageWarnRetentive

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2120	0x3030.01	Desc	0	U16	-	RO	-	-

Details of the retentive Warnings of the [Logic voltage error](#).

LogicVoltageWarnDynamic

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2121	0x3030.02	Desc	0	U16	-	RO	-	-

Details of the dynamic Warnings of the [Logic voltage error](#).

LogicVoltageFaultRetentive

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2122	0x3030.03	Desc	0	U16	-	RO	-	-

Details of the retentive Faults of the [Logic voltage error](#).

LogicVoltageFaultDynamic

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2123	0x3030.04	Desc	0	U16	-	RO	-	-

Details of the dynamic Faults of the [Logic voltage error](#).

FeedbackSensorError

Specific details of the [Feedback sensor error](#).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x3031.00	4	4	U8	-	CST	-	-

Number of parameters in this group.

FeedbackSensorWarnRetentive

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2125	0x3031.01	Desc	0	U16	-	RO	-	-

Details of the retentive Warnings of the [Feedback sensor error](#).

FeedbackSensorWarnDynamic

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2126	0x3031.02	Desc	0	U16	-	RO	-	-

Details of the dynamic Warnings of the [Feedback sensor error](#).

FeedbackSensorFaultRetentive

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2127	0x3031.03	Desc	0	U16	-	RO	-	-

Details of the retentive Faults of the [Feedback sensor error](#).

FeedbackSensorFaultDynamic

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2128	0x3031.04	Desc	0	U16	-	RO	-	-

Details of the dynamic Faults of the [Feedback sensor error](#).

STOError

Specific details of [/STO Management Error](#).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x3032.00	2	2	U8	-	CST	-	-

Number of parameters in this group.

STOFaultRetentive

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2132	0x3032.03	Desc	0	U16	-	RO	-	-

Retentive Faults details of the [/STO Management Error](#).

STOFaultDynamic

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2133	0x3032.04	Desc	0	U16	-	RO	-	-

Dynamic Faults details of the [/STO Management Error](#).

InternalError

Specific details of [Internal Error](#).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x303F.00	2	2	U8	-	CST	-	-

Number of parameters in this group.

InternalErrorFaultRetentive

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2192	0x303F.03	Desc	0	U16	-	RO	-	-

Details of the retentive Faults of the [Internal Error](#)

InternalErrorFaultDynamic

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2193	0x303F.04	Desc	0	U16	-	RO	-	-

Details of the dynamic Faults of the [Internal Error](#)

27.14. CiA402 state machine (2400-2449)**Controlword**

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2400	0x6040.00	Desc	-	U16	-	RW	YES	-

Parameter to manage the CiA402 State Machine and the specific commands offered by the operating modes. For further details see what is reported in [Section 8.5, CiA402 state machine](#). The bits are divided in this way:

- *Bit 0 - 3 and 7* to command each [Transition](#) of the CiA402 state machine.
- *Bit 8*: bits to manage the command of *Halt*.
- *Bit 4 - 6*: bits to request specific commands that can vary depending on the value of [ModesOfOperationDisplay](#).
- *Bit 9 - 15*: bits not used.

For further details see what is reported in [Section 8.5, CiA402 state machine](#).

Statusword

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2401	0x6041.00	Desc	-	U16	-	RO	YES	-

State of the CiA402 State Machine and of the specific commands of the operative modes. For further details see what is reported in [Section 8.5, CiA402 state machine](#). In the following chart you can find the encoding of the status of the Statusword. The bits shown with 'x' are not important to determine the status.

Statusword	Name	Description
xxxx xxxx x0xx 0000	<i>Not Ready to Switch On</i>	Initializing
xxxx xxxx x1xx 0000	<i>Switch On Disabled</i>	Idle
xxxx xxxx x01x 0001	<i>Ready to Switch On</i>	Preparation to enabling
xxxx xxxx x01x 0011	<i>Switched On</i>	The drive can be enabled or disabled, depending on the SwitchedOnOptionCode parameter value.
xxxx xxxx x01x 0111	Operation enable	Drive enabled and possibility to command the motor motion
xxxx xxxx x00x 0111	<i>Quick Stop Active</i>	Running a command of <i>Quick stop</i>
xxxx xxxx x0xx 1111	<i>Fault Reaction Active</i>	Reaction to a Fault situation. The drive can be enabled or not, depending on the situation before the error occurred
xxxx xxxx x0xx 1000	<i>Fault</i>	Fault state, finished reaction

QuickStopConfiguration

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2402	0x605A.00	Desc	6	S16	-	RW	-	ES

Action run after a *Quick Stop* command.

QuickStop-Configuration	Action
-1	The motor is stopped with maximum deceleration by resetting RequestedSpeed and then the drive reaches the <i>Switch On Disabled</i> state.
1	The motor is stopped with deceleration equal to ProfileDeceleration and later the drive enters the <i>Switch On Disabled</i> state.
2	The motor is stopped with deceleration equal to QuickStopDeceleration and later the drive enters the <i>Switch On Disabled</i> state.
5	The motor is stopped with deceleration equal to ProfileDeceleration and the drive remains in the <i>Quick Stop Active</i> state.
6	The motor is stopped with deceleration equal to QuickStopDeceleration and the drive remains in the <i>Quick Stop Active</i> state.

SwitchedOnOptionCode

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2410	0x42E0.00	Desc	0	S16	-	RW	-	ES

Value that determines the CiA402 state machine behaviour when it's in the *Switched On* state (see [Section 8.5, “CiA402 state machine”](#)).

SwitchedOnOptionCode	Action
0	torque not present in the motor if the drive is in the <i>Switched On</i> state.
1	torque present in the motor if the drive is in the <i>Switched On</i> state.

27.15. System manager (2450-2499)

SysMngCommand

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2450	0x5FF7.01	Desc	0	U16	-	RW	-	-

Command of the [System Manager](#) requested to the drive.

SysMngCommand	Description
0	No command
100	End tuning command
600	End download parameters file
601	End export parameters file
620	End digital I/O setup
1001	Tuning: extended inertia estimator (requires the writing of ResetWatchdogTimeout)
1002	Tuning: inertia estimator (requires the writing of ResetWatchdogTimeout)
1003	Tuning: RL estimator (requires the writing of ResetWatchdogTimeout)
1010	Function Generator current D (requires the writing of ResetWatchdogTimeout)
1015	Function Generator current Q (requires the writing of ResetWatchdogTimeout)
1020	Function Generator velocity (requires the writing of ResetWatchdogTimeout)
1030	Function Generator position (requires the writing of ResetWatchdogTimeout)
1040	Function Generator profile velocity (requires the writing of ResetWatchdogTimeout)
1050	Function Generator profile position (requires the writing of ResetWatchdogTimeout)
1101	Set all loops, tuning and estimated parameters at default
1102	Parameter recalculation of all loops
1103	Parameter recalculation of motion loops
1110	Parameter recalculation of CurrentLoop
1120	Parameter recalculation of speed loop
1130	Parameter recalculation of position loop
1140	Parameter recalculation of flux weakening loop
2001	Permanent memory: save all parameters
2200	Permanent memory: restore to default of all parameters (permanent)
2201	Reset to default of all parameters (temporary)

SysMngCommand	Description
2250	Permanent memory: delete motor and sensor data
2300	Permanent memory: reload value of all parameters
2301	Permanent memory: reload value of loops parameters and tuning configuration
5000	Hard firmware reset
5001	Soft firmware reset
5100	Request download firmware
5300	Phasing of feedback position sensor
5310	Test phasing of feedback position sensor
5320	Save phasing of feedback position sensor
5400	Update ESI eeprom
6000	Downloading parameters file
6001	Export parameters file
6200	Setup digital I/O
7200	Start Analog input 0 offset calibration
7201	Start Analog input 0 gain calibration
8000	Request download PLC program
8100	Request erase PLC program
8200	Request upload PLC program

SysMngStatus

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2451	0x5FF7.02	Desc	-	U16	-	RO	-	-

Status of the [System Manager](#).

SysMngStatus	Description
5400	Comparing of the EEPROM data with the expected ones
5401	EEPROM data writing in progress
5402	EEPROM data verification in progress
5403	Procedure closing phase
5404	The procedure is finished with an error
5405	The procedure is correctly finished (eeprom updated with new values)
5406	The procedure is correctly finished (eeprom verified, no data updated)

NOTE

The reported codes are valid only for the EtherCAT drives.

SysMngError

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2452	0x5FF7.03	Desc	0	U16	-	RO	-	-

Error of the last command of the [System Manager](#), requested to the drive.

SysMngError	Message	Solution
0	No error	-
1	Unrecognized command	Check that the value that's written in the SysMngCommand parameter is present in the table that describes it. If the value is present and the error remains, update the firmware to the latest available version.
2	Test function are active	Please contact Bonfiglioli.
3	Test enabling key is required	The command cannot be executed by the user.
4	Enabling key is required	The command cannot be executed by the user.
5	Safety condition not satisfied: drive is enabled	Disable the drive before to give the command.
6	Generic time out	The command has taken more than the expected time. Repeat the command and check that's correctly executed.
7	No active command to stop	There are not active commands to stop. it requires the command interruption only if it is in progress.
9	Safety condition not satisfied: one or more digital outputs are active	Disable the digital outputs and try again.
10	Safety condition not satisfied: one or more digital outputs are not configured as Generic Output	Configure all the digital outputs as Generic Output (I/O X - Out X) .
11	Safety condition not satisfied: capture units are active	Stop the capture peripherals.
12	Generic error during upload/download	Check the connection status and repeat the command.
13	Dynamic memory is busy	Stop the oscilloscope and try again.
1000	User has stopped the command	It has been required the interruption of the last command in progress. If the end of the command is not desired, check that the drive is not commanded by other master devices.
1001	Command watch dog is expired	Check if the connection is active and the Reset-WatchdogTimeout parameter writing timing requiring.
1002	Switched on state has been required	If the Transition of the CiA402 State Machine is not desired, check that the drive is not commanded by other master devices (see Section 8.5, "CiA402 state machine").
1003	Position limits are reached	Disengage the limit switch and repeat the command. Be sure that the required mechanical movement doesn't engage the limit switch.
1004	Quick stop has been required	If the Transition of the CiA402 State Machine is not desired, check that the drive is not commanded by other master devices (see Section 8.5, "CiA402 state machine").
1005	Halt has been required	If the Transition of the CiA402 State Machine is not desired, check that the drive is not commanded by other master devices (see Section 8.5, "CiA402 state machine").
1006	Disable has been required	If the Transition of the CiA402 State Machine is not desired, check that the drive is not commanded by other master devices (see Section 8.5, "CiA402 state machine").

SysMngError	Message	Solution
1007	Drive is in Fault state	Verify the cause that has generated the Fault and, once it's solved, give a Reset command, see Table 8.13 .
1008	Unknown transition has been required	If the Transition of the CiA402 State Machine is not desired, check that the drive is not commanded by other master devices (see Section 8.5 , " CiA402 state machine ").
1009	Estimator torque is out of range	EstimatorTorque must be lower than ActualTorqueLimitP .
1010	Estimator speed is out of range	InertiaEstimatorVelocity must be lower than MaxMotorSpeed .
1011	Motor shaft is blocked	The applied load blocks the motor movement; check the mechanical.
1012	Servo mode is not active	Internal error, repeat the command or reset the drive (Hard reset).
1013	Tuning mode is not achievable	Internal error, repeat the command or reset the drive (Hard reset). Check if the drive is not piloted by other master devices.
1014	Motion is enable	The drive is in Operation enable ; take the drive to the Switched On state.
1015	Motor and feedback sensor are not aligned	With incremental encoder, turn the motor for at least a half mechanical revolution.
1016	Estimated inertia is lower than motor inertia	Load with low inertia moment; try again to confirm the estimation.
1017	Estimate inertia is too high: bandwidth is limited	The inertia moment of the mechanical load doesn't allow to obtain a high VelocityLoopEstimatedBandwidth ; try again to confirm the estimation.
1018	Estimated inertia limit reached	Inertia moment too large to be estimated. Retry to confirm the estimation; if the estimation is reliable, verify the good functioning of the mechanical. If the performances are not satisfactory, it's necessary to increase the motor size.
1019	Motor Parameters are not correctly set	Check the Warnings.
1020	Feedback position sensor is not set	Check the Warnings.
1021	Estimator security position limit reached	Decrease the value of InertiaEstimatorVelocity or increase the value of EstimatorTorque and retry. if the problem persists, try to execute a not extended estimation of the inertia moment (command 1002 in the place of command 1001 of the SysMngCommand). Check the mechanical parts work properly. If the problem persists, the estimator cannot be used, then try with what's described in Section 20.4 , Gains calculation .
1022	Estimator torque greater than nominal current	Reduce EstimatorTorque .
1023	Estimator speed is too low: InertiaEstimatorVelocity is lower than 15rad/s.	Increase the value of InertiaEstimatorVelocity .
1024	Requested estimator speed is not reached	Retry the estimation; Try to execute a not extended estimation of the inertia moment (command 1002 in the place of command 1001 of the SysMngCommand).
1025	I2T Warning threshold reached	Increase I2TWarningThreshold .

SysMngError	Message	Solution
1026	DC bus voltage (+HV) is too low	Increase the supply voltage DCBusVoltage(+HV) and retry.
2000	Permanent memory address is out of range	Restore the permanent memory through the command 2200 (SysMngCommand). Reset the drive through the command 5000.
2001	Permanent memory data length is not valid	Restore the permanent memory through the command 2200 (SysMngCommand). Reset the drive through the command 5000.
2002	Message: "Dati non salvabili perché ADC di corrente non sono calibrati"	Please contact Bonfiglioli.
2003	Message: "Dati non salvabili perché ADC di tensione non sono calibrati"	Please contact Bonfiglioli.
2004	Last permanent memory writing was not completed correctly. Permanent memory data may be corrupted	Restore the permanent memory through the command 2200 (SysMngCommand). Reset the drive through the command 5000.
2005	Message: "Dati non salvabili perche' la calibrazione dell'Analog Input 0 non e' completa"	Completely execute the analog input calibration (see Section 17.2, Calibration).
2100	No error for file system	-
2101	File system ID not exist	Restore the permanent memory through the command 2200 (SysMngCommand). Reset the drive through the command 5000. If the problem persists, please contact Bonfiglioli.
2102	File system ID not present in permanent memory	
2103	File system data length mismatch	
2104	File system CRC is invalid	
2105	File system command is refused by I2C driver	
2106	File system dynamic memory is busy	
2107	File system dimension limit reached	
2108	File system ID is zero	
2109	File system data length is zero	
2110	File system operation not exist	
2200	No error for I2C driver	
2201	I2C driver is busy	
2202	I2C time out in reading	
2203	I2C time out in writing	
2204	I2C driver bus error	
2205	I2C driver has detected an odd permanent memory address	
2300	Hiperface internal memory: no error	-
2301	Hiperface internal memory: driver is busy	Turn the drive off and then on again. If the problem persists, please contact Bonfiglioli.
2302	Hiperface internal memory: operation not exist	Turn the drive off and then on again. If the problem persists, please contact Bonfiglioli.
2303	Hiperface internal memory: data size is too large	Turn the drive off and then on again. If the problem persists, please contact Bonfiglioli.
2304	Hiperface internal memory: for details, see Feedback sensor error	Check Feedback sensor error .
2305	Hiperface internal memory: dynamic memory is busy	Stop the oscilloscope and try again. Turn the drive off and then on again. If the problem persists, please contact Bonfiglioli.
2306	Hiperface internal memory: CRC is invalid	Check the wirings of the feedback sensor and that the FeedbackSensorTemperature is correct-

SysM- ngError	Message	Solution
		ly read. Turn the drive off and then on again. Repeat the phasing and the saving.
5000	Module ID is not present in ID table	Turn the drive off and then on again. If the problem persists, please contact Bonfiglioli.
5101	Download: file corrupted	See the solution in FirmwareStatus (value 151).
5103	Download: file requires unsupported features	See the solution in FirmwareStatus (value 153).
5104	Download: file requires unsupported features	See the solution in FirmwareStatus (value 154).
5105	Download: file requires unsupported features	See the solution in FirmwareStatus (value 155).
5106	Download: file requires unsupported features	See the solution in FirmwareStatus (value 156).
5107	Download: file requires unsupported features	See the solution in FirmwareStatus (value 157).
5108	Download: file requires unsupported features	See the solution in FirmwareStatus (value 158).
5111	Download: file corrupted	See the solution in FirmwareStatus (value 161).
5112	Download: file corrupted	See the solution in FirmwareStatus (value 162).
5113	Download: file corrupted	See the solution in FirmwareStatus (value 163).
5114	Download: file corrupted	See the solution in FirmwareStatus (value 164).
5115	Download: file corrupted	See the solution in FirmwareStatus (value 165).
5116	Download: file requires unsupported features	See the solution in FirmwareStatus (value 166).
5117	Download: file requires unsupported features	See the solution in FirmwareStatus (value 167).
5118	Download: file requires unsupported features	See the solution in FirmwareStatus (value 168).
5119	Download: file requires unsupported features	See the solution in FirmwareStatus (value 169).
5120	Download: file requires unsupported features	See the solution in FirmwareStatus (value 170).
5121	Download: file requires unsupported features	See the solution in FirmwareStatus (value 171).
5122	Download: memory error	See the solution in FirmwareStatus (value 172).
5123	Download: file corrupted	See the solution in FirmwareStatus (value 173).
5124	Download: file corrupted	See the solution in FirmwareStatus (value 174).
5125	Download: memory error	See the solution in FirmwareStatus (value 175).
5150	Download: memory error	See the solution in FirmwareStatus (value 200).
5151	Download: memory error	See the solution in FirmwareStatus (value 201).
5152	Download: memory error	See the solution in FirmwareStatus (value 202).
5153	Download: memory error	See the solution in FirmwareStatus (value 203).
5154	Download: memory error	See the solution in FirmwareStatus (value 204).
5160	Download: memory error	See the solution in FirmwareStatus (value 210).
5161	Download: memory error	See the solution in FirmwareStatus (value 211).
5162	Download: memory error	See the solution in FirmwareStatus (value 212).
5163	Download: memory error	See the solution in FirmwareStatus (value 213).
5164	Download: memory error	See the solution in FirmwareStatus (value 214).
5170	Download: memory error	See the solution in FirmwareStatus (value 220).
5171	Download: memory error	See the solution in FirmwareStatus (value 221).
5180	Download: memory error	See the solution in FirmwareStatus (value 230).
5300	Feedback position sensor is not compatible with command required.	It's not necessary to execute the required command.
5301	Feedback position sensor is not phased: angle error is out of range.	Turn the drive off and then on again.

SysMngError	Message	Solution
5302	Read/Write error of the internal memory of feedback position sensor.	Check the wirings of the feedback sensor and that the FeedbackSensorTemperature is correctly read.
5400	Update ESI eeprom: the EtherCAT master does not allow access to the ESI eeprom ^a	Check that the master is connected to the EtherCAT port, repeat the procedure according to the operation sequence. If the error persists, please contact Bonfiglioli.
5401	Update ESI eeprom: procedure internal error ^a	Turn the drive off and then on again, repeat the procedure according to the operation sequence. If the error persists, please contact Bonfiglioli.
5402	Update ESI eeprom: procedure in timeout ^a	Turn the drive off and then on again, repeat the procedure according to the operation sequence. If the error persists, please contact Bonfiglioli.
5403	Update ESI eeprom: error reading data ^a	Turn the drive off and then on again, repeat the procedure according to the operation sequence. If the error persists, please contact Bonfiglioli.
5404	Update ESI eeprom: error writing data ^a	Turn the drive off and then on again, repeat the procedure according to the operation sequence. If the error persists, please contact Bonfiglioli.
6200	Impossible to change the IO configuration because an IO overload Warning is active (Digital output overtemperature or overload)	Reset the Warning and try again.
7100	Message: "VGATE non presente (manca /STO o abilitazione software)"	Please contact Bonfiglioli.

^aThis error is valid only for EtherCAT drives.

SysMngEnForcing

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2455	0x5FF7.06	0 ÷ 1	0	U16	-	RW	-	-

It enables to force the [System manager safety conditions](#), for the next command of the [System Manager](#) requested to the drive (0 = disabled forcing, 1 = enabled forcing).

27.16. Capture peripherals (2800-2899)

⚠ NOTICE

In this section the parameters of both the capture interfaces are contained (selectable through the [CaptureInterfaceMode](#) parameter). When an interface has been selected, the parameters that are related to the other one are ignored and any try to access them returns a Warning. For further details see [Section 18.2, Configuration interface selection](#).

IMPORTANT

The parameters listed in this section are divided according to the interface to which they belong. Taking as reference the [CaptureInterfaceMode](#) parameter:

- the previous parameters are related to the CUSTOM interface
- The successive parameters are related to the [CiA-402](#) interface

CaptureParam_A

Parameters of capture peripheral (A).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4000.00	7	7	U8	-	CST	-	-

Number of parameters in this group.

CaptureUnitCommand_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2801	0x4000.01	0÷3	0	U16	-	RW	YES	-

Commands for the capture peripheral A.

UnitCommand	Description
0	<i>Stop</i> Disabling the capture peripheral.
1	<i>Single Run</i> Enabling the single capture. When the selected trigger event takes place (CaptureTriggerInput_A), the selected values of the quantities to capture (CaptureSource0_A , CaptureSource1_A , CaptureSource2_A) are copied in the parameters CapturedValue0_A , CapturedValue1_A , CapturedValue2_A . After the capture, CaptureUnitState_A goes from <i>Single capture armed</i> to <i>Single stop</i> . The capture results will remain valid until the next rearmament. Any further trigger events will be ignored by the capture peripheral.
2	<i>Repetitive Run</i> It enables the repeating capture. When the selected trigger event takes place (CaptureTriggerInput_A), the selected values of the quantities to capture (CaptureSource0_A , CaptureSource1_A , CaptureSource2_A) are copied in the parameters CapturedValue0_A , CapturedValue1_A , CapturedValue2_A . After the capture, CaptureUnitState_A goes from <i>Repetitive capture armed</i> to <i>Repetitive capture done</i> . A further trigger event will cause a new capture by overwriting the capture values of the previous event. When at least one of the parameters of the results are read, CaptureUnitState_A goes to <i>Repetitive capture armed</i> .
3	<i>Capture now</i> Enable the single capture and force the trigger. This mode is useful in debug phase to check that the configurations of the capture peripheral are correct, even if the physical source of the trigger is not available. The behaviour of the capture peripheral, in this case, is equal to that of the mode <i>Single Run</i> , with the only difference that the trigger event is simulated.

Table 27.6. Codes for UnitCommand

CaptureTriggerInput_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2802	0x4000.02	Desc	0	U16	-	RW	-	ES

Trigger signal that causes the capture for the peripheral A.

TriggerInput	Description
0	Digital input In9
1	Digital input In8

TriggerInput	Description
3	Index pulse of the feedback encoder
4	Index pulse of the master encoder

Table 27.7. *TriggerInput codes.*

CaptureTriggerEdge_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2803	0x4000.03	0 ÷ 2	0	U16	-	RW	-	ES

Trigger edge that causes the capture for the peripheral A.

TriggerEdge	Description
0	Falling edge
1	Rising edge
2	Both the edges

Table 27.8. *Codes for TriggerEdge.*

CaptureInhibitTime_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2804	0x4000.04	0-65500	0	U16	ms	RW	-	ES

Inhibition time of the capture for the peripheral A, after the trigger event, to avoid repeated captures, in case of not clean triggers. When the trigger event happens, the peripheral executes the capture and then ignore the trigger signal for the specified time.

In case of capture on both edges ([CaptureTriggerEdge_A](#) = 2), [CaptureInhibitTime_A](#) is applied "for edge". In case of repetitive capture ([CaptureUnitCommand_A](#) = 2), when a capture event happens, the capture is inhibited for the time that has been set in this parameter in relation to the specific capture edge. The other capture edge is not inhibited until it will not happen at least one time.

CaptureValidationFilterMode_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2809	0x4000.0A	0-1	0	U16	-	RW	-	ES

Filtering mode of the first quantity to capture for the peripheral A (0=symmetric, 1=asymmetric). In the symmetric mode the filtering value is expressed by the parameter [CaptureActiveSlopeValidationFilter_A](#) and it is the same for the edge carrying out the capture and for the restore edge. In the asymmetric mode, the filtering value applied to the capture edge is expressed by the parameter [CaptureActiveSlopeValidationFilter_A](#), while the filtering value applied to the restore edge is expressed by the parameter [CaptureRestoreSlopeValidationFilter_A](#). For further information on the working of this type of filter please see [Section 18.4, Filter on CaptureSource0_A and CaptureSource0_B](#).

CaptureRestoreSlopeValidationFilter_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2810	0x4000.09	-	0	U32	Desc	RW	-	ES

Enables the filter on the value of the first quantity of the peripheral A for the capture edge not enabled (restoring). This parameter is valid only if [CaptureValidationFilterMode_A](#) is equal to 1 (asymmetric mode). When different, it is ignored. The value shows the filtering entity and the unit of measurement is the same of the first quantity of the peripheral A. For further information please see [Section 18.4, Filter on CaptureSource0_A and CaptureSource0_B](#).

CaptureActiveSlopeValidationFilter_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2812	0x4000.08	-	0	U32	Desc	RW	-	ES

Enables the filter on the value of the first quantity of the peripheral A for the capture edge. If [CaptureValidationFilterMode_A](#) is equal to 0 (symmetric mode), the filtering expressed in this parameter is applied on the capture edge and on the restore edge, on the contrary the filtering expressed by this parameter is applied only to the capture edge; the filtering set by [CaptureRestoreSlopeValidationFilter_A](#) is applied to the restore edge.

CaptureState_A

Status of the capture peripheral (A).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4001.00	2	2	U8	-	CST	-	-

Number of parameters in this group.

CaptureUnitState_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2800	0x4001.01	-	0	U16	-	RO	YES	-

Status of the capture peripheral A.

UnitState	Description
0	<i>Capture stop</i> Capture peripheral in stop. The trigger source is ignored.
1	<i>Single capture armed</i> The capture peripheral is waiting for the trigger event to carry out the capture of type <i>Single Run</i> . When the trigger event takes place, the requested data will be stored and the capture peripheral will enter the <i>Single stop</i> state.
2	<i>Repetitive capture armed</i> The capture peripheral is waiting for the trigger event to carry out a capture of repetitive type. When the trigger event takes place, the requested data will be stored and the capture peripheral will enter the <i>Repetitive capture done</i> state.
3	<i>Single stop</i> The capture peripheral captured the selected data after the trigger event. After the captured data have been read, the peripheral can be disabled. The trigger source is ignored.
4	<i>Repetitive capture done</i>

UnitState	Description
	The peripheral captured the selected data after the trigger event, every new trigger event causes a new capture of the selected data and the overwriting of the previous values. This possibility is not notified in any way by the drive. When at least one of the results of the capture is read, the peripheral enters the status <i>Repetitive capture armed</i> .
19	<i>Single capture done on falling edge</i> The capture peripheral has captured the selected data after the trigger event. After the captured data have been read, the peripheral can be disabled. The trigger source is ignored.
35	<i>Single capture done on rising edge</i> The capture peripheral has captured the selected data after the trigger event. After the captured data have been read, the peripheral can be disabled. The trigger source is ignored.
51	<i>Single capture done on both edges</i> The capture peripheral has captured the selected data after the trigger event. After the captured data have been read, the peripheral can be disabled. The trigger source is ignored.
20	<i>Repetitive capture done on falling edge</i> The peripheral captured the selected data after the trigger event, every new trigger event causes a new capture of the selected data and the overwriting of the previous values. This possibility is not notified in any way by the drive. When at least one of the results of the capture is read, the peripheral enters the status <i>Repetitive capture armed</i> .
36	<i>Repetitive capture done on rising edge</i> The peripheral captured the selected data after the trigger event, every new trigger event causes a new capture of the selected data and the overwriting of the previous values. This possibility is not notified in any way by the drive. When at least one of the results of the capture is read, the peripheral enters the status <i>Repetitive capture armed</i> .

Table 27.9. Codes for UnitState.

NumberCapturesRecorded_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2814	0x4001.02	-	-	U16	-	RO	YES	-

Counter of the capture number of the capture peripheral A.

NumberCapturesRecordedRising_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2815	0x4001.03	-	-	U16	-	RO	YES	-

Counter of the events that have been captured on the rising edge of the capture peripheral A.

NumberCapturesRecordedFalling_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2816	0x4001.04	-	-	U16	-	RO	YES	-

Counter of the events that have been captured on the falling edge of the capture peripheral A.

CapturedValues_Rising_A

Captured value on the rising edge of the capture peripheral (A).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4007.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

CapturedValueRising0_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2820	0x4007.01	-	-	S32	-	RO	YES	-

32 bit value of the first variable of the capture peripheral A, captured on the rising edge.

CapturedValueRising1_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2822	0x4007.02	-	-	S32	-	RO	YES	-

32 bit value of the second variable of the capture peripheral A, captured on the rising edge.

CapturedValueRising2_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2824	0x4007.03	-	-	S32	-	RO	YES	-

32 bit value of the third variable of the capture peripheral A, captured on the rising edge.

CapturedValues_Falling_A

Captured value on the falling edge of the capture peripheral (A).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4008.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

CapturedValueFalling0_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2826	0x4008.01	-	-	S32	-	RO	YES	-

32 bit value of the first variable of the capture peripheral A, captured on the falling edge.

CapturedValueFalling1_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2828	0x4008.02	-	-	S32	-	RO	YES	-

32 bit value of the second variable of the capture peripheral A, captured on the falling edge.

CapturedValueFalling2_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2830	0x4008.03	-	-	S32	-	RO	YES	-

32 bit value of the third variable of the capture peripheral A, captured on the falling edge.

CaptureSources_A

Selection of the quantity to capture with the capture peripheral (A).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4003.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

CaptureSource0_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2835	0x4003.01	Desc	2	U16	-	RW	-	ES

Code of the first quantity to capture for the peripheral A.

CaptureX	Description
0	No quantity
1	AuxiliaryEncoderPosition
2	PositionActualValue
4	PositionFollowingError

Table 27.10. Codes of the quantities to capture.

CaptureSource1_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2836	0x4003.02	Desc	1	U16	-	RW	-	ES

Code of the second quantity to capture for the peripheral A. In [Table 27.10](#) you can find the available codes.

CaptureSource2_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2837	0x4003.03	Desc	0	U16	-	RW	-	ES

Code of the third quantity to capture for the peripheral A. In [Table 27.10](#) you can find the available codes.

CapturedValues_A

Capture peripheral (A) captured values, saved in memory locations of 1 Long size.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4004.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

CapturedValue0_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2840	0x4004.01	-	-	S32	-	RO	YES	-

Captured value of the first quantity for the peripheral A (4 bytes).

CapturedValue1_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2842	0x4004.02	-	-	S32	-	RO	YES	-

Captured value of the second quantity for the peripheral A (4 bytes).

CapturedValue2_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2844	0x4004.03	-	-	S32	-	RO	YES	-

Captured value of the third quantity for the peripheral A (4 bytes).

CapturedValues_Word_A

Capture peripheral (A) captured values, saved in memory locations of 1 Word size.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4005.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

CapturedValue0_Word_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4005.01	-	-	S16	-	RO	YES	-

Captured value of the first quantity for the peripheral A (2 bytes).

CapturedValue1_Word_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4005.02	-	-	S16	-	RO	YES	-

Captured value of the second quantity for the peripheral A (2 bytes).

CapturedValue2_Word_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4005.03	-	-	S16	-	RO	YES	-

Captured value of the third quantity for the peripheral A (2 bytes).

CapturedValues_Byte_A

Capture peripheral (A) captured values, saved in memory locations of 1 Byte size.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4006.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

CapturedValue0_Byte_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4006.01	-	-	S8	-	RO	YES	-

Captured value of the first quantity for the peripheral A (1 byte).

CapturedValue1_Byte_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4006.02	-	-	S8	-	RO	YES	-

Captured value of the second quantity for the peripheral A (1 byte).

CapturedValue2_Byte_A

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4006.03	-	-	S8	-	RO	YES	-

Captured value of the third quantity for the peripheral A (1 byte).

CaptureState_B

Capture peripheral (B) status.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4011.00	4	4	U8	-	CST	-	-

Number of parameters in this group.

CaptureUnitState_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2850	0x4011.01	-	0	U16	-	RO	YES	-

Status of the capture peripheral B. In [Table 27.9](#) you can find the available codes.

NumberCapturesRecorded_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2864	0x4011.02	-	-	U16	-	RO	YES	-

Counter of the capture number of the capture peripheral B.

NumberCapturesRecordedRising_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2865	0x4011.03	-	-	U16	-	RO	YES	-

Counter of the events that have been captured on the rising edge of the capture peripheral B.

NumberCapturesRecordedFalling_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2866	0x4011.04	-	-	U16	-	RO	YES	-

Counter of the events that have been captured on the falling edge of the capture peripheral B.

CaptureParam_B

Parameters of capture peripheral (B).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4010.00	7	7	U8	-	CST	-	-

Number of parameters in this group.

CaptureUnitCommand_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2851	0x4010.01	0÷3	0	U16	-	RW	YES	-

Commands for the capture peripheral B. In [Table 27.6](#) you can find the available codes.

CaptureTriggerInput_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2852	0x4010.02	Desc	0	U16	-	RW	-	ES

Trigger signal that causes the capture for the peripheral B. In [Table 27.7](#) you can find the available codes.

CaptureTriggerEdge_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2853	0x4010.03	0 ÷ 2	0	U16	-	RW	-	ES

Trigger edge that causes the capture for the peripheral B. In [Table 27.8](#) you can find the available codes.

CaptureInhibitTime_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2854	0x4010.04	0-65500	0	U16	ms	RW	-	ES

Inhibition time of the capture for the peripheral B, after the trigger event, to avoid repeated captures, in case of not clean triggers. When the trigger event happens, the peripheral executes the capture and then ignore the trigger signal for the specified time.

In case of capture on both edges ([CaptureTriggerEdge_B](#) = 2), [CaptureInhibitTime_B](#) is applied "for edge". In case of repetitive capture ([CaptureUnitCommand_B](#) = 2), when a capture event happens, the capture is inhibited for the time that has been set in this parameter in relation to the specific capture edge. The other capture edge is not inhibited until it will not happen at least one time.

CaptureValidationFilterMode_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2859	0x4010.0A	0-1	0	U16	-	RW	-	ES

Filtering mode of the first quantity to capture for the peripheral B (0=symmetric, 1=asymmetric). In the symmetric mode the filtering value is expressed by the parameter [CaptureActiveSlopeValidationFilter_B](#) and it is the same for the edge carrying out the capture and for the restore edge. In the asymmetric mode, the filtering value applied to the capture edge is expressed by the parameter [CaptureActiveSlopeValidationFilter_B](#), while the filtering value applied to the restore edge is expressed by the parameter [CaptureRestoreSlopeValidationFilter_B](#). For further information on the working of this type of filter please see [Section 18.4, Filter on CaptureSource0_A and CaptureSource0_B](#).

CaptureRestoreSlopeValidationFilter_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2860	0x4010.09	-	0	U32	Desc	RW	-	ES

Enabling the filter on the value of the first quantity of the peripheral B for the capture edge not enabled (restoring). This parameter is valid only if [CaptureValidationFilterMode_B](#) is equal to 1 (asymmetric mode). When different, it is ignored. The value shows the filtering entity and the unit of measurement is the same of the first quantity of the peripheral B. For further information please see [Section 18.4, Filter on CaptureSource0_A and CaptureSource0_B](#).

CaptureActiveSlopeValidationFilter_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2862	0x4010.08	-	0	U32	Desc	RW	-	ES

Enabling the filter on the value of the first quantity of the peripheral B for the capture edge. If [CaptureValidationFilterMode_B](#) is equal to 0 (symmetric mode), the filtering expressed in this parameter is applied on the capture edge and on the restore edge, on the contrary the filtering expressed by this parameter is applied only to the capture edge; the filtering set by [CaptureRestoreSlopeValidationFilter_B](#) is applied to the restore edge.

CapturedValues_Rising_B

Captured value on the rising edge of the capture peripheral (B).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4017.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

CapturedValueRising0_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2870	0x4017.01	-	-	S32	-	RO	YES	-

32 bit value of the variable 0 that has been captured on the rising edge of the capture peripheral B.

CapturedValueRising1_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2872	0x4017.02	-	-	S32	-	RO	YES	-

32 bit value of the variable 1 that has been captured on the rising edge of the capture peripheral B.

CapturedValueRising2_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2874	0x4017.03	-	-	S32	-	RO	YES	-

32 bit value of the variable 2 that has been captured on the rising edge of the capture peripheral B.

CapturedValues_Falling_B

Captured value on the falling edge of the capture peripheral (B).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4018.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

CapturedValueFalling0_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2876	0x4018.01	-	-	S32	-	RO	YES	-

32 bit value of the variable 0 that has been captured on the falling edge of the capture peripheral B.

CapturedValueFalling1_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2878	0x4018.02	-	-	S32	-	RO	YES	-

32 bit value of the variable 1 that has been captured on the falling edge of the capture peripheral B.

CapturedValueFalling2_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2880	0x4018.03	-	-	S32	-	RO	YES	-

32 bit value of the variable 2 that has been captured on the falling edge of the capture peripheral B.

CaptureSources_B

Selection of the quantity to capture with the capture peripheral (B).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4013.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

CaptureSource0_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2885	0x4013.01	Desc	2	U16	-	RW	-	ES

Code of the first quantity to capture for the peripheral B. In [Table 27.10](#) you can find the available codes.

CaptureSource1_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2886	0x4013.02	Desc	1	U16	-	RW	-	ES

Code of the second quantity to capture for the peripheral B. In [Table 27.10](#) you can find the available codes.

CaptureSource2_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2887	0x4013.03	Desc	0	U16	-	RW	-	ES

Code of the third quantity to capture for the peripheral B. In [Table 27.10](#) you can find the available codes.

CapturedValues_B

Capture peripheral (B) captured values, saved in memory locations of 1 Long size.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4014.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

CapturedValue0_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2890	0x4014.01	-	-	S32	-	RO	YES	-

Captured value of the first quantity for the peripheral B (4 bytes).

CapturedValue1_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2892	0x4014.02	-	-	S32	-	RO	YES	-

Captured value of the second quantity for the peripheral B (4 bytes).

CapturedValue2_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2894	0x4014.03	-	-	S32	-	RO	YES	-

Captured value of the third quantity for the peripheral B (4 bytes).

CapturedValues_Word_B

Capture peripheral (B) captured values, saved in memory locations of 1 Word size.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4015.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

CapturedValue0_Word_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4015.01	-	-	S16	-	RO	YES	-

Captured value of the first quantity for the peripheral B (2 bytes).

CapturedValue1_Word_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4015.02	-	-	S16	-	RO	YES	-

Captured value of the second quantity for the peripheral B (2 bytes).

CapturedValue2_Word_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4015.03	-	-	S16	-	RO	YES	-

Captured value of the third quantity for the peripheral B (2 bytes).

CapturedValues_Byte_B

Capture peripheral (B) captured values, saved in memory locations of 1 Byte size.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4016.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

CapturedValue0_Byte_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4016.01	-	-	S8	-	RO	YES	-

Captured value of the first quantity for the peripheral B (1 byte).

CapturedValue1_Byte_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4016.02	-	-	S8	-	RO	YES	-

Captured value of the second quantity for the peripheral B (1 byte).

CapturedValue2_Byte_B

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4016.03	-	-	S8	-	RO	YES	-

Captured value of the third quantity for the peripheral B (1 byte).

CaptureInterfaceMode

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2949	0x402F.00	0 ÷ 1	0	U16	-	RW	YES	ES

Switch to select the interface to be used to manage the capture peripherals A and B (0=custom mode, 1=CiA-402 mode). See [Section 18.2, "Configuration interface selection"](#)

IMPORTANT

It's not possible to change the interface if the capture functionality is active:
 - in case [CaptureInterfaceMode](#) value is 0 (CUSTOM interface): if at least one of the [CaptureUnitState_A](#) and [CaptureUnitState_B](#) parameters value is 1
 - in case [CaptureInterfaceMode](#) value is 1 (CiA-402 interface): if both the bits 0 and/or both the bits 8 of [TouchProbeFunction](#) and of [TouchProbeStatus](#) are set to 1.

TouchProbeFunction

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2950	0x60B8.00	Desc	0	U16	-	RW	YES	-

Settings of the capture peripherals A and B.

Bit	Description
0	0 = Capture peripheral A disable 1 = Capture peripheral A enable
1	0 = Single capture 1 = Repetitive capture
2	0 = Trigger on Digital Input A 1 = Trigger on Index pulse of the feedback encoder or PositionActualValue
3	Reserved
4	0 = Capture on rising edge of the capture peripheral A disable 1 = Capture on rising edge of the capture peripheral A enable
5	0 = Capture on falling edge of the capture peripheral A disable 1 = Capture on falling edge of the capture peripheral A enable
6, 7	At disposal of the user (e.g. for test)
8	0 = Capture peripheral B disable 1 = Capture peripheral B enable
9	0 = Single capture 1 = Repetitive capture
10	0 = Trigger on Digital Input B 1 = Trigger on Index pulse of the feedback encoder or PositionActualValue
11	Reserved

Bit	Description
12	0 = Capture on rising edge of the capture peripheral B disable 1 = Capture on rising edge of the capture peripheral B enable
13	0 = Capture on falling edge of the capture peripheral B disable 1 = Capture on falling edge of the capture peripheral B enable
14, 15	At disposal of the user (e.g. for test)

Table 27.11. Meaning of the bits related to the capture peripherals function.

TouchProbeStatus

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2951	0x60B9.00	-	-	U16	-	RO	YES	-

Status of the capture peripherals A and B.

Bit	Description
0	0 = Capture peripheral A disabled 1 = Capture peripheral A enabled
1	0 = No value captured on rising edge of the capture peripheral A 1 = Value captured on falling edge of the capture peripheral A
2	0 = No value captured on falling edge of the capture peripheral A 1 = Value captured on rising edge of the capture peripheral A
3 - 5	Reserved
6, 7	At disposal of the user (e.g. for test)
8	0 = Capture peripheral B disabled 1 = Capture peripheral B enabled
9	0 = No value captured on rising edge of the capture peripheral B 1 = Value captured on falling edge of the capture peripheral B
10	0 = No value captured on falling edge of the capture peripheral B 1 = Value captured on rising edge of the capture peripheral B
11 - 13	Reserved
14, 15	At disposal of the user (e.g. for test)

Table 27.12. Meaning of the bits related to the capture peripherals status.

TouchProbesSource

Selection of the capture source of the capture peripheral.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x60D0.00	2	2	U8	-	CST	-	-

Number of parameters in this group.

TouchProbe1Source

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2952	0x60D0.01	Desc	1	S16	-	RW	YES	-

Capture source of the capture peripheral A. The values that this parameter can take are reported in the following table.

Value	Trigger Event
-1	Master encoder Index pulse
1	Touch probe input 1 (Digital input In8)
2	Touch probe input 2 (Digital input In9)
5	Feedback encoder Index pulse

Table 27.13. Codes for the selection of the trigger event of the capture peripheral.

TouchProbe2Source

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2953	0x60D0.02	Desc	0	S16	-	RW	YES	-

Capture source of the capture peripheral B. The values that this parameter can take are reported in the [Table 27.13](#).

TouchProbePosition1PosValue

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2960	0x60BA.00	-	-	S32	-	RO	YES	-

32 bit value captured on the rising edge of the capture peripheral A.

TouchProbePosition1NegValue

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2962	0x60BB.00	-	-	S32	-	RO	YES	-

32 bit value captured on the falling edge of the capture peripheral A.

TouchProbePosition2PosValue

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2964	0x60BC.00	-	-	S32	-	RO	YES	-

32 bit value captured on the rising edge of the capture peripheral B.

TouchProbePosition2NegValue

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2966	0x60BD.00	-	-	S32	-	RO	YES	-

32 bit value captured on the falling edge of the capture peripheral B.

TouchProbe1PosEdgeCounter

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2980	0x60D5.00	-	-	U16	-	RO	YES	-

Counter of the number of the values that have been captured on the rising edge of the capture peripheral A.

TouchProbe1NegEdgeCounter

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2981	0x60D6.00	-	-	U16	-	RO	YES	-

Counter of the number of the values that have been captured on the falling edge of the capture peripheral A.

TouchProbe2PosEdgeCounter

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2982	0x60D7.00	-	-	U16	-	RO	YES	-

Counter of the number of the values that have been captured on the rising edge of the capture peripheral B.

TouchProbe2NegEdgeCounter

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
2983	0x60D8.00	-	-	U16	-	RO	YES	-

Counter of the number of the values that have been captured on the falling edge of the capture peripheral B.

27.17. Feedback sensor (3000-3999)

FeedbackSensor

Feedback sensor related values.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x36C0.00	5	5	U8	-	CST	-	-

Number of parameters in this group.

FeedbackSensorResolution

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
3000	0x36C0.02	-	8000	U32	Desc	RO	-	-

Feedback sensor resolution, valid only for the sensors that declare it. The unit of measurement depends on the motor type: rotary motor [count/rev], linear motor [count/PolePitch].

FeedbackSensorCode

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
3004	0x36C0.04	-	-	U16	-	Desc	-	EM

Code of the feedback sensor

This parameter is only for reading.

NOTE

If the value of this parameter is modified, then all the **Non-resettable parameters** reset.

SensorCode	Description
100	Absolute Hiperface encoder multiturn SEL37 16sin/rev, 4096rev.
101	Absolute Hiperface encoder multiturn SKM36 128sin/rev, 4096rev.
150	Absolute Hiperface encoder singleturn SEK37 16sin/rev.

NOTE

In the drives of the *iBMD* series with Hiperface encoders, the **Index** is simulated.

NOTE

The default value, once it has been modified, is no more restorable.

FeedbackSensorFaultTemperatureThrs

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
3005	0x36C0.05	-	-	U16	°C	RO	-	EM

Feedback sensor temperature Fault threshold. In case the FeedbackSensorFaultTemperatureThrs value is 65535, it means that the encoder overheating temperature alarm management is disabled. In this case the only monitoring that remains active is, therefore, the motor temperature one, that can be read through the **MotorTemperature** parameter, that protects even the sensor.

FeedbackSensorAbsMode

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
3010	0x36C0.08	-	-	S16	-	RW	-	EM

Absolute sensor functioning mode (0=incremental, 1=absolute). This parameter only makes sense if the physical sensor installed on the system is an absolute sensor (encoder hiperface mono or multi turn, resolver 2P=1, pure SinCos 2P=1). Since this parameter determines the mode to reconstruct the position, when it is written through the vocabulary, it will even be immediately and automatically saved in the permanent memory, so that even in case of NMT / SOFT reset (see [Section 21.8, Resetting](#)) there will be no undesired changes on the functioning mode.

NOTE

As for the [FeedbackSensorCode](#) parameter, the default value, once it has been modified, is no more restorable.

NOTE

If the value of this parameter is modified, then all the [Non-resettable parameters](#) reset.

FeedbackSensorPhasing

Feedback sensor phasing parameters related values.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x36C2.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

FeedbackSensorPhasingStatus

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
3020	0x36C2.01	-	-	U16	-	RO	-	-

Feedback sensor phasing status (0=not phased, 1=phasing in progress, 2=phased, 3=phasing error).

FeedbackSensorPhasingAngleTest

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
3021	0x36C2.02	0-3600	-	S16	10 = 1deg	RW	-	-

Value of the electric angle used to execute the phasing test through the command 5300 of the [SysMngCommand](#).

FeedbackSensorPhasingAngleError

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
3022	0x36C2.03	-	-	S16	10 = 1deg	RW	-	-

Error of the electric angle used to execute the phasing test through the command 5300 of the [SysMngCommand](#).

HallFeedbackSensor

Hall sensors features related values.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x3680.00	2	2	U8	-	CST	-	-

Number of parameters in this group.

HallValidationWindow

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
3066	0x3680.0E	-	-	S16	Count	RO	-	-

Accuracy of the Hall sensors of the feedback sensor, valid only for the sensors that declare it. If the sensor doesn't respect this accuracy, the *Phasing: Validation window not respected* warning is reported (see [Table 24.13](#)).

27.18. Motion (4000-4999)

PositionResolution

Number of increments related to a motor axis revolution (for further details see [Section 13.2, Revolution resolution](#)). This parameter is calculated as [EncoderIncrements](#) / [MotorRevolutions](#). The unit of measurement depends on the motor type: rotary motor [inc/rev], linear motor [inc/[PolePitch](#)].

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x608F.00	2	2	U8	-	CST	-	-

Number of parameters in this group.

EncoderIncrements

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4000	0x608F.01	256 - 1048576	8000	U32	Desc	RW	-	ES

Number of increments of the feedback position sensor, used to calculate the [PositionResolution](#).

NOTE

This parameter is part of the group [Non-resettable on the reset parameters](#).

MotorRevolutions

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4003	0x608F.02	1	1	U32	Desc	RW	-	-

Parameter that's necessary to calculate the [PositionResolution](#). For rotative motors, it indicates the motor revolutions number. For linear motors, it indicates the motor polar steps number. Actually, this parameter is set to 1, so the [PositionResolution](#) coincides with the value of [EncoderIncrements](#).

Polarity

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4002	0x607E.00	-	0	U8	-	RW	YES	ES

Motor axis rotation direction in which the position increments. For further details see [Section 13.3, Polarity](#).

Polarity	Name	Description
0	Forward	With rotary motor: positive direction clockwise towards the motor flange With linear motor: the positive direction is defined by the motor constructor, supposing the correct wiring of the motor phases.
192	Reverse	With rotary motor: positive direction counterclockwise towards the motor flange With linear motor: the positive direction is the opposite one than the direction defined by the motor constructor, supposing the correct wiring of the motor phases.

NOTE

This parameter is part of the group [Non-resettable on the reset parameters](#).

ModesOfOperation

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4100	0x6060.00	Desc	3	S8	-	RW	YES	ES

Selection of the operating mode of drive functioning. The accepted values are shown in the [Table 27.14](#).

Value	Name	Description
1	<i>Profile Position Mode</i>	The drive runs positionings with profile and set points configured by the user.
3	<i>Profile Velocity Mode (CiA402)</i>	The drive runs speed motions with profile and set point configured by the user.
4	<i>Torque Mode</i>	The drive runs a motion by following a torque reference configured by the user. Only the current regulation loop is used.
6	<i>Homing Mode</i>	The drive runs a homing procedure (zero searching) with profile configured by the user.
7	<i>Interpolated Position Mode</i>	The drive runs a motion by following a position set point periodically set by the user (positionings in Real-time).
8	<i>Cyclic Synchronous Position Mode</i>	The drive runs a motion by following a position set point periodically set by the user (positionings in Real-time).
9	<i>Cyclic Synchronous Velocity Mode</i>	The drive runs a motion by following a velocity set point periodically set by the user (positionings in Real-time).
10	<i>Cyclic Synchronous Torque Mode</i>	The drive runs a motion by following a torque set point periodically set by the user (positionings in Real-time).
-113	<i>Profile Velocity Mode (CUSTOM)</i>	The drive runs a parametrized motion as speed profile but internally checked by the drive even in its position.
-111	<i>Profile Velocity AI Mode</i>	The drive runs speed motions with profile configured by the user and set point set through the analog input.
-101	<i>Torque AI Mode</i>	The drive executes a movement because it's following a torque reference that's related to the analog input value. Only the current regulation loop is used.

Table 27.14. Accepted values for the ModesOfOperation parameter.

NOTE

It is possible to change **ModesOfOperation** only if the drive is not on Quick Stop Active or Fault Reaction Active state. If the drive is on **Operation enable** state, it's possible to change the operative mode only if the bit 4 of the **Controlword** is set to 0. The operative mode change, with this method, must be done with the motor stopped, and it's user's responsibility to be sure of this condition.

ModesOfOperationDisplay

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4101	0x6061.00	Desc	3	S8	-	RO	YES	-

Mode of operation active in the drive. The values that can be read are the same of the **ModesOfOperation** parameter (see [Table 27.14](#)) with, in addition, the *Tuning Mode* (-127) used for some tuning and configuration commands.

ApplyModeOperation

Group of parameter to manage the on-the-fly change of the operative mode.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x42C0.00	9	9	U8	-	CST	-	-

Number of parameters in this group.

ApplyModeOperationCommand

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4108	0x42C0.01	Desc	-	S8	-	RW	YES	-

Selection of the operating mode for the functionality of on-the-fly mode change.

ApplyModeOp- erationComand	Name
1	<i>Profile Position Mode</i>
6	<i>Homing Mode</i>
7	<i>Interpolated Position Mode</i>
-113	<i>Profile Velocity Mode (CUSTOM)</i>

NOTE

It is possible to change operative mode through this parameter only when the drive is in the **Operation enable** state. For further details see [Section 22.5, On-the-fly operative mode change](#).

ApplyModeOperationStatus

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4109	0x42C0.02	-	-	U8	-	RO	YES	-

Status of the on-the-fly mode change. The parameter shows if the change was carried out or not and it shows any possible error code.

ApplyModeOperationStatus	Description
0	No error, change ApplyModeOperationCommand correctly run.
1	Error: parameter ApplyModeOperationCommand not correct.
2	Error: parameter 1 of ApplyModeOperationParameters not correct.
3	Error: parameter 2 of ApplyModeOperationParameters not correct.
4	Error: parameter 3 of ApplyModeOperationParameters not correct.
5	Error: parameter 4 of ApplyModeOperationParameters not correct.
6	Error: parameter 5 of ApplyModeOperationParameters not correct.
7	Error: parameter 6 of ApplyModeOperationParameters not correct.
8	Error: parameter 7 of ApplyModeOperationParameters not correct.

ApplyModeOperationParameters

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4110 - 4122	0x42C0.03 - 0x42C0.09	-	-	U32	-	RW	YES	-

Group of 7 parameters through which it is possible to set the on-the-fly operating mode change. The meaning of every parameter changes when [ApplyModeOperationCommand](#) changes. For further details please see [Section 22.5, On-the-fly operative mode change](#).

PositionValidationStatus

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4150	0x42BF.00	-	-	U32	-	RW	-	-

System encoder position validation: it indicates if the position of the sensor, here after listed, is valid for the application. Each bit is related to an Encoder type and must be set (logic state 1) from the user if the procedures that are necessary to validate the position have been executed. With "validate" we mean that the position can be considered "aligned" with the value that is reported by the sensor (homing, position, ...) If for any motive (reset, turn off, polarity inversion, ...) the position is no more coherent, the corresponding bits automatically reset. The causes that reset the bit are:

Bit	Encoder	Cause
0	Feedback encoder	turn off, HardReset by SystemManager command (see SysMngCommand) EncoderIncrements or Polarity parameters value change
3	Selected auxiliary encoder	NMT reset , turn off, HardReset and SoftReset by SystemManager command (see SysMngCommand)
4	Real auxiliary encoder	NMT reset , turn off, HardReset and SoftReset by SystemManager command (see SysMngCommand)
5	Virtual auxiliary encoder	NMT reset , turn off, HardReset and SoftReset by SystemManager command (see SysMngCommand)

PositionActualValue

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4156	0x6064.00	-	-	S32	inc	RO	YES	-

Current drive position.

NOTICE

This parameter is part of the group **Non-resettable parameters**. If a firmware re-set happens, and the feedback sensor is not absolute, the actual position, read by the **PositionActualValue** parameter, is maintained only if the code that's returned by the **ResetCause** parameter is 5 or 6. If the feedback sensor is absolute the actual position is kept even if the drive is turned off (within the sensor functioning range).

FollowingErrorWindow

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4160	0x6065.00	-	Desc	U32	inc	RW	YES	ES

Positioning window (Fault threshold) to check the **Error of position tracking** (setting used only in the position modes). If **PositionFollowingError** remains over this threshold longer than **FollowingErrorTimeout**, the system signals the Fault of following error, if enabled. The default value is equal to 64 motor revolutions.

FollowingErrorWindowWarn

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4162	0x4282.01	-	Desc	U32	inc	RW	-	ES

Position window (Warning threshold) to check the **Error of position tracking** (setting used only in the position modes). If **PositionFollowingError** remains above this threshold longer than **FollowingErrorTimeout**, the system signals the Warning of following error. The default value is equal to 64 motor revolutions.

PositionFollowingError

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4164	0x60F4.00	-	-	S32	inc	RO	YES	-

Current value of the error of position following.

FollowingErrorTimeout

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4166	0x6066.00	-	0	U16	ms	RW	YES	ES

Maximum time period during which the absolute value of **PositionFollowingError** can get over the error windows (**FollowingErrorWindow** and **FollowingErrorWindowWarn**) before respectively a fault or a Warning is notified. Setting used only in the position modes.

PositionWindow

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4170	0x6067.00	-	0	U32	inc	RW	YES	ES

Tolerance window on the [Position reached target](#) (setting used only in the position modes). Once the [PositionActualValue](#) reached the window and remains inside it for a time period equal to at least [PositionWindowTime](#), the bit *Target reached* of the [Statusword](#) is set. Vice versa the same bit is immediately reset as soon as the difference between the two positions (target and current) gets over the window. If this parameter is set to 0, the position target is reached only if the theoretical value of the position (set point of the position loop) is equal to the position target for a time period at least equal to [PositionWindowTime](#).

PositionWindowTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4172	0x6068.00	-	10	U16	ms	RW	YES	ES

Minimum time period to check the reaching of the final position. Setting used only in the position modes.

VelocityActualValue

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4203	0x606C.00	-	-	S32	inc/s	RO	YES	-

Actual drive velocity, filtered by the Sensor filter (see [Figure 27.1](#)).

VelocityWindow

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4205	0x606D.00	-	0	U16	inc/s	RW	YES	ES

Tolerance window on the [Speed target reached](#) (setting used only in the speed modes). Once the [VelocityActualValue](#) reached the window and remains inside it for a time period equal to at least [VelocityWindowTime](#), the bit *Target reached* of the [Statusword](#) is set. Vice versa the same bit is immediately reset as soon as the difference between the two speeds (target and current) gets over the window. If this parameter is set to 0, the speed target is reached only if the theoretical value of the speed (set point of the speed loop) is equal to the speed target for a time period at least equal to [VelocityWindowTime](#).

VelocityThreshold

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4206	0x606F.00	-	0	U16	inc/s	RW	YES	ES

Speed threshold to recognize [Stopped motor](#) (setting used only in the speed modes). Once the [VelocityActualValue](#) is decreased with a lower value than the threshold and it stays in this for a time period at least equal to [VelocityThresholdTime](#), the bit *Speed* of the [Statusword](#) is set. Vice versa the same bit is immediately reset as soon as the current speed gets over the threshold. If this parameter is set to 0, the motor is considered as stopped only if

the theoretical value of the speed (set point of the speed loop) is equal to 0 for a time period at least equal to [VelocityThresholdTime](#).

VelocityWindowTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4208	0x606E.00	-	0	U16	ms	RW	YES	ES

Minimum time period to check the reaching of the final speed. Setting used only in the speed modes.

VelocityThresholdTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4209	0x6070.00	-	0	U16	ms	RW	YES	ES

Minimum time period to check the condition of the stopped motor. Setting used only in the speed modes.

TargetTorque

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4250	0x6071.00	-	0	S16	10 = 1%IS	RW	YES	-

Target torque the motor has to reach in *Torque Mode* or in *Cyclic Synchronous Torque Mode*.

MaxTorque

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4251	0x6072.00	0 ÷ 32767	1000	U16	10 = 1%IS	RW	YES	ES

Symmetrical limit of the torque reference [1000 = Rated current] set by the user. This value is taken as reference in case the [TorqueLimitSelector](#) parameter is set to 1.

ActualTorqueLimitP

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4252	0x420F.00	-	-	U16	10 = 1%IS	RO	YES	-

Actual torque positive limit [1000 = Rated current].

ActualTorque

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4253	0x6077.00	-	-	S16	10 = 1%IS	RO	YES	-

Applied torque value.

TorqueFilterFrequency

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4254	0x3321.01	-	80	U16	Hz	RW	-	ES

Typical filter frequency to obtain the [ActualFilteredTorque](#) parameter.

ActualFilteredTorque

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4255	0x4210.00	-	-	S16	10 = 1%IS	RO	YES	-

Filtered value of [ActualTorque](#). The filter is a [Low-pass filter of the first order](#) with typical frequency equal to [TorqueFilterFrequency](#).

RequestedTorque

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4256	0x6074.00	-	-	S16	10 = 1%IS	RO	YES	-

Value of the torque that's required to the motor.

ActualTorqueLimitN

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4257	0x4211.00	-	-	U16	10 = 1%IS	RO	YES	-

Actual torque negative limit [1000 = Rated current].

PositiveTorqueLimitValue

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4258	0x60E0.00	-	-	U16	10 = 1%IS	RW	YES	ES

Torque reference positive limit [1000 = Rated current].

NegativeTorqueLimitValue

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4259	0x60E1.00	-	-	U16	10 = 1%IS	RW	YES	ES

Torque reference negative limit [1000 = Rated current].

TorqueLimitSelector

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4270	0x4202.00	-	0	U16	-	RW	YES	ES

Selector that allows to select the source to obtain the torque limit.

TorqueLimitSelector	Description
0	Peak Current (the torque limit is always active and is equal to UserPeakCurrent)
1	Max/Positive/Negative (only for ETC version) Max Torque (only for CAN version) Torque limit is active at the MaxTorque value ^a

TorqueLimitSelector	Description
2	Torque limit enabled through analog input (see Section 17.3, Conversion)

^aIn this case the limit can be symmetrical by setting the [MaxTorque](#) parameter, or asymmetrical by setting the [PositiveTorqueLimitValue](#) and [NegativeTorqueLimitValue](#) values.

TorqueSlope

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4280	0x6087.00	0xFFFFFFFF	0xFFFFFFFF	U32	-	RW	YES	-

Torque increment per second in the torque profile ramps. This parameter is not used.

TorqueProfileType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4282	0x6088.00	-1	-1	S16	-	RO	YES	-

Torque profile type: -1=Torque step.

PositioningOptionCode

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4300	0x60F2.00	Desc	0	U16	-	RW	YES	ES

Necessary options to define the behaviour of the position operating modes. Only the bits related to the behaviour of the *Profile Position Mode* have been currently implemented:

- **Relative option (bit 0 - 1)**
Group of bits used to check the positioning behaviour when it is of relative type (the bit *Absolute / Relative* of the [Controlword](#) is equal to 1). The accepted values are:
0: the positioning is run in relation to the last position target (absolute internal).
1: the positioning is carried out in relation to the set-point of the position loop.
2: the positioning is carried out in relation to the [PositionActualValue](#).
- **Change immediately option (bit 2 - 3)**
Group of bits used to check the positioning behaviour when the bit *Change set immediately* of the [Controlword](#) is set as equal to 1. The only accepted value is 0 showing that the positioning carried out in this mode immediately readjusts the current motion to the new parameters of the position profile.
- **Request-response option (bit 4 - 5)**
Group of bits used to check the handshake between the drive and the master to start the positionings. The only accepted value is 0 showing that the supported handshake is the standard one, described in [Section 22.9, Profile Position Mode](#).

ProfilePositionStatus

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4319	0x42A0.00	0 - 6	-	U16	-	RO	YES	-

Status of the position trajectory generator.

ProfilePositionStatus	Description
0	The trajectory generator is disabled: ModesOfOperationDisplay is not <i>Profile Position Mode</i> or the drive is disabled.
1	The position profile is in the <i>stationary phase</i> : steady references. From this status on ModesOfOperationDisplay is always equal to <i>Profile Position Mode</i> , the drive is always in the status Operation enable and the trajectory generator is always enabled.
2	The position profile is in the <i>Deceleration phase for direction reversal</i> . This is the first phase carried out when the motor, already moving, has to reverse the motion. In this phase the deceleration used is always equal to ProfileDeceleration .
3	The position profile is in the <i>Acceleration phase</i> . This is the phase carried out when the trajectory generator must accelerate the motor (or decelerate depending on the set parameters) to reach the cruise speed ProfileVelocity .
4	The position profile is in the <i>Cruise phase</i> . This phase is carried out at a constant speed equal to ProfileVelocity .
5	The position profile is in the <i>Deceleration phase</i> . This phase is carried out when the trajectory generator must decelerate the motor in order to reach the speed EndVelocity .
6	The position profile is in the <i>Phase of profile end</i> . This phase is carried out at a constant speed equal to EndVelocity before stopping the positioning. When this phase is over the trajectory generator enters the status 1, <i>Stationary phase</i> .

TargetPosition

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4320	0x607A.00	-	0	S32	inc	RW	YES	-

Target position that must be reached at the end of a positioning carried out in *Profile Position Mode* or in *Cyclic Synchronous Position Mode*. In *Cyclic Synchronous Position Mode* the value is always read as absolute; in *Profile Position Mode* the value is read as absolute or relative depending on the *Absolute / Relative* bit of the [Controlword](#). If the positioning is of absolute type the TargetPosition is understood as a position related to the [Zero position](#), vice versa if the positioning is of relative type the TargetPosition is understood as shown in the bits *Relative option* of the parameter [PositioningOptionCode](#).

NOTE

If in *Profile Position Mode*, in the parametrisation of a positioning, the TargetPosition value even include the space to be travelled with speed equal to [EndVelocity](#) at the end of the profile, that is [EndIncrements](#). However if this last value is higher than TargetPosition the motion is carried out with speed equal to [EndVelocity](#) and the content of the parameter [EndIncrements](#) is ignored.

EndIncrements

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4322	0x4284.01	-	0	U32	inc	RW	YES	ES

Space to cover with speed equal to [EndVelocity](#) at the end of the deceleration ramp of a position profile. If the value of [EndVelocity](#) is 0 the value of EndIncrements is ignored and the positioning ends after the deceleration ramp.

HomeOffset

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4324	0x607C.00	-	0	S32	inc	RW	YES	ES

Difference between [Zero position](#) and [Home position](#). Please see [Section 22.19, Homing Mode](#).

NOTE

If the sensor is absolute then the value of [HomeOffset](#) must be between 0 and the negative full scale value (for example in a drive that has a single turn absolute encoder of 4096 imp/rev, [HomeOffset](#) must be between 0 and $-(1*4096)$).

PositionLimitEnable

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4326	0x4280.01	0 - 1	0	U16	-	RW	-	ES

Parameter used to enable/disable the software position limits. See [Section 19.6, Limits of software position](#).

SoftwarePositionLimit

Software position limits, for details see [Section 19.6, Limits of software position](#).

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x607D.00	2	2	U8	-	CST	-	-

Number of parameters in this group.

PositionLimitNegative

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4327	0x607D.01	-	-2147483648	S32	inc	RW	YES	ES

Negative software position limit.

PositionLimitPositive

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4329	0x607D.02	-	2147483647	S32	inc	RW	YES	ES

Positive software position limit.

MaxProfileVelocity

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4331	0x607F.00	Desc	Desc	U32	inc/s	RW	YES	ES

Maximum speed of the trajectory generators. Its default value is 100% of [MotorRatedSpeed](#) while the maximum settable value is 3216.9 rad/s.

MaxMotorSpeed

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4333	0x6080.00	-	Desc	U32	Desc	RW	YES	ES

Motor velocity limit value. The default value is equal to the 120% of [MotorRatedSpeed](#). The unit of measurement depends on the motor type: rotary motor [rpm], linear motor [mm/s].

ProfileVelocity

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4335	0x6081.00	Desc	Desc	U32	inc/s	RW	YES	ES

Running speed of the position profile. At the end of the acceleration ramp the motor reaches this speed which is kept until the beginning of the deceleration ramp. If the value of ProfileVelocity is lower than [StartVelocity](#) or [EndVelocity](#), its value is internally set with the higher between the two. The default value and the adjustable maximum value are respectively 3.0 rad/s and 3216.9 rad/s. It cannot be set with a zero value.

EndVelocity

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4337	0x6082.00	Desc	0	U32	inc/s	RW	YES	ES

Speed which the motor has to reach at the end of the profile deceleration ramp. The maximum settable value is 3216.9 rad/s.

ProfileAcceleration

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4339	0x6083.00	Desc	Desc	U32	inc/s	RW	YES	ES

Value of the profile acceleration ramp. The default value is 125.0 rad/s² while the range of accepted values goes from 0.32 to 205887.3 rad/s².

ProfileDeceleration

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4341	0x6084.00	Desc	Desc	U32	inc/s ²	RW	YES	ES

Profile deceleration ramp value. The default value is 125.0 rad/s² while the range of the accepted values goes from 0.32 to 205887.3 rad/s².

QuickStopDeceleration

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4343	0x6085.00	Desc	Desc	U32	inc/s ²	RW	YES	ES

Quick stop ramp deceleration value. This deceleration is used in the following cases:

- the drive is in the status **Operation enable** with parameter **QuickStopConfiguration** equal to 2 or 6 and gets a command of *Quick Stop*.
- The drive is in the status **Operation enable**, is carrying out a motion and it reaches or gets over a position limit (hardware or software).

The default value is equal to the parameter **MaxDeceleration** while the range of admitted value goes from 0.32 to 205887.3 rad/s².

MotionProfileType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4345	0x6086.00	0	0	S16	-	RW	YES	ES

Type of acceleration and deceleration ramps used to create the profile. It is currently possible to use only linear ramps (trapeze profile).

StartVelocity

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4347	0x4244.00	Desc	0	U32	inc/s	RW	YES	ES

Motor speed at the beginning of the profile. The maximum settable value is 3216.9 rad/s.

HomingMethod

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4500	0x6098.00	Desc	35	S8	-	RW	YES	ES

Method used to start the homing procedure. For further details please see [Section 22.19, Homing Mode](#).

 **WARNING**

If the **Polarity** is of Reverse type, then the roles of **Positive limit switch (FC +)** and **Negative limit switch (FC -)** are reversed: **Positive limit switch (FC +)** behaves like **Negative limit switch (FC -)** and **Negative limit switch (FC -)** behaves like **Positive limit switch (FC +)**. This is true both in the text of this manual and in the MotionDrive.

 **WARNING**

If a **HomingMethod** (see also [Table 22.3](#)) with mechanical stop is selected (e.g. mode -1), remember to set the torque limit (see [Section 19.3, Torque limit](#)).

Value	Procedure description
1	FC- sw, Index pulse
2	FC+ sw, Index pulse
7	Home sw, dir +, Index before rise edge, Fc+ reverse
8	Home sw, dir +, Index after rise edge, Fc+ reverse
9	Home sw, dir +, Index before fall edge, Fc+ reverse
10	Home sw, dir +, Index after fall edge, Fc+ reverse
11	Home sw, dir -, Index before rise edge, Fc+ reverse
12	Home sw, dir -, Index after rise edge, Fc+ reverse

Value	Procedure description
13	Home sw, dir -, Index before fall edge, Fc+ reverse
14	Home sw, dir -, Index after fall edge, Fc+ reverse
17	FC- sw, no Index
18	FC+ sw, no Index
23	Home sw, dir +, rise edge, no Index, Fc+ reverse
26	Home sw, dir +, fall edge, no Index, Fc+ reverse
27	Home sw, dir -, rise edge, no Index, Fc+ reverse
30	Home sw, dir -, fall edge, no Index, Fc+ reverse
35	Current position
-1	Mechanical stop, dir -, Index pulse
-2	Mechanical stop, dir +, Index pulse
-7	Home sw, dir +, Index before rise edge, Fc+ stop
-8	Home sw, dir +, Index after rise edge, Fc+ stop
-9	Home sw, dir +, Index before fall edge, Fc+ stop
-10	Home sw, dir +, Index after fall edge, Fc+ stop
-11	Home sw, dir -, Index before rise edge, Fc- stop
-12	Home sw, dir -, Index after rise edge, Fc- stop
-13	Home sw, dir -, Index before fall edge, Fc- stop
-14	Home sw, dir -, Index after fall edge, Fc- stop
-17	Mechanical stop, dir -, no Index
-18	Mechanical stop, dir +, no Index
-23	Home sw, dir +, rise edge, no Index, Fc+ stop
-26	Home sw, dir +, fall edge, no Index, Fc+ stop
-27	Home sw, dir -, rise edge, no Index, Fc- stop
-30	Home sw, dir -, fall edge, no Index, Fc- stop
-35	Current RequestedPosition

IndexPulseDeadZone

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4501	0x4285.02	Desc	Desc	U32	inc	RW	-	ES

Position offset where the drive, after detecting the disengagement of the Home switch or of the limit switch (depending on the chosen method), does not control the Index pulse of the feedback sensor. It represents the measurement of the dead zone after which the drive starts looking for the Index pulse. The resolution of IndexPulseDeadZone is 1° rounded off, the range goes from 0° to 180° and the default value is 1°.

HomingSpeeds

Speeds used in the *Homing Mode*.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x6099.00	2	2	U8	-	CST	-	-

Number of parameters in this group.

SpeedForSwitch

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4504	0x6099.01	Desc	Desc	U32	inc/s	RW	YES	ES

Speed used during the search phase of the [Home](#) switch or of the limit switch (depending on the chosen method), in the homing procedure. The default value and the maximum settable value are respectively 1.5 rad/s and 3216.9 rad/s. It cannot be set with a zero value.

SpeedForZero

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4506	0x6099.02	Desc	Desc	U32	inc/s	RW	YES	ES

Speed used during the search phase of the [Home position](#). The default value and the maximum settable value are respectively 0.4 rad/s and 3216.9 rad/s. It cannot be set with a zero value.

HomingAcceleration

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4510	0x609A.00	Desc	Desc	U32	inc/s ²	RW	YES	ES

Value of the accelerations and decelerations used during the homing procedures. The default value is 15.0 rad/s² while the range of the accepted values goes from 0.32 to 205887.3 rad/s².

HomingPosDisengagement

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4512	0x4285.03	Desc.	Desc.	U32	inc	RW	-	ES

Minimum disengagement space used in the mechanical stop [HomingMethod](#) without the [Index](#) pulse searching, described on [Table 22.3](#) (after the reaching of the mechanical stop, the drive reverses its direction and distances the motor from the mechanical stop of at least of the number of pulses that are written in this parameter). The value of this parameter depends on the feedback sensor resolution and can take the values from 0 to a maximum of 2048*resolution/revolution and by default it's 1/8 of the feedback sensor resolution. For example, if the feedback sensor is 8000 pul/rev then HomingPosDisengagement=2048*8000=16384000 with default=1/8*8000=1000.

HomingAbsRangeMode

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4514	0x4285.04	Desc.	Desc.	U16	inc	RW	-	ES

Selector of the allowed positions range, with absolute encoder (0=from 0 to encoder range, 1=from -1/2 range to +1/2 range). It has to be defined if the homing has to be executed with “zero at centre” or “zero at side”. At the end of the homing procedure the drive, that has an

absolute encoder (**FeedbackSensorAbsMode** = 1), will save the data so that the position can be reconstructed even if the drive is turned off and on again (provided that the axis position is within the range that has been defined for the homing, range that has been defined with this parameter).

HomingStatus

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4530	0x42A1.00	-	-	S16	-	RO	YES	-

Homing mode status (see details in the [Table 27.15](#)).

Value	Description
-2	Homing running.
-1	The drive is saving the data in the permanent memory.
0	The homing has been disabled and/or interrupted (aborted) by another command (e.g. bit <i>Halt</i> , reset bit <i>Homing operation start</i> , ..., see Table 8.14).
1	Homing correctly executed.
17	Error: It has not been found the Home switch between 2 limit switch (it concerns the HomingMethod with limit switches management, see also Table 22.3) and the axis is moving.
18	Error: it has been reached a limit switch before the Home switch has been found (it regards the HomingMethod without limit switch management, see also Table 22.3) and the axis is on moving.
20	Error: The Index pulse has already been programmed as capture trigger in the Capture B peripheral and the axis is on moving (see IndexPulseNote).
21	Error: during the homing procedure when it has been selected a mode with the mechanical stop management, the axis is on moving and it has not been activated the torque limit (see Section 19.3 , " <i>Torque limit</i> ").
49	Same as 17. Differences: the axis is stationary.
50	Same as 18. Differences: the axis is stationary.
52	Same as 20. Differences: the axis is stationary.
53	Same as 21. Differences: the axis is stationary.

Table 27.15. Accepted values for the HomingStatus parameter.

NOTICE

This parameter is part of the group **Non-resettable parameters**. If a firmware reset happens, and the feedback sensor is not absolute, the homing status, read by the **HomingStatus** parameter, is maintained only if the code that's returned by the **ResetCause** parameter is 5 or 6. If the feedback sensor is absolute the homing status is maintained even if the drive is off.

NOTE

In some cases the reset of this parameter can also be done by the modification of one of the **Non-resettable on the reset parameters**.

CyclicSynchronousSubMode

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4540	0x42D0.00	Desc	-136	S16	-	RW	YES	-

This parameter is used only to change the interpolation type that the drive has to execute when one of the synchronous cyclic modes is active (see [Section 22.11, Cyclic Synchronous Position Mode](#), [Section 22.12, Cyclic Synchronous Velocity Mode](#), [Section 22.13, Cyclic Synchronous Torque Mode](#)).

The new sub-mode is applied when the operative mode is changed by writing the value of the new operative mode in the [ModesOfOperation](#). Otherwise the previous sub-mode remains active.

This parameter is applied even if an operative mode change doesn't happen, in case the drive executes a transition to switch the state machine [CiA-402](#) to the [Operation enable](#) status: in particular, it is referred to the transitions 4 and 16 (see [Table 8.13](#)).

ModesOfOperationDisplay	CyclicSynchronousSubMode	Interpolation type	Auto KVff ^a	Auto KAff ^b
8	-136	none	0	0
	-135		0	1
	-132		1	0
	-131		1	1
	-144	linear	0	0
	-143		0	1
	-140		1	0
	-139		1	1
	-148	cubic	1	0
	-147		1	1
9	-136, -132	none	-	0
	-135, -131		-	1
	-144, -140	linear	-	0
	-143, -139		-	1
10	-136, -135, -132, -131	none	-	-
	-144, -143, -140, -139	linear	-	-

^a0 = the feed forward velocity is calculated according to the [VelocityOffset](#) parameter; 1 = the feed forward velocity calculation is automatically executed internally of the drive; - = not applicable.

^b0 = the feed forward acceleration is calculated according to the [TorqueOffset](#) parameter; 1 = the feed forward acceleration calculation is automatically executed internally of the drive; - = not applicable.

Table 27.16. Available interpolation modes.

Sub-modes application example

- the drive is turned-on and the [ModesOfOperation](#) and [CyclicSynchronousSubMode](#) cells values are the defaults, respectively 3 and -136;
- write -139 in the parameter (the new sub-mode is selected but not applied);
- write 8 (CSP) in the parameter (the new sub-mode is applied for the CSP mode);
- write -136 in the parameter (the new sub-mode is selected but not applied);
- write 9 (CSV) in the parameter (the new sub-mode is applied for the CSV mode);
- write 8 (CSP) in the parameter (the new sub-mode is applied for the CSP mode);

PositionOffset

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4541	0x60B0.00	-	0	S32	inc	RW	YES	-

Position offset that will be added to the [TargetPosition](#) if the *Cyclic Synchronous Position Mode* is active (see [Section 22.11, Cyclic Synchronous Position Mode](#)).

VelocityOffset

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4543	0x60B1.00	Desc	0	S32	inc/s	RW	YES	-

Velocity offset that will be added to the [TargetVelocity](#) if the *Cyclic Synchronous Velocity Mode* is active (see [Section 22.12, Cyclic Synchronous Velocity Mode](#)). Instead, in case of *Cyclic Synchronous Position Mode*, it can be used as velocity feed forward or velocity reference, depending on the interpolation mode (see [CyclicSynchronousSubMode](#)). The range of accepted values goes from -3216.9 to 3216.9 rad/s.

TorqueOffset

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4545	0x60B2.00	-	0	S16	10 = 1%IS	RW	YES	-

Torque offset that will be added to the [TargetTorque](#) if the *Cyclic Synchronous Torque Mode* is active (see [Section 22.13, Cyclic Synchronous Torque Mode](#)). Instead, in case of *Cyclic Synchronous Position Mode* or *Cyclic Synchronous Velocity Mode* it can be used as acceleration feed forward (vedere [CyclicSynchronousSubMode](#)).

IpPosSubModeSelect

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4550	0x60C0.00	Desc	0	S16	-	RW	YES	-

Selector of the interpolation type the drive must run when the *Interpolated Position Mode* is enabled (see [Section 22.10, Interpolated Position Mode](#)).

IpPosSub-ModeSelect	Description
0	Linear interpolation.
-1	Cubic interpolation.
-10	Linear interpolation with speed feed forward.

IpTimePeriod

Time gap in which the interpolation data must be transmitted. the final value must be calculated with the following formula: $\text{IpTimePeriodValue} * 10^{\text{IpTimeIndex}}$ [s]. This parameter can be used alternatively to the [CommunicCyclePeriod](#) (CAN) or [CommunicCyclePeriod](#) (ETC) parameter. If these parameters are used at the same time, they must express the same value.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x60C2.00	2	2	U8	-	CST	-	-

Number of parameters in this group.

The validation is done as follows:

- With EtherCAT drives, in **Soft sync** mode : If **IpTimePeriod** or **CommunicCyclePeriod** have been implemented with an out of range or not equal value, a configuration error is reported. If **IpTimePeriod** is right and **CommunicCyclePeriod** is set to 0, then **CommunicCyclePeriod** takes the value of **IpTimePeriod**. If **IpTimePeriod** has not been set (default) and **CommunicCyclePeriod** has a correct value, **CommunicCyclePeriod** is copied in **IpTimePeriod**. If both the values are within the limits and equals each other, the **CommunicCyclePeriod** parameter value is taken as cycle time.
- With EtherCAT drives in **Hard sync** mode : the **CommunicCyclePeriod** parameter is ignored, in its place the value that's written in the 0x09A0 address, in the **ET1100** registers area, is inserted. If **IpTimePeriod** or **ET1100** are set with an out of range or not equal value, a configuration error is reported. If **IpTimePeriod** has not been set and **ET1100** has a correct value, **ET1100** is copied in **IpTimePeriod**. If both the values are within the limits and equals each other, the **ET1100** value is taken as cycle time.
- With CANopen drives : If **IpTimePeriod** or **CommunicCyclePeriod** have been set with an out of range or not equal value, a configuration error is reported. If **IpTimePeriod** has not been set (default) and **CommunicCyclePeriod** has a correct value, **CommunicCyclePeriod** is copied in **IpTimePeriod**. If both the values are within the limits and equals each other, the **CommunicCyclePeriod** parameter value is taken as cycle time.

IMPORTANT

For the CAN version drives, the parameters of the **IpTimePeriod** group are writable only if the drive has not the **NMT state machine** in OPERATIONAL state.
For the ETC version drives, the parameters of the **IpTimePeriod** group are writable only if the drive has not the **EtherCAT state machine** in SAFE-OPERATIONAL or OPERATIONAL state.

IpTimePeriodValue

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4551	0x60C2.01	0-255	1	U8	s	RW	-	-

First multiplication factor to calculate **IpTimePeriod**.

IpTimePeriodIndex

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4552	0x60C2.02	-6 ÷ -2	-3	S8	-	RW	-	-

Exponent (base 10) for the calculation of **IpTimePeriod**.

IpPosDataRecord

Group of parameters that defines the set-point in the *Interpolated Position Mode*. It consists of **IpPosFirstParameter** and **IpPosSecondParameter**.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x60C1.00	2	2	U8	-	CST	-	-

Number of parameters in this group.

IpPosFirstParameter

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4560	0x60C1.01	-	0	S32	inc	RW	YES	-

This parameter is the first of a data group that are used all together to define the set-point the interpolator must reach. It contains the position value which must be reached. The parameter is valid only for *Interpolated Position Mode*.

IpPosSecondParameter

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4562	0x60C1.02	-	0	S32	Desc	RW	YES	-

This parameter is the second of a data group that are used all together to define the set-point the interpolator must reach. It contains the speed which must be reached. The parameter is valid only for *Interpolated Position Mode* and is expressed in $[65536 = 1inc/T_{SYNC}]$.

IpPosDataConfig

Group of parameters that define the [IpPosDataRecord](#) configuration.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x60C4.00	6	6	U8	-	CST	-	-

Number of parameters in this group.

IpPosDataConfigMaxBufferSize

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4592	0x60C4.01	1	1	U32	-	RW	-	-

[IpPosDataRecord](#) configuration: maximum number of buffer points.

IpPosDataConfigActualBufferSize

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4594	0x60C4.02	1	1	U32	-	RW	-	-

[IpPosDataRecord](#) configuration: actual number of buffer points.

IpPosDataConfigBufferOrganization

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4596	0x60C4.03	0	0	U8	-	RW	-	-

[IpPosDataRecord](#) configuration: it specifies the buffer organization (FIFO type buffer).

IpPosDataConfigBufferPosition

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4597	0x60C4.04	0	0	U16	-	RW	-	-

IpPosDataRecord configuration: index of **IpPosDataRecord** used for the interpolation (index of the first available point).

IpPosDataConfigSizeDataRecord

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4598	0x60C4.05	Desc	-	U8	-	WO	-	-

IpPosDataRecord configuration: it expresses the dimension in bytes of **IpPosDataRecord** (dimension in byte of the single point). It can take the values 4 or 8, depending on the **IpPosSubModeSelect** parameter; if **IpPosSubModeSelect**=0 then **IpPosDataConfigSizeDataRecord**=4, else **IpPosDataConfigSizeDataRecord**=8

IpPosDataConfigBufferClear

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4599	0x60C4.06	1	1	U8	-	RW	-	-

IpPosDataRecord configuration: it specifies that the **IpPosDataRecord** is enabled (it can't be disabled).

MaxAcceleration

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4600	0x60C5.00	Desc	Desc	U32	inc/s ²	RW	YES	ES

Maximum deceleration used to run a profile. The default value is 205887.3 rad/s² while the range of the accepted values goes from 0.32 to 205887.3 rad/s².

MaxDeceleration

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4602	0x60C6.00	Desc	Desc	U32	inc/s ²	RW	YES	ES

Maximum deceleration used to run a profile. The default value is 205887.3 rad/s² while the range of the accepted values goes from 0.32 to 205887.3 rad/s².

TargetVelocity

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4700	0x60FF.00	Desc	0	S32	inc/s	RW	YES	-

Target velocity the motor has to reach in *Profile Velocity Mode (CiA402)*, in *Profile Velocity Mode (CUSTOM)* or in *Cyclic Synchronous Velocity Mode*. If the drive is programmed with the *Profile Velocity Mode (CiA402)* or the *Profile Velocity Mode (CUSTOM)* and its status is **Operation enable**, the writing of a velocity that has an absolute value greater than **EndVe-**

locity and **StartVelocity** starts the movement, while the writing of a velocity that has an absolute value lower or equal stops the movement. The sign of the speed written in this parameter defines the motion direction. The range of accepted values goes from -3216.9 to 3216.9 rad/s.

SupportedDriveModes

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
4800	0x6502.00	0x3ED	0x3ED	U32	-	RO	-	ES

Seupported **CiA-402** standard operative modes: *csp (Cyclic Synchronous Position Mode)*, *csv (Cyclic Synchronous Velocity Mode)*, *cst (Cyclic Synchronous Torque Mode)*, *ip (Interpolated Position Mode)*, *hm (Homing Mode)*, *tq (Torque Mode)*, *pv (Profile Velocity Mode (CiA402))*, *pp (Profile Position Mode)*.

27.19. Brake (5000-5199)

Brake

Group of parameter to manage the brake.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x36D0.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

BrakeReleaseTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
5000	0x36D0.01	-	Desc	U16	ms	RW	-	EM

Brake release delay time.

BrakeCloseTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
5001	0x36D0.02	-	Desc	U16	ms	RW	-	EM

Brake response time.

BrakeStatus

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
5002	0x36D0.03	-	Desc	U16	-	RW	-	-

Brake status. This parameter is writable only when the motor is disabled.. The values that it can assume are: 0=Brake close (the brake is closed and ther motor is braked), 1=Brake release (the brake is released and ther motor is not braked).

27.20. Auxiliary position sensor (6500-6549)

RealEncParam

Group of parameters for the real master sensor functionalities configuration.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x36C9.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

RealEncoderPosition

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6500	0x36C9.01	-	0	S32	cnt	RW	YES	-

Position reached by the physical auxiliary position sensor. Through a writing operation it's possible to modify this value.

RealEncoderVelocity

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6502	0x36C9.03	-	0	S32	cnt/s	RO	YES	-

Velocity reached by the physical auxiliary position sensor.

RealEncoderPolarity

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6504	0x36C9.02	-	0	U16	-	RW	-	ES

Polarity of the physical sensor: Rotation direction where the position value increases: 0=Forward, 1=Reverse.

VirtualEncParam

Group of parameters for the virtual master sensor functionalities configuration.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x36C8.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

VirtualEncoderPosition

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6510	0x36C8.01	-	0	S32	cnt	RW	YES	-

Position reached by the virtual auxiliary position sensor.

VirtualEncoderVelocity

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6512	0x36C8.03	-	0	S32	Desc	RW	YES	-

Velocity of virtual auxiliary sensor expressed in [65536 = 10000cnt/s] (e.g.. to obtain 2500 cnt/s the value to be inserted is 16384).

VirtualEncoderRunStop

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6514	0x36C8.02	0-1	0	U8	-	RW	-	-

Run/stop command of the virtual sensor (0=stop, 1=run).

AuxiliaryEncParam

Group of parameters for the selected auxiliary master sensor functionalities configuration.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x36CA.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

AuxiliaryEncoderPosition

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6520	0x36CA.01	-	-	S32	cnt	RO	YES	-

Position reached by the selected auxiliary position sensor.

AuxiliaryEncoderSpeed

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6522	0x36CA.03	-	-	S32	cnt/s	RO	YES	-

Velocity reached by the selected auxiliary position sensor.

AuxiliaryEncoderSelector

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6524	0x36CA.02	0-1	0	U16	-	RW	-	-

Auxiliary sensor selection command: 0=real encoder, 1=virtual encoder.

27.21. Digital inputs and outputs (6550-6999)

DigitalInputFuncStatus

Status of digital inputs if programmed as FC, Home, Enable.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4054.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

FcStatus

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6558	0x4054.01	-	-	U16	-	RO	-	-

Status of the programmed inputs with the function of positive and negative limit switch.



If the [Polarity](#) is of Reverse type, then the roles of [Positive limit switch \(FC +\)](#) and [Negative limit switch \(FC -\)](#) are reversed: [Positive limit switch \(FC +\)](#) behaves like [Negative limit switch \(FC -\)](#) and [Negative limit switch \(FC -\)](#) behaves like [Positive limit switch \(FC +\)](#). This is true both in the text of this manual and in the MotionDrive.

FcStatus	Description
Bit 0	Status of the programmed input with the functionality Negative limit switch (FC -)
Bit 1	Status of the programmed input with the functionality Positive limit switch (FC +)

HomeStatus

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6559	0x4054.02	-	-	U16	-	RO	-	-

Status of the programmed input with the function of [Home](#)

EnableInputStatus

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6560	0x4054.03	-	-	U16	-	RO	-	-

Status of the programmed input with the function of [Enable](#). If no input is associated to the [Enable](#) function, EnableInputStatus is always equal to 1.

DisableOption

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6561	0x406E.00	-	2	S16	-	RW	-	ES

Disabling options through the digital input configured as [Enable](#).

DisableOption	Description
-1	The motor is stopped with maximum deceleration by resetting to zero RequestedSpeed
2	The motor is stopped with deceleration equal to QuickStopDeceleration

DisableOkOutput

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6570	0x406F.00	-	1041	U32	-	RW	-	ES

Mask used to select the Faults disabling the digital output [Drive Ok \(Drv OK\)](#): 0 = the Fault, even if present, does not disable the output; 1 = the Fault disables the output. The relation between the mask bits and the Faults is shown in [Table 24.1](#).

PwmHwParam

Group of parameters for the PWM output configuration.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x403F.00	6	6	U8	-	CST	-	-

Number of parameters in this group.

PwmHwFrequencyIO0

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6580	0x403F.01	1-50000	1000	U16	Hz	RW	-	-

Frequency of the signal generated by the I/O 0 when programmed as output pwm.

PwmHwDutyCycleIO0

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6581	0x403F.02	0-100	0	U16	%	RW	-	-

Duty Cycle of the signal generated by the I/O 0 when programmed as output pwm. The value 0 means the output is disabled while the value 100 means the output is enabled.

PwmHwFrequencyIO1

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6582	0x403F.03	1-50000	1000	U16	Hz	RW	-	-

Frequency of the signal generated by the I/O 0 when programmed as output pwm.

PwmHwDutyCycleIO1

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6583	0x403F.04	0-100	0	U16	%	RW	-	-

Duty Cycle of the signal generated by the I/O 0 when programmed as output pwm. The value 0 means the output is disabled while the value 100 means the output is enabled.

PwmHwFrequencyIO2

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6584	0x403F.05	1-50000	1000	U16	Hz	RW	-	-

Frequency of the signal generated by the I/O 0 when programmed as output pwm.

PwmHwDutyCycleIO2

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6585	0x403F.06	0-100	0	U16	%	RW	-	-

Duty Cycle of the signal generated by the I/O 0 when programmed as output pwm. The value 0 means the output is disabled while the value 100 means the output is enabled.

LogicalDigitalInputStatus

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6600	0x4051.01	-	-	U32	-	RO	YES	-

Logical status of the digital inputs, after having applied [PolarityInputValue](#).

Bit	Resource
0-15	Reserved
16	IN/OUT 0
17	IN/OUT 1
18	IN/OUT 2
19	IN/OUT 3
20	IN 4
21	IN 5
22	IN 6
23	IN 7
24	IN 8
25	IN 9
26	/STO
27-31	Reserved

Table 27.17. Association of the bits of the parameter [LogicalDigitalInputStatus](#) of the I/O of iBMD.

DigitalInputs

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6602	0x60FD.00	-	-	U32	-	RO	YES	-

Physical status of the digital inputs, for the description of the single bits see [Table 27.17](#).

PhysicalOutputs

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6604	0x60FE.01	-	Desc	U32	-	RW	YES	-

Status of the digital outputs. The default value of the digital outputs which have the [Generic Output \(I/O X - Out X\)](#) functionality is 0 (output off).

Bit	Resource
0-15	Reserved
16	IN/OUT 0
17	IN/OUT 1
18	IN/OUT 2
19	IN/OUT 3
20	OUT 4
21	OUT 5
22	OUT 6
23-31	Reserved

Table 27.18. Association of the bits of the parameter [PhysicalOutputs](#) of the I/O of iBMD.

DigitalOutputsBitMask

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6606	0x60FE.02	-	0xFFFFFFFF	U32	-	RW	YES	-

Enabling mask of the writing of the parameter [PhysicalOutputs](#): 1=writing enabled, 0=writing not enabled. For a description of the single bits see [Table 27.18](#)

DebounceTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6608	0x405F.00	250-65000	250	U16	µs	RW	-	ES

Filtering time of the digital inputs. See [Filtering of the digital inputs](#)

EnableDebounce

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6609	0x405E.00	-	0	U16	-	RW	-	ES

Enabling mask of the filtering on the selected inputs. See [Filtering of the digital inputs](#)

PolarityInputValue

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6610	0x405A.00	-	0	U16	-	RW	YES	ES

This parameter is used to define which inputs must work by reversed logics. As default the input is on the logical status 1 when there is power on that. This setting has no effect if the input is programmed as limit switch. See [Selection of the polarity of the digital inputs](#) for further details.

Bit	Resource
0	IN/OUT 0
1	IN/OUT 1
2	IN/OUT 2
3	IN/OUT 3
4	IN 4
5	IN 5
6	IN 6
7	IN 7
8	IN 8
9	IN 9
7-15	Reserved

Table 27.19. Association of the bits of the parameter *PolarityInputValue* of the I/O of iBMD.

TerminationResistance

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6611	0x405B.00	-	0	U16	-	RW	YES	ES

This parameter is used to enable the termination resistances for the resources at differential logics. See [Termination resistances](#) for further details.

Bit	Resource
0	IN/OUT 0
1	IN/OUT 1
2	IN/OUT 2
3-15	Reserved

Table 27.20. Association of the bits of the parameter *TerminationResistance* of the I/O of iBMD.

IO_0_Function

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6700	0x4070.01	-	1	U16	-	RW	-	ES


Functionality given to the I/O 0.

The codes of the functionalities are listed in [Table 27.21](#). In the [Table 16.6](#) you can find the functionalities which can be given to the single resources.

Functionalities	Code
Generic Input (I/O X - In X)	1
Generic Output (I/O X - Out X)	2
Fault (Fault)	3
Home	7
Step	8
Dir	9
Positive limit switch (FC +)	10
Negative limit switch (FC -)	11
Enable	13

Functionalities	Code
Quadrature Input ChA (Ch A)	14
Quadrature Input ChB (Ch B)	15
Quadrature Input Index (Idx)	16
Pwm out (Pwm O)	17
Motor Fan (M. Fan)	19
Drive Fan (D. Fan)	20
Drive Ok (Drv OK)	22
Simulated 24V Out (S24V)	23
Simulated GND (SGND)	24

Table 27.21. Codes related to the functionalities which can be given to the I/O resources



NOTICE

Simulated GND (SGND) input is not protected against overcurrent.

IO_1_Function

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6701	0x4071.01	-	1	U16	-	RW	-	ES

Functionality assigned to I/O 1.

The codes of the functionalities are listed in Table 27.21. In the Table 16.6 you can find the resources which can be given to the single functionalities.

IO_2_Function

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6702	0x4072.01	-	1	U16	-	RW	-	ES

Functionality assigned to I/O 2.

The codes of the functionalities are listed in Table 27.21. In the Table 16.6 you can find the resources which can be given to the single functionalities.

IO_3_Function

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6703	0x4073.01	-	1	U16	-	RW	-	ES

Functionality assigned to I/O 3.

The codes of the functionalities are listed in Table 27.21. In the Table 16.6 you can find the resources which can be given to the single functionalities.

In_4_Function

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6724	0x4084.01	-	1	U16	-	RW	-	ES

Functionality assigned to In 4.

The codes of the functionalities are listed in [Table 27.21](#). In the [Table 16.6](#) you can find the resources which can be given to the single functionalities.

In_5_Function

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6725	0x4085.01	-	1	U16	-	RW	-	ES

Functionality assigned to In 5.

The codes of the functionalities are listed in [Table 27.21](#). In the [Table 16.6](#) you can find the resources which can be given to the single functionalities.

In_6_Function

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6726	0x4086.01	-	1	U16	-	RW	-	ES

Functionality assigned to In 6.

The codes of the functionalities are listed in [Table 27.21](#). In the [Table 16.6](#) you can find the resources which can be given to the single functionalities.

In_7_Function

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6727	0x4087.01	-	1	U16	-	RW	-	ES

Functionality assigned to In 7.

The codes of the functionalities are listed in [Table 27.21](#). In the [Table 16.6](#) you can find the resources which can be given to the single functionalities.

In_8_Function

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6728	0x4088.01	-	1	U16	-	RW	-	ES

Functionality assigned to In 8.

The codes of the functionalities are listed in [Table 27.21](#). In the [Table 16.6](#) you can find the resources which can be given to the single functionalities.

In_9_Function

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6729	0x4089.01	-	1	U16	-	RW	-	ES

Functionality assigned to In 9.

The codes of the functionalities are listed in [Table 27.21](#). In the [Table 16.6](#) you can find the resources which can be given to the single functionalities.

Out_4_Function

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6789	0x40C4.01	-	2	U16	-	RW	-	ES

Functionality assigned to Out 4.

The codes of the functionalities are listed in [Table 27.21](#). In the [Table 16.6](#) you can find the resources which can be given to the single functionalities.

Out_5_Function

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6790	0x40C5.01	-	2	U16	-	RW	-	ES

Functionality assigned to Out 5.

The codes of the functionalities are listed in [Table 27.21](#). In the [Table 16.6](#) you can find the resources which can be given to the single functionalities.

Out_6_Function

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
6791	0x40C6.01	-	2	U16	-	RW	-	ES

Functionality assigned to Out 6.

The codes of the functionalities are listed in [Table 27.21](#). In the [Table 16.6](#) you can find the resources which can be given to the single functionalities.

27.22. Analog input (7000-7999)

AI0CalibrationParameters

Calibration of the analog input 0.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4100.00	-	4	U8	-	CST	-	-

Number of parameters in this group. For further details see [Section 17.2, Calibration](#).

AI0CalibrationStatus

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
7001	0x4100.01	-	4	U16	-	RO	-	ES

Status of the calibration of the analog input 0.

AI0CalibrationStatus	Description
0	No calibration run; the voltage values may not respect the specified tolerance
1	Calibration not completed (only offset); complete the calibration
2	Calibration not completed (only gain); complete the calibration
3	Calibration completed
4	Default calibration

AI0CalibrationOffset

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
7002	0x4100.02	-	Desc	S16	-	RO	-	ES

Calibration offset of the analog input 0. The default value is calculated with the calibration run by Bonfiglioli.

AI0CalibrationGain

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
7003	0x4100.03	-	Desc	U16	-	RO	-	ES

Calibration gain of the analog input 0.

AI0CalibrationVoltage

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
7004	0x4100.04	4000-10000	-	U16	mV	RW	-	-

Calibration voltage of the analog input 0. The default value is calculated with the calibration run by Bonfiglioli.

AI0FilterParameters

Filter of the analog input 0.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4110.00	-	3	U8	-	CST	-	-

Number of parameters in this group. For further details see [Chapter 28, Digital filters](#).

AI0FilterFrequency

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
7011	0x4110.01	-	100	U16	Hz	RW	-	ES

Typical frequency of the filter on the analog input 0.

AI0FilterType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
7012	0x4110.02	-	2	U16	-	RW	-	ES

Filter type on the analog input 0.

AI0FilterType	Description
0	All-stop filter
1	Low-pass filter of the first order

AI0FilterType	Description
2	Low-pass filter of the second order
3	Band-eliminating filter
65535	All-pass filter

AI0FilterQFactor

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
7013	0x4110.03	-	100	U16	10 = 1	RW	-	ES

Quality Q factor of the filter on the analog input 0.

AI0ConversionParameters

Settings for the conversions with the analog input 0.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x4120.00	-	8	U8	-	CST	-	-

Number of parameters in this group. For further details see [Section 17.3, Conversion](#).

AI0VSettings

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
7051	0x4120.01	-	1	U16	-	RW	-	ES

Setting the voltage for the conversion with the analog input 0 (0 = only positive; 1 = symmetric).

AI0RSettings

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
7052	0x4120.02	-	1	U16	-	RW	-	ES

Setting the reference for the conversion with the analog input 0 (0 = only positive; 1 = symmetric).

AI0VPolarity

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
7053	0x4120.03	-	0	U16	-	RW	-	ES

Voltage polarity for the conversion with the analog input 0 (0 = normal; 1 = reversed).

AI0RPolarity

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
7054	0x4120.04	-	0	U16	-	RW	-	ES

Reference polarity for the conversion with the analog input 0 (0 = normal; 1 = reversed).

AIOV0Zone

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
7055	0x4120.05	-	10	U16	mV	RW	-	ES

Half amplitude of the dead zone of the analog input.

AIOVRefLevel

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
7056	0x4120.06	-	10000	U16	mV	RW	-	ES

Voltage value to define the conversion.

AIOTRefValue

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
7057	0x4120.07	0 ÷ 32767	1200	U16	10 = 1%IS	RW	-	ES

Torque value to define the conversion.

AIOWRefValue

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
7058	0x4120.08	-	MotorRatedSpeed	U32	inc/s	RW	-	ES

Speed value to define the conversion.

27.23. PDO managed by the port CANopen (10000-11999)

NOTE

This vocabulary section can be found only in the drive version CAN

PdoRx1_CommunicationParameters

Communication parameters of the PDO RX 1.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1400.00	2	2	U8	-	CST	-	-

Number of parameters in this group.

PdoRx1_CobID

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10000	0x1400.01	Desc	Desc	U32	-	RW	-	-

PDO RX 1 COB-ID. In [Table 27.22](#) the bit code interpretation is reported. The default value is 0x80000200 + Node-ID.

Bit	Description
0 - 10	Field at 11 bits for the standard ID (CAN 2.0).
11 - 28	Field at 18 bits for the extended ID, not supported. They must be set at 0.
29	Format identifier. It must be equal to 0 (standard identifier).
30	It must always be set at 0 because the drives of the series iBMD do not support the PDOs of RTR type
31	If set to 0, it enables the PDO when the NMT state machine is in the OPERATIONAL status.

Table 27.22. Bit encoding of the parameters to set the COB-ID of the PDO

PdoRx1_TransmissionType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10002	0x1400.02	Desc	255	U8	-	RW	-	-

Type of transmission PDO RX 1. In [Table 27.23](#) you can find the accepted values.

PDO RX Transmission Type	Description
0 - 240	<i>Synchronous</i> . The received PDO is applied only to the receiving of the next SYNC.
241 - 253	Not supported
254 - 255	<i>On event</i> . The received PDO is immediately applied.

Table 27.23. Accepted values of the parameters to set the Transmission Type of the PDOs RX

PdoRx2_CommunicationParameters

Communication parameters of the PDO RX 2.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1401.00	2	2	U8	-	CST	-	-

Number of parameters in this group.

PdoRx2_CobID

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10015	0x1401.01	Desc	Desc	U32	-	RW	-	-

PDO RX 2 COB-ID. In [Table 27.22](#) the bit code interpretation is reported. The default value is 0x80000300 + Node-ID.

PdoRx2_TransmissionType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10017	0x1401.02	Desc	255	U8	-	RW	-	-

Transmission type PDO RX 2. In [Table 27.23](#) you can find the accepted values.

PdoRx3_CommunicationParameters

Communication parameters of the PDO RX 3.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1402.00	2	2	U8	-	CST	-	-

Number of parameters in this group.

PdoRx3_CobID

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10030	0x1402.01	Desc	Desc	U32	-	RW	-	-

PDO RX 3 COB-ID. In [Table 27.22](#) the bit code interpretation is reported. The default value is 0x80000400 + Node-ID.

PdoRx3_TransmissionType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10032	0x1402.02	Desc	255	U8	-	RW	-	-

Transmission type PDO RX 3. In [Table 27.23](#) you can find the accepted values.

PdoRx4_CommunicationParameters

Communication parameters of the PDO RX 4.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1403.00	2	2	U8	-	CST	-	-

Number of parameters in this group.

PdoRx4_CobID

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10045	0x1403.01	Desc	Desc	U32	-	RW	-	-

PDO RX 4 COB-ID. In [Table 27.22](#) the bit code interpretation is reported. The default value is 0x80000500 + Node-ID.

PdoRx4_TransmissionType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10047	0x1403.02	Desc	255	U8	-	RW	-	-

Transmission type PDO RX 4. In [Table 27.23](#) you can find the accepted values.

PdoRx1_MappingParameters

Parameters for the PDO RX 1 mapping.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10150	0x1600.00	0 - 8	1	U8	-	RW	-	-

Number of mapped objects.

PdoRx1_Objects

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
Desc	Desc	Desc	Desc	U32	-	RW	-	-

Parameters used for mapping the mappable parameters in the PDOs.

Modbus	CANopen	Name	Default
10151	0x1600.01	PdoRx1_Object1	0x60400010 (Controlword)
10153	0x1600.02	PdoRx1_Object2	0
10155	0x1600.03	PdoRx1_Object3	0
10157	0x1600.04	PdoRx1_Object4	0
10159	0x1600.05	PdoRx1_Object5	0
10161	0x1600.06	PdoRx1_Object6	0
10163	0x1600.07	PdoRx1_Object7	0
10165	0x1600.08	PdoRx1_Object8	0

PdoRx2_MappingParameters

Parameters for the PDO RX 2 mapping.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10175	0x1601.00	0 - 8	2	U8	-	RW	-	-

Number of mapped objects.

PdoRx2_Objects

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
Desc	Desc	Desc	Desc	U32	-	RW	-	-

Parameters used for mapping the mappable parameters in the PDOs.

Modbus	CANopen	Name	Default
10176	0x1601.01	PdoRx2_Object1	0x60400010 (Controlword)
10178	0x1601.02	PdoRx2_Object2	0x60600008 (ModesOfOperation)
10180	0x1601.03	PdoRx2_Object3	0
10182	0x1601.04	PdoRx2_Object4	0
10184	0x1601.05	PdoRx2_Object5	0
10186	0x1601.06	PdoRx2_Object6	0
10188	0x1601.07	PdoRx2_Object7	0
10190	0x1601.08	PdoRx2_Object8	0

PdoRx3_MappingParameters

Parameters for the PDO RX 3 mapping.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10200	0x1602.00	0 - 8	2	U8	-	RW	-	-

Number of mapped objects.

PdoRx3_Objects

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
Desc	Desc	Desc	Desc	U32	-	RW	-	-

Parameters used for mapping the mappable parameters in the PDOs.

Modbus	CANopen	Name	Default
10201	0x1602.01	PdoRx3_Object1	0x60400010 (Controlword)
10203	0x1602.02	PdoRx3_Object2	0x607A0020 (TargetPosition)
10205	0x1602.03	PdoRx3_Object3	0
10207	0x1602.04	PdoRx3_Object4	0
10209	0x1602.05	PdoRx3_Object5	0
10211	0x1602.06	PdoRx3_Object6	0
10213	0x1602.07	PdoRx3_Object7	0
10215	0x1602.08	PdoRx3_Object8	0

PdoRx4_MappingParameters

Parameters for the PDO RX 4 mapping.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10225	0x1603.00	0 - 8	2	U8	-	RW	-	-

Number of mapped objects.

PdoRx4_Objects

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
Desc	Desc	Desc	Desc	U32	-	RW	-	-

Parameters used for mapping the mappable parameters in the PDOs.

Modbus	CANopen	Name	Default
10226	0x1603.01	PdoRx4_Object1	0x60400010 (Controlword)
10228	0x1603.02	PdoRx4_Object2	0x60FF0020 (TargetVelocity)
10230	0x1603.03	PdoRx4_Object3	0
10232	0x1603.04	PdoRx4_Object4	0
10234	0x1603.05	PdoRx4_Object5	0
10236	0x1603.06	PdoRx4_Object6	0
10238	0x1603.07	PdoRx4_Object7	0
10240	0x1603.08	PdoRx4_Object8	0

PdoTx1_CommunicationParameters

Communication parameters of the PDO TX 1.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1800.00	5	5	U8	-	CST	-	-

Number of parameters in this group.

PdoTx1_CobID

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10350	0x1800.01	Desc	Desc	U32	-	RW	-	-

PDO TX 1 COB-ID. In [Table 27.22](#) the bit code interpretation is reported. The default value is 0xC0000180 + Node-ID.

PdoTx1_TransmissionType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10352	0x1800.02	Desc	255	U8	-	RW	-	-

Transmission type PDO TX 1. In [Table 27.24](#) you can find the accepted values.

PDO TX Transmission Type	Description
0	<i>Acyclic.</i> The PDO is transmitted together with the SYNC, but only when the internal logics of the drive asks for the sending. This value cannot be set if the Event timer of the PDO is different from 0.
1 - 240	<i>Cyclic.</i> The PDO is transmitted together with the SYNC, one for each <i>PDO TX Transmission Type</i> SYNC messages received. This values cannot be set if the Event timer of the PDO is different from 0.
241 - 253	Not supported
254 - 255	<i>On event.</i> The PDO is immediately transmitted the internal logics of the drive asks for the sending.

Table 27.24. Accepted values for setting the Transmission Type of the PDO TX

PdoTx1_InhibitTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10353	0x1800.03	-	1	U16	10 = 1ms	RW	-	-

PDO TX 1 inhibition time (see the notes reported in [Section 9.5, Process data object \(PDO\)](#)).

PdoTx1_EventTimer

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10356	0x1800.05	-	0	U16	ms	RW	-	-

Event timer of the PDO TX 1.

PdoTx2_CommunicationParameters

Communication parameters of the PDO TX 2.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1801.00	5	5	U8	-	CST	-	-

Number of parameters in this group.

PdoTx2_CobID

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10365	0x1801.01	Desc	Desc	U32	-	RW	-	-

PDO TX 2 COB-ID. In [Table 27.22](#) the bit code interpretation is reported. The default value is 0xC0000280 + Node-ID.

PdoTx2_TransmissionType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10367	0x1801.02	Desc	255	U8	-	RW	-	-

Transmission type PDO TX 2. In [Table 27.24](#) you can find the accepted values.

PdoTx2_InhibitTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10368	0x1801.03	-	1	U16	10 = 1ms	RW	-	-

PDO TX 2 inhibition time (see the notes reported in [Section 9.5, Process data object \(PDO\)](#)).

PdoTx2_EventTimer

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10371	0x1801.05	-	0	U16	ms	RW	-	-

Event timer of the PDO TX 2.

PdoTx3_CommunicationParameters

Communication parameters of the PDO TX 3.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1802.00	5	5	U8	-	CST	-	-

Number of parameters in this group.

PdoTx3_CobID

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10380	0x1802.01	Desc	Desc	U32	-	RW	-	-

PDO TX 3 COB-ID. In [Table 27.22](#) the bit code interpretation is reported. The default value is 0xC0000380 + Node-ID.

PdoTx3_TransmissionType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10382	0x1802.02	Desc	255	U8	-	RW	-	-

Transmission type PDO TX 3. In [Table 27.24](#) you can find the accepted values.

PdoTx3_InhibitTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10383	0x1802.03	-	1	U16	10 = 1ms	RW	-	-

PDO TX 3 inhibition time (see the notes reported in [Section 9.5, Process data object \(PDO\)](#)).

PdoTx3_EventTimer

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10386	0x1802.05	-	0	U16	ms	RW	-	-

Event timer of the PDO TX 3.

PdoTx4_CommunicationParameters

Communication parameters of the PDO TX 4.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1803.00	5	5	U8	-	CST	-	-

Number of parameters in this group.

PdoTx4_CobID

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10395	0x1803.01	Desc	Desc	U32	-	RW	-	-

PDO TX 4 COB-ID. In [Table 27.22](#) the bit code interpretation is reported. The default value is 0xC0000480 + Node-ID.

PdoTx4_TransmissionType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10397	0x1803.02	Desc	255	U8	-	RW	-	-

Transmission type PDO TX 4. In [Table 27.24](#) you can find the accepted values.

PdoTx4_InhibitTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10398	0x1803.03	-	1	U16	10 = 1ms	RW	-	-

PDO TX 4 inhibition time (see the notes reported in [Section 9.5, Process data object \(PDO\)](#)).

PdoTx4_EventTimer

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10401	0x1803.05	-	0	U16	ms	RW	-	-

Event timer of the PDO TX 4.

PdoTx1_MappingParameters

Parameters for the PDO TX 1 mapping.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10500	0x1A00.00	0 - 8	1	U8	-	RW	-	-

Number of mapped objects.

PdoTx1_Objects

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
Desc	Desc	Desc	Desc	U32	-	RW	-	-

Parameters used for mapping the mappable parameters in the PDOs.

Modbus	CANopen	Name	Default
10501	0x1A00.01	PdoTx1_Object1	0x60410010 (Statusword)
10503	0x1A00.02	PdoTx1_Object2	0
10505	0x1A00.03	PdoTx1_Object3	0
10507	0x1A00.04	PdoTx1_Object4	0
10509	0x1A00.05	PdoTx1_Object5	0
10511	0x1A00.06	PdoTx1_Object6	0
10513	0x1A00.07	PdoTx1_Object7	0
10515	0x1A00.08	PdoTx1_Object8	0

PdoTx2_MappingParameters

Parameters for the PDO TX 2 mapping.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10525	0x1A01.00	0 - 8	2	U8	-	RW	-	-

Number of mapped objects.

PdoTx2_Objects

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
Desc	Desc	Desc	Desc	U32	-	RW	-	-

Parameters used for mapping the mappable parameters in the PDOs.

Modbus	CANopen	Name	Default
10526	0x1A01.01	PdoTx2_Object1	0x60410010 (Statusword)
10528	0x1A01.02	PdoTx2_Object2	0x60610008 (ModesOfOperationDisplay)
10530	0x1A01.03	PdoTx2_Object3	0
10532	0x1A01.04	PdoTx2_Object4	0
10534	0x1A01.05	PdoTx2_Object5	0
10536	0x1A01.06	PdoTx2_Object6	0
10538	0x1A01.07	PdoTx2_Object7	0
10540	0x1A01.08	PdoTx2_Object8	0

PdoTx3_MappingParameters

Parameters for the PDO TX 3 mapping.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10550	0x1A02.00	0 - 8	2	U8	-	RW	-	-

Number of mapped objects.

PdoTx3_Objects

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
Desc	Desc	Desc	Desc	U32	-	RW	-	-

Parameters used for mapping the mappable parameters in the PDOs.

Modbus	CANopen	Name	Default
10551	0x1A02.01	PdoTx3_Object1	0x60410010 (Statusword)
10553	0x1A02.02	PdoTx3_Object2	0x60640020 (PositionActualValue)
10555	0x1A02.03	PdoTx3_Object3	0
10557	0x1A02.04	PdoTx3_Object4	0
10559	0x1A02.05	PdoTx3_Object5	0
10561	0x1A02.06	PdoTx3_Object6	0
10563	0x1A02.07	PdoTx3_Object7	0
10565	0x1A02.08	PdoTx3_Object8	0

PdoTx4_MappingParameters

Parameters for the PDO TX 4 mapping.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
10575	0x1A03.00	0 - 8	2	U8	-	RW	-	-

Number of mapped objects.

PdoTx4_Objects

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
Desc	Desc	Desc	Desc	U32	-	RW	-	-

Parameters used for mapping the mappable parameters in the PDOs.

Modbus	CANopen	Name	Default
10576	0x1A03.01	PdoTx4_Object1	0x60410010 (Statusword)
10578	0x1A03.02	PdoTx4_Object2	0x606C0020 (VelocityActualValue)

Modbus	CANopen	Name	Default
10580	0x1A03.03	PdoTx4_Object3	0
10582	0x1A03.04	PdoTx4_Object4	0
10584	0x1A03.05	PdoTx4_Object5	0
10586	0x1A03.06	PdoTx4_Object6	0
10588	0x1A03.07	PdoTx4_Object7	0
10590	0x1A03.08	PdoTx4_Object8	0

27.24. Sync manager and PDOs managed by the port EtherCAT

NOTE

This vocabulary section can be found only in the drive versions ETC

PdoRx1_MappingParameters

Parameters for the PDO RX 1 mapping.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1600.00	0 - 8	2	U8	-	RW	-	-

Number of mapped objects.

PdoRx1_Objects

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
Desc	Desc	Desc	Desc	U32	-	RW	-	-

Parameters used for mapping the mappable parameters in the PDOs.

Modbus	CANopen	Name	Default
-	0x1600.01	PdoRx1_Object1	0x60400010 (Controlword)
-	0x1600.02	PdoRx1_Object2	0x60C10120 (IpPosFirstParameter)
-	0x1600.03	PdoRx1_Object3	0
-	0x1600.04	PdoRx1_Object4	0
-	0x1600.05	PdoRx1_Object5	0
-	0x1600.06	PdoRx1_Object6	0
-	0x1600.07	PdoRx1_Object7	0
-	0x1600.08	PdoRx1_Object8	0

PdoRx2_MappingParameters

Parameters for the PDO RX 2 mapping.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1601.00	0 - 8	6	U8	-	RW	-	-

Number of mapped objects.

PdoRx2_Objects

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
Desc	Desc	Desc	Desc	U32	-	RW	-	-

Parameters used for mapping the mappable parameters in the PDOs.

Modbus	CANopen	Name	Default
-	0x1601.01	PdoRx2_Object1	0x60400010 (Controlword)
-	0x1601.02	PdoRx2_Object2	0x607A0020 (TargetPosition)
-	0x1601.03	PdoRx2_Object3	0x60FF0020 (TargetVelocity)
-	0x1601.04	PdoRx2_Object4	0x60710010 (TargetTorque)
-	0x1601.05	PdoRx2_Object5	0x60720010 (MaxTorque)
-	0x1601.06	PdoRx2_Object6	0x60600008 (ModesOfOperation)
-	0x1601.07	PdoRx2_Object7	0
-	0x1601.08	PdoRx2_Object8	0

PdoRx3_MappingParameters

Parameters for the PDO RX 3 mapping.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1602.00	0 - 8	2	U8	-	RW	-	-

Number of mapped objects.

PdoRx3_Objects

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
Desc	Desc	Desc	Desc	U32	-	RW	-	-

Parameters used for mapping the mappable parameters in the PDOs.

Modbus	CANopen	Name	Default
-	0x1602.01	PdoRx3_Object1	0x60400010 (Controlword)

Modbus	CANopen	Name	Default
-	0x1602.02	PdoRx3_Object2	0x607A0020 (TargetPosition)
-	0x1602.03	PdoRx3_Object3	0
-	0x1602.04	PdoRx3_Object4	0
-	0x1602.05	PdoRx3_Object5	0
-	0x1602.06	PdoRx3_Object6	0
-	0x1602.07	PdoRx3_Object7	0
-	0x1602.08	PdoRx3_Object8	0

PdoRx4_MappingParameters

Parameters for the PDO RX 4 mapping.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1603.00	0 - 8	2	U8	-	RW	-	-

Number of mapped objects.

PdoRx4_Objects

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
Desc	Desc	Desc	Desc	U32	-	RW	-	-

Parameters used for mapping the mappable parameters in the PDOs.

Modbus	CANopen	Name	Default
-	0x1603.01	PdoRx4_Object1	0x60400010 (Controlword)
-	0x1603.02	PdoRx4_Object2	0x60FF0020 (TargetVelocity)
-	0x1603.03	PdoRx4_Object3	0
-	0x1603.04	PdoRx4_Object4	0
-	0x1603.05	PdoRx4_Object5	0
-	0x1603.06	PdoRx4_Object6	0
-	0x1603.07	PdoRx4_Object7	0
-	0x1603.08	PdoRx4_Object8	0

PdoTx1_MappingParameters

Parameters for the PDO TX 1 mapping.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1A00.00	0 - 8	2	U8	-	RW	-	-

Number of mapped objects.

PdoTx1_Objects

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
Desc	Desc	Desc	Desc	U32	-	RW	-	-

Parameters used for mapping the mappable parameters in the PDOs.

Modbus	CANopen	Name	Default
-	0x1A00.01	PdoTx1_Object1	0x60410010 (Statusword)
-	0x1A00.02	PdoTx1_Object2	0x60640020 (PositionActualValue)
-	0x1A00.03	PdoTx1_Object3	0
-	0x1A00.04	PdoTx1_Object4	0
-	0x1A00.05	PdoTx1_Object5	0
-	0x1A00.06	PdoTx1_Object6	0
-	0x1A00.07	PdoTx1_Object7	0
-	0x1A00.08	PdoTx1_Object8	0

PdoTx2_MappingParameters

Parameters for the PDO TX 2 mapping.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1A01.00	0 - 8	6	U8	-	RW	-	-

Number of mapped objects.

PdoTx2_Objects

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
Desc	Desc	Desc	Desc	U32	-	RW	-	-

Parameters used for mapping the mappable parameters in the PDOs.

Modbus	CANopen	Name	Default
-	0x1A01.01	PdoTx2_Object1	0x60410010 (Statusword)
-	0x1A01.02	PdoTx2_Object2	0x60640020 (PositionActualValue)
-	0x1A01.03	PdoTx2_Object3	0x60F40020 (PositionFollowingError)
-	0x1A01.04	PdoTx2_Object4	0x60770010 (ActualTorque)
-	0x1A01.05	PdoTx2_Object5	0x60610008 (ModesOfOperationDisplay)
-	0x1A01.06	PdoTx2_Object6	0x606C0020
-	0x1A01.07	PdoTx2_Object7	0

Modbus	CANopen	Name	Default
-	0x1A01.08	PdoTx2_Object8	0

PdoTx3_MappingParameters

Parameters for the PDO TX 3 mapping.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1A02.00	0 - 8	2	U8	-	RW	-	-

Number of mapped objects.

PdoTx3_Objects

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
Desc	Desc	Desc	Desc	U32	-	RW	-	-

Parameters used for mapping the mappable parameters in the PDOs.

Modbus	CANopen	Name	Default
-	0x1A02.01	PdoTx3_Object1	0x60410010 (Statusword)
-	0x1A02.02	PdoTx3_Object2	0x60640020 (PositionActualValue)
-	0x1A02.03	PdoTx3_Object3	0
-	0x1A02.04	PdoTx3_Object4	0
-	0x1A02.05	PdoTx3_Object5	0
-	0x1A02.06	PdoTx3_Object6	0
-	0x1A02.07	PdoTx3_Object7	0
-	0x1A02.08	PdoTx3_Object8	0

PdoTx4_MappingParameters

Parameters for the PDO TX 4 mapping.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1A03.00	0 - 8	3	U8	-	RW	-	-

Number of mapped objects.

PdoTx4_Objects

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
Desc	Desc	Desc	Desc	U32	-	RW	-	-

Parameters used for mapping the mappable parameters in the PDOs.

Modbus	CANopen	Name	Default
-	0x1A03.01	PdoTx4_Object1	0x60410010 (Statusword)
-	0x1A03.02	PdoTx4_Object2	0x60640020 (PositionActualValue)
-	0x1A03.03	PdoTx4_Object3	0x606C0020 (VelocityActualValue)
-	0x1A03.04	PdoTx4_Object4	0
-	0x1A03.05	PdoTx4_Object5	0
-	0x1A03.06	PdoTx4_Object6	0
-	0x1A03.07	PdoTx4_Object7	0
-	0x1A03.08	PdoTx4_Object8	0

SM_CommunicationType

Communication type set in the Sync Manager.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1C00.00	4	4	U8	-	CST	-	-

Number of parameters in this group.

SM0_CommunicationType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1C00.01	1	1	U8	-	RO	-	ES

Communication type of the Sync manager 0. In [Table 27.25](#) you can find the accepted values.

Value	Communication type of the Sync Manager
1	Mailbox RX
2	Mailbox TX
3	Process data RX
4	Process data TX

Table 27.25. Sync Manager Communication Type

SM1_CommunicationType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1C00.02	2	2	U8	-	RO	-	ES

Communication type of the Sync manager 1. In [Table 27.25](#) you can find the accepted values.

SM2_CommunicationType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1C00.03	3	3	U8	-	RO	-	ES

Communication type of the Sync manager 2. In [Table 27.25](#) you can find the accepted values.

SM3_CommunicationType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1C00.04	4	4	U8	-	RO	-	ES

Communication type of the Sync manager 3. In [Table 27.25](#) you can find the accepted values.

SM0_PdoAssignment

Parameters for the assignment of the PDOs to the Sync Manager 0.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1C10.00	0	0	U8	-	RO	-	-

Number of PDOs given to the Sync Manager 0. For this Sync Manager it is not possible to assign any PDO.

SM0_PdoMapping

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
Desc	Desc	Desc	Desc	U16	-	RO	-	-

Parameters for the assignment of the PDOs to the Sync Manager 0. For this Sync Manager it is not possible to assign any PDO.

Modbus	CANopen	Name	Default
-	0x1C10.01	SM0_PdoMapping0	0
-	0x1C10.02	SM0_PdoMapping1	0
-	0x1C10.03	SM0_PdoMapping2	0
-	0x1C10.04	SM0_PdoMapping3	0

SM1_PdoAssignment

Parameters for the assignment of the PDOs to the Sync Manager 1.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1C11.00	0	0	U8	-	RO	-	-

Number of PDOs given to the Sync Manager 1. For this Sync Manager it is not possible to assign any PDO.

SM1_PdoMapping

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
Desc	Desc	Desc	Desc	U16	-	RO	-	-

Parameters for the assignment of the PDOs to the Sync Manager 1. For this Sync Manager it is not possible to assign any PDO.

Modbus	CANopen	Name	Default
-	0x1C11.01	SM1_PdoMapping0	0
-	0x1C11.02	SM1_PdoMapping1	0
-	0x1C11.03	SM1_PdoMapping2	0
-	0x1C11.04	SM1_PdoMapping3	0

SM2_PdoAssignment

Parameters for the assignment of the PDOs to the Sync Manager 2.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1C12.00	0-4	1	U8	-	RW	-	-

Number of PDOs given to the Sync Manager 2.

SM2_PdoMapping

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
Desc	Desc	Desc	Desc	U16	-	RW	-	-

Parameters for the assignment of the PDOs to the Sync Manager 2, for this Sync Manager it is possible to assign only PDO RX. The assignment takes place by writing the index CANopen (without subindex) of the *PDO RX Mapping parameters* that you want to assign.

Modbus	CANopen	Name	Default
-	0x1C12.01	SM2_PdoMapping0	0x1600 (PdoRx1_MappingParameters)
-	0x1C12.02	SM2_PdoMapping1	0
-	0x1C12.03	SM2_PdoMapping2	0
-	0x1C12.04	SM2_PdoMapping3	0

SM3_PdoAssignment

Parameters for the assignment of the PDOs to the Sync Manager 3.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1C13.00	0-4	1	U8	-	RW	-	-

Number of PDOs assigned to the Sync Manager 3.

SM3_PdoMapping

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
Desc	Desc	Desc	Desc	U16	-	RW	-	-

Parameters for the assignment of the PDOs to the Sync Manager 3, for this Sync Manager it is possible to assign only PDO TX. The assignment takes place by writing the index CANopen (without subindex) of the *PDO TX Mapping parameters* that you want to assign.

Modbus	CANopen	Name	Default
-	0x1C13.01	SM3_PdoMapping0	0x1A00 (PdoTx1_MappingParameters)
-	0x1C13.02	SM3_PdoMapping1	0
-	0x1C13.03	SM3_PdoMapping2	0
-	0x1C13.04	SM3_PdoMapping3	0

SM0_Synchronization

Parameters used for the management of the messages synchronization of the sync 0.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1C30.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

SM0_SynchronizationType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1C30.01	0	0	U16	-	RO	-	-

Synchronization type of the messages managed by the Sync Manager 0.

SM0_CycleTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1C30.02	0	0	U32	ns	RO	-	-

Time period of the messages managed by the Sync Manager 0.

SM0_ShiftTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1C30.03	0	0	U32	ns	RO	-	-

Time interval between the receiving/sending of the messages managed by the Sync Manager 0 and their application.

SM1_Synchronization

Parameters used for the management of the messages synchronization of the sync 1.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1C31.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

SM1_SynchronizationType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1C31.01	0	0	U16	-	RO	-	-

Synchronization type of the messages managed by the Sync Manager 1.

SM1_CycleTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1C31.02	0	0	U32	ns	RO	-	-

Time period of the messages managed by the Sync Manager 1.

SM1_ShiftTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1C31.03	0	0	U32	ns	RO	-	-

Time interval between the receiving/sending of the messages managed by the Sync Manager 1 and their application.

SM2_Synchronization

Parameters used for the management of the messages synchronization of the sync 2.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1C32.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

SM2_SynchronizationType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
11200	0x1C32.01	0 - 2	1	U16	-	RW	-	-

Synchronization type of the messages managed by the Sync Manager 2. In [Table 27.26](#) you can find the meaning of the values.

Value	Synchronization type of the Sync Manager
0	Free run. No synchronization.
1	Synchronized on this Sync Manager. Synchronization of the event started by the Sync Manager on which this setting is applied.
2	Synchronized on <i>Sync Signal 0</i> . Synchronization on the signal Sync 0 managed by the <i>Distributed clocks</i> .
34	Synchronized on <i>SM 2</i> . Synchronization of the event started by the Sync Manager 2.

Table 27.26. Sync Manager Synchronization Type

SM2_CycleTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
11201	0x1C32.02	0	0	U32	ns	RW	-	-

Time period of the messages managed by the Sync Manager 2. Only times that are multiples of 1 μ s are admitted.

SM2_ShiftTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
11203	0x1C32.03	0	0	U32	ns	RO	-	-

Time interval between the receiving/sending of the messages managed by the Sync Manager 2 and their application.

SM3_Synchronization

Parameters used for the management of the messages synchronization of the sync 3.

Number of entries

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
-	0x1C33.00	3	3	U8	-	CST	-	-

Number of parameters in this group.

SM3_SynchronizationType

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
11300	0x1C33.01	0; 2; 34	34	U16	-	RW	-	-

Synchronization type of the messages managed by the Sync Manager 3. In [Table 27.26](#) you can find the meaning of the values.

SM3_CycleTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
11301	0x1C33.02	0	0	U32	ns	RW	-	-

Time period of the messages managed by the Sync Manager 3. Only times that are multiples of 1 μ s are admitted.

SM3_ShiftTime

Modbus	CANopen	Range	Default	Type	Units	Acc	PDO	Mem
11303	0x1C33.03	0	0	U32	ns	RO	-	-

Time interval between the receiving/sending of the messages managed by the Sync Manager 3 and their application.

Chapter 28

Digital filters

The drives of the *iBMD* series provide a library of programmable digital filters. The available filters are:

- All-pass filter
- Low-pass filter of the first order
- Low-pass filter of the second order
- Band-eliminating filter
- All-stop filter.

The parameters of every filter can be modified in any moment, even during the working of the filter. The output of the filter adjusts in real time to the new settings.

ADVICE

Do not set the frequencies of the filters at 0 Hz or at values which are one third higher than the frequency of the filter sampling.

All-pass filter

The all-pass filter or transparent filter does not apply any filtering action. The input signal of the filter is brought back to the output with unity gain and without phase delay.

Low-pass filter of the first order

The low-pass filter of the first order is implemented in the *iBMD* drive series as a Butterworth low-pass digital filter of the first order with pre-warping compensation. Here follow the Bode diagrams of the function of filter transfer as the frequency changes, normalized at the value of the critical frequency. You can notice that for frequencies higher than the critical frequency, the module slope is -20dB/decade and the maximum phase delay is 90°.




Figure 28.1. Bode diagrams of the transfer function of the low-pass filter of the first Butterworth order.

NOTE

Setting the frequency at 0 means having a filter with an infinite attenuation band. This condition cannot be accepted because the filter loses its low-pass property. It is not recommended to use the filter under these conditions.

Low-pass filter of the second order

The low-pass filter of the second order is implemented in the *iBMD* drive series as a Butterworth low-pass digital filter of the second order with pre-warping compensation. Here follow the Bode diagrams of the function of filter transfer as the frequency changes, normalized at the value of the critical frequency. You can notice that for frequencies higher than the critical frequency, the module slope is -40dB/decade and the maximum phase delay is 180°.




Figure 28.2. Bode diagrams of the transfer function of the low-pass filter of the second Butterworth order.

NOTE

Setting the frequency at 0 means having a filter with an infinite attenuation band. This condition cannot be accepted because the filter loses its low-pass property. It is not recommended to use the filter under these conditions.

All-stop filter

The all-stop filter stops the passing of every signal by resetting at zero its output.

Band-eliminating filter

The band-eliminating filter is implemented in the *iBMD* drive series as a Notch filter of the second order with pre-warping compensation. Here follow the Bode diagrams of the function of filter transfer as the frequency changes, normalized at the value of the central frequency, for different values of the Q quality factor.




Figure 28.3. Bode diagrams of the transfer function of the Notch filter of the second order.

NOTE


Setting a Q quality factor at 0 means having a filter with an infinite attenuation band. This condition cannot be accepted because the filter loses its band-eliminating property. Furthermore when the Q quality factor increases and the central frequency decreases, the filter convergence time increases. It is not recommended to use the filter under these conditions.

Chapter 29

Order codes

29.1. OrderCode

The **iBMD** series drives are available in different models with various functionalities. The **ManufacturerDeviceName**, that's composed by the order coded preceded by the product name (e.g. **iBMD**), defines the features and the functionalities, and identifies the drive model.



*Figure 29.1. Position of the fields in the **ManufacturerDeviceName**.*

ManufacturerDeviceName		0	1	2	3	4	5	6	7	8	9	10
Field	Description	Value										
Series	Integrated brushless drive	iBMD										
Motor size	Flange 82mm; 2.7Nm, 3.8Nm		82									
	Flange 102mm; 5.1Nm, 6.2Nm		102									
	Flange 145mm; 14.5Nm, 18.5Nm		145									
	Flange 170mm; 29Nm, 36Nm		170									
Motor stall torque	Flange 82mm; 2.7Nm			2.7								
	Flange 82mm; 3.8Nm			3.8								
	Flange 102mm; 5.1Nm			5.1								
	Flange 102mm; 6.2Nm			6.2								
	Flange 145mm; 14.5Nm			14.5								
	Flange 145mm; 18.5Nm			18.5								
	Flange 170mm; 29Nm			29								
	Flange 170mm; 36Nm			36								
Motor rated speed	All drives				3000							
Nominal DC voltage	All drives					560						
Mechanical interface	Size 82, 102						100					
	Size 82, 102						115					
	Size 145, 170						165					
Shaft diameter	Size 82							11				
	Size 82							14				
	Size 82, 102, 145							19				
	Size 102, 145, 170							24				
	Size 145, 170							28				
	Size 170							32				
Shaft keyway	With key									K		
	Without key									NK		
Absolute encoders	Single turn (16 sin/cos)									S1C		
	Single turn (128 sin/cos)									S1O		
	Multi turn (16 sin/cos - 4096 turns)									M1C		
	Multi turn (128 sin/cos - 4096 turns)									M1O		
Brake or Flywheel	Brake 24Vdc										F24	
	Flywheel										F1	
Communication interface	Fieldbus											CAN
												ETC

Table 29.1. Fields that make up the *ManufacturerDeviceName*.

NOTE

In regards to the [Table 29.1](#) not all the combinations are possible. Please contact the sales office to verify the order possibilities.



Bonfiglioli has been designing and developing innovative and reliable power transmission and control solutions for industry, mobile machinery and renewable energy applications since 1956.